


# FE170CG System Repair Guides


# FE170CG System Repair Guides

- No Power
- Display Error
- Camera Error
- Touch Error
- Audio Error
- Bluetooth Error
- SD/ SIM Card Error
- 2/3G Voice Error
- BT/WIFI Error
- GSP Error


# No Power



# Display Error




# Camera Error




Open cam app fail  
Or capture fail

# Touch Error






# Audio Error




# SD Card Error







# SIM Card Error



# 2/3G Test Procedure



# BT/WiFi Repair Test Procedure



# GPS Repair Test Procedure

