

5. MAIN Electrical Parts List

[SM-J610F]

Parts Code	Design LOC	Description
0401-001110	ZD6000	DIODE-SWICHGING
0404-001250	D4001	DIODE-SCHOTTKY
0404-001646	D6004	DIODE-SCHOTTKY
0406-001561	D4015,D4016,D5000	DIODE-TVS
0406-001561	D5003	DIODE-TVS
0406-001592	D4012,D6011,D6013	DIODE-TVS
0406-001592	D6014,D6017	DIODE-TVS
0406-001682	D5010	DIODE-TVS
0406-001709	D5013	DIODE-TVS
0406-001728	D4008	DIODE-TVS
0406-001743	D4002,D4003	DIODE-TVS
0406-001776	D4004,D4005,D4006	DIODE-TVS
0406-001776	D4007	DIODE-TVS
0406-001781	D5007,D5008	DIODE-TVS
0406-001789	D4013,D4014,D6012	DIODE-TVS
0406-001797	D4009,D4010	DIODE-TVS
0406-001807	D4000	DIODE-TVS
0406-001808	D4011	DIODE-TVS
0505-002088	TR4001,TR6000	FET-SILICON
0505-003618	TR4002	FET-SILICON
0601-003734	LED4001	LED
0601-003735	LED4000	LED
1001-001655	U4006	IC
1001-001968	U5000	IC
1001-001969	U2000	IC
1001-001970	U1004,U1007	IC
1001-002022	U2003	IC
1001-002046	U1001,U1002	IC
1108-000638	UME5000	MEMORY
1201-003786	U2006	IC
1201-003984	U1006	IC
1201-003985	U1100	IC
1201-004109	PAM1001	IC
1201-004209	PAM1000	IC
1203-008251	U6019	IC
1203-008379	U2002	IC
1203-008468	U4007	IC

5. MAIN Electrical Parts List

1203-008575	U6009	IC
1203-008603	U6014	IC
1203-008816	PM4000	IC
1203-008859	U6012	IC
1203-008865	U6001	IC
1203-008867	U6006,U6024	IC
1203-008870	U6005,U6007	IC
1203-008955	U6013	IC
1203-008995	U4004	IC
1205-005217	U6011	IC
1205-005493	U1016	IC
1205-005525	U2008	IC
1205-006027	UCP3000	IC
1209-002413	U6015	IC
1209-002414	U6017	IC
1209-002450	U6016	IC
1404-001664	TH1000,TH3000,TH3001	THERMISTOR
1405-001404	VR6001	VARISTOR
2007-003015	R4025,R4026	R-CHIP
2007-003025	R5024,R5085	R-CHIP
2007-007142	R6005,R6011,R6012	R-CHIP
2007-007142	R6014	R-CHIP
2007-007315	R3000	R-CHIP
2007-007317	R3007,R3008	R-CHIP
2007-007741	R3034,R3035,R3037	R-CHIP
2007-007741	R3039,R4019,R5002	R-CHIP
2007-007741	R5023,R6002,R6004	R-CHIP
2007-007741	R6024	R-CHIP
2007-007798	R4027	R-CHIP
2007-008210	R1000,R4129	R-CHIP
2007-008304	R5011	R-CHIP
2007-008419	R4007,R4014	R-CHIP
2007-008531	R5008,R6000,R6001	R-CHIP
2007-008531	R6003	R-CHIP
2007-008579	R1013	R-CHIP
2007-008582	R1002,R1003	R-CHIP
2007-008788	R3027	R-CHIP
2007-008798	R4028,R4029	R-CHIP
2007-009111	R6006	R-CHIP

5. MAIN Electrical Parts List

2007-009155	R5009	R-CHIP
2007-009157	R1009,R2009,R3029	R-CHIP
2007-009157	R3030,R4000,R4005	R-CHIP
2007-009157	R4016,R5016,R5026	R-CHIP
2007-009157	R5086	R-CHIP
2007-009158	R4006	R-CHIP
2007-009171	R4018	R-CHIP
2007-009212	R3032,R5006	R-CHIP
2007-009223	R5017	R-CHIP
2007-009314	R4022,R4023,R4024	R-CHIP
2007-009315	R4111,R4112,R4113	R-CHIP
2007-009315	R4114,R4115,R4116	R-CHIP
2007-009315	R4117,R4118,R4120	R-CHIP
2007-009315	R4121,R4122,R4123	R-CHIP
2007-009315	R4125,R4126,R4127	R-CHIP
2007-009408	R3015,R3016,R3017	R-CHIP
2007-009408	R3018,R3021,R3022	R-CHIP
2007-009408	R3023,R3024,R3025	R-CHIP
2007-009408	R3026	R-CHIP
2007-009793	R5019	R-CHIP
2007-009801	R4015,R5005,R5007	R-CHIP
2007-009801	R5018	R-CHIP
2007-009805	R1001,R1006,R1010	R-CHIP
2007-009805	R1024	R-CHIP
2007-009866	R5020	R-CHIP
2007-009920	R3002,R5012,R5013	R-CHIP
2007-009924	R5022	R-CHIP
2007-009969	R5010	R-CHIP
2007-010202	R5021	R-CHIP
2007-010685	R3001	R-CHIP
2007-011043	R3028	R-CHIP
2007-012068	R4021	R-CHIP
2203-000425	C6034	C-CERAMIC,CHIP
2203-001239	C6035	C-CERAMIC,CHIP
2203-002677	C2090	C-CERAMIC,CHIP
2203-005682	C1004,C1041,C1056	C-CERAMIC,CHIP
2203-005682	C1057,C1132,C1164	C-CERAMIC,CHIP
2203-005682	C1201,C1202,C2021	C-CERAMIC,CHIP
2203-005682	C2022,C2023,C2039	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-005682	C2040,C5033,C6065	C-CERAMIC,CHIP
2203-005682	C6068,C6071,L2047	C-CERAMIC,CHIP
2203-005719	C6062	C-CERAMIC,CHIP
2203-005725	C1151,C1153,C1154	C-CERAMIC,CHIP
2203-005725	C1157,C1169,L1033	C-CERAMIC,CHIP
2203-005725	L1044	C-CERAMIC,CHIP
2203-005729	C1131,C5004,C5023	C-CERAMIC,CHIP
2203-005729	C5032,C5036,C5040	C-CERAMIC,CHIP
2203-005729	C6004,C6005	C-CERAMIC,CHIP
2203-005732	C5030,C5034,C5035	C-CERAMIC,CHIP
2203-005732	C5041	C-CERAMIC,CHIP
2203-005734	C1001,C1105,C2083	C-CERAMIC,CHIP
2203-005736	C1003,C1011,C1027	C-CERAMIC,CHIP
2203-005736	C1031,C1046,C1047	C-CERAMIC,CHIP
2203-005736	C1052,C1060,C1069	C-CERAMIC,CHIP
2203-005736	C1100,C1102,C1111	C-CERAMIC,CHIP
2203-005736	C1120,C1124,C1133	C-CERAMIC,CHIP
2203-005736	C1134,C1138,C1142	C-CERAMIC,CHIP
2203-005736	C1152,C1158,C1165	C-CERAMIC,CHIP
2203-005736	C1166,C1172,C1173	C-CERAMIC,CHIP
2203-005736	C1178,C1184,C1185	C-CERAMIC,CHIP
2203-005736	C1186,C1187,C2002	C-CERAMIC,CHIP
2203-005736	C2005,C2011,C2013	C-CERAMIC,CHIP
2203-005736	C2020,C2028,C2030	C-CERAMIC,CHIP
2203-005736	C2032,C2034,C2038	C-CERAMIC,CHIP
2203-005736	C2044,C2045,C2088	C-CERAMIC,CHIP
2203-005736	C2102,C2105,C6047	C-CERAMIC,CHIP
2203-005736	C6063,L1011,L1012	C-CERAMIC,CHIP
2203-005736	L1014,L1026,L1040	C-CERAMIC,CHIP
2203-005736	L1057,L1082,L1088	C-CERAMIC,CHIP
2203-005736	L1100,L1102,L2011	C-CERAMIC,CHIP
2203-005736	L2018,L2024,R1015	C-CERAMIC,CHIP
2203-005736	R1025	C-CERAMIC,CHIP
2203-005777	C1023,C1024,C1125	C-CERAMIC,CHIP
2203-005777	C1129,C2087,L1002	C-CERAMIC,CHIP
2203-005777	L1062,L1070,L2034	C-CERAMIC,CHIP
2203-005777	L2042	C-CERAMIC,CHIP
2203-005789	C2001,C2006,C2007	C-CERAMIC,CHIP
2203-005789	C2010,C2093,L2026	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-005792	L2035	C-CERAMIC,CHIP
2203-005806	C1163,C2018,C2026	C-CERAMIC,CHIP
2203-005806	C2054,C3073,C3074	C-CERAMIC,CHIP
2203-005806	C4000	C-CERAMIC,CHIP
2203-006121	C5026	C-CERAMIC,CHIP
2203-006194	C2100,C2101,C2106	C-CERAMIC,CHIP
2203-006194	C4093,C4095	C-CERAMIC,CHIP
2203-006305	C2046,L2031	C-CERAMIC,CHIP
2203-006318	C1022,C1050,C1122	C-CERAMIC,CHIP
2203-006318	C2089,L1029	C-CERAMIC,CHIP
2203-006399	C6042	C-CERAMIC,CHIP
2203-006400	C1107,C1130,C1200	C-CERAMIC,CHIP
2203-006410	C2092	C-CERAMIC,CHIP
2203-006423	C1025,C1045,C1139	C-CERAMIC,CHIP
2203-006423	C1145,C1146,C1147	C-CERAMIC,CHIP
2203-006423	C3000,C3001,C3002	C-CERAMIC,CHIP
2203-006423	C3010,C3011,C3012	C-CERAMIC,CHIP
2203-006423	C3016,C3017,C3018	C-CERAMIC,CHIP
2203-006423	C3019,C3020,C3021	C-CERAMIC,CHIP
2203-006423	C3022,C3029,C3030	C-CERAMIC,CHIP
2203-006423	C3031,C3032,C3033	C-CERAMIC,CHIP
2203-006423	C3034,C3035,C3036	C-CERAMIC,CHIP
2203-006423	C3037,C3038,C3039	C-CERAMIC,CHIP
2203-006423	C3040,C3041,C3042	C-CERAMIC,CHIP
2203-006423	C3043,C3044,C3045	C-CERAMIC,CHIP
2203-006423	C3046,C3047,C3048	C-CERAMIC,CHIP
2203-006423	C3052,C3054,C3055	C-CERAMIC,CHIP
2203-006423	C3056,C3057,C3058	C-CERAMIC,CHIP
2203-006423	C3070,C3071,C3072	C-CERAMIC,CHIP
2203-006423	C3076,C3077,C3078	C-CERAMIC,CHIP
2203-006423	C3080,C3081,C3082	C-CERAMIC,CHIP
2203-006423	C3083,C3084,C3085	C-CERAMIC,CHIP
2203-006423	C3086,C4005,C4016	C-CERAMIC,CHIP
2203-006423	C4022,C4024,C4056	C-CERAMIC,CHIP
2203-006423	C4075,C5010,C5013	C-CERAMIC,CHIP
2203-006423	C5019,C5022,C5025	C-CERAMIC,CHIP
2203-006423	C6057,C6058	C-CERAMIC,CHIP
2203-006556	C5027	C-CERAMIC,CHIP
2203-006604	C1064,C4082,C4083	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-006604	C4084,C4085,L1045	C-CERAMIC,CHIP
2203-006648	C2110	C-CERAMIC,CHIP
2203-006665	L1061	C-CERAMIC,CHIP
2203-006707	C2061	C-CERAMIC,CHIP
2203-006839	C3068,C3069,C4029	C-CERAMIC,CHIP
2203-006839	C6026,C6032,C6066	C-CERAMIC,CHIP
2203-006846	C1035,C1075	C-CERAMIC,CHIP
2203-006896	C1159,C5020,C5021	C-CERAMIC,CHIP
2203-006968	L2049	C-CERAMIC,CHIP
2203-006979	C1136,C1148,C1167	C-CERAMIC,CHIP
2203-006979	U1012	C-CERAMIC,CHIP
2203-007194	C2117,C6045,L1024	C-CERAMIC,CHIP
2203-007210	C3064,C4077,C5005	C-CERAMIC,CHIP
2203-007210	C5008,C5009,C5015	C-CERAMIC,CHIP
2203-007210	C5017	C-CERAMIC,CHIP
2203-007271	C4060,C4076	C-CERAMIC,CHIP
2203-007295	C2091	C-CERAMIC,CHIP
2203-007317	C4080,C6007,C6009	C-CERAMIC,CHIP
2203-007317	C6038,C6056	C-CERAMIC,CHIP
2203-007391	C1144,C2099,C4094	C-CERAMIC,CHIP
2203-007391	C4096,C5011	C-CERAMIC,CHIP
2203-007393	C2008,C2015,C2107	C-CERAMIC,CHIP
2203-007393	C3004,C3023,C3062	C-CERAMIC,CHIP
2203-007393	C3092,C4008,C4010	C-CERAMIC,CHIP
2203-007393	C4012,C4020,C4025	C-CERAMIC,CHIP
2203-007393	C4026,C4027,C4028	C-CERAMIC,CHIP
2203-007393	C4045,C5016,C5018	C-CERAMIC,CHIP
2203-007781	C3094,C3097,C3098	C-CERAMIC,CHIP
2203-007781	C3099,C3100,C3101	C-CERAMIC,CHIP
2203-007781	C3102,C3103,C4030	C-CERAMIC,CHIP
2203-007781	C4031,C4053,C4054	C-CERAMIC,CHIP
2203-007781	C4055,C4057,C4098	C-CERAMIC,CHIP
2203-007796	C2103,C3005,C3024	C-CERAMIC,CHIP
2203-007796	C3025,C3026,C3050	C-CERAMIC,CHIP
2203-007796	C3051,C3053,C3060	C-CERAMIC,CHIP
2203-007796	C3061,C3065,C3090	C-CERAMIC,CHIP
2203-007796	C3091,C4004,C4006	C-CERAMIC,CHIP
2203-007796	C4007,C4009,C4011	C-CERAMIC,CHIP
2203-007796	C4013,C4014,C4019	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-007796	C4023,C4050,C4062	C-CERAMIC,CHIP
2203-007796	C5001,C5002,C5003	C-CERAMIC,CHIP
2203-007796	C5006,C5007,C5014	C-CERAMIC,CHIP
2203-007796	C6006,C6012,C6018	C-CERAMIC,CHIP
2203-007796	C6020,C6029,C6030	C-CERAMIC,CHIP
2203-007796	C6041,C6049,C6051	C-CERAMIC,CHIP
2203-007796	C6059,C6060,C6073	C-CERAMIC,CHIP
2203-007796	C6078	C-CERAMIC,CHIP
2203-008094	C4073	C-CERAMIC,CHIP
2203-008097	C1033	C-CERAMIC,CHIP
2203-008572	C4035,C4038	C-CERAMIC,CHIP
2203-008654	C4091	C-CERAMIC,CHIP
2203-008749	C6036	C-CERAMIC,CHIP
2203-008860	C1141,C1149,C3066	C-CERAMIC,CHIP
2203-008860	C4033,C4037,C4049	C-CERAMIC,CHIP
2203-008860	C4051,C4069,C4071	C-CERAMIC,CHIP
2203-008860	C4079,C6016,C6019	C-CERAMIC,CHIP
2203-008860	C6021,C6027,C6040	C-CERAMIC,CHIP
2203-008860	C6053,C6070,C6072	C-CERAMIC,CHIP
2203-008876	C1026,C1032,C1135	C-CERAMIC,CHIP
2203-008876	C1140,C3049,C4002	C-CERAMIC,CHIP
2203-008876	C4003,C4034,C4036	C-CERAMIC,CHIP
2203-008876	C4039,C4040,C4043	C-CERAMIC,CHIP
2203-008876	C4044,C4046,C4047	C-CERAMIC,CHIP
2203-008876	C5000,C6031,C6061	C-CERAMIC,CHIP
2203-008876	C6064,C6067	C-CERAMIC,CHIP
2203-009733	C1034,C2012,C2073	C-CERAMIC,CHIP
2203-009733	C2074,C2104,C4048	C-CERAMIC,CHIP
2203-009733	C4059,C4089,C6014	C-CERAMIC,CHIP
2203-009733	C6015,C6033,C6037	C-CERAMIC,CHIP
2203-009733	C6039,C6043,C6046	C-CERAMIC,CHIP
2203-009733	C6048,C6074	C-CERAMIC,CHIP
2203-009736	C6010	C-CERAMIC,CHIP
2203-010085	C4058,C4063	C-CERAMIC,CHIP
2703-002268	L2052	INDUCTOR-SMD
2703-002308	L5015	INDUCTOR-SMD
2703-002901	C1007,L1034,L2022	INDUCTOR-SMD
2703-002903	C1036,C1065,C1089	INDUCTOR-SMD
2703-002903	L1036,L1103	INDUCTOR-SMD

5. MAIN Electrical Parts List

2703-002907	L1066	INDUCTOR-SMD
2703-002951	L1041,L4009,L4011	INDUCTOR-SMD
2703-002955	C1021,L1084,L1085	INDUCTOR-SMD
2703-002955	L1086,L1087,L4010	INDUCTOR-SMD
2703-002955	L4012	INDUCTOR-SMD
2703-002958	L1003	INDUCTOR-SMD
2703-002959	L2005,L2008,L2012	INDUCTOR-SMD
2703-002959	L2048,L2057	INDUCTOR-SMD
2703-002999	C1104,C1150	INDUCTOR-SMD
2703-003878	L5008	INDUCTOR-SMD
2703-003970	L1009	INDUCTOR-SMD
2703-004000	L1090	INDUCTOR-SMD
2703-004012	C1055,C1070,C2056	INDUCTOR-SMD
2703-004012	C2057,L1018,L2000	INDUCTOR-SMD
2703-004013	C1028,C1044,C1118	INDUCTOR-SMD
2703-004013	C1143,C2029,L1031	INDUCTOR-SMD
2703-004013	L1068,L1073	INDUCTOR-SMD
2703-004014	L1055,L1104,L2039	INDUCTOR-SMD
2703-004014	L2054	INDUCTOR-SMD
2703-004018	L1027,L1056	INDUCTOR-SMD
2703-004034	C1005,C1121,C2003	INDUCTOR-SMD
2703-004034	L1010,L1054,L2037	INDUCTOR-SMD
2703-004036	C2059,L1023	INDUCTOR-SMD
2703-004193	L5017,L5018	INDUCTOR-SMD
2703-004286	C2024,C2031,C2058	INDUCTOR-SMD
2703-004286	L1022,L1025,L1079	INDUCTOR-SMD
2703-004286	L1089,L2029,L2032	INDUCTOR-SMD
2703-004286	L2038	INDUCTOR-SMD
2703-004288	C1103,L1028,L2002	INDUCTOR-SMD
2703-004288	L2044	INDUCTOR-SMD
2703-004289	C2047,L1072,L2033	INDUCTOR-SMD
2703-004300	L1004,L1007,L1078	INDUCTOR-SMD
2703-004300	L2001	INDUCTOR-SMD
2703-004301	L1064	INDUCTOR-SMD
2703-004317	C1019,C1038,C1101	INDUCTOR-SMD
2703-004317	L1000,L1008,L1021	INDUCTOR-SMD
2703-004317	L1058	INDUCTOR-SMD
2703-004328	L1059,L2007,L2061	INDUCTOR-SMD
2703-004328	L2062	INDUCTOR-SMD

5. MAIN Electrical Parts List

2703-004362	L2059	INDUCTOR-SMD
2703-004363	C2052	INDUCTOR-SMD
2703-004366	L2043	INDUCTOR-SMD
2703-004367	L2046	INDUCTOR-SMD
2703-004368	C1116	INDUCTOR-SMD
2703-004684	L3000	INDUCTOR-SMD
2703-004763	C1048	INDUCTOR-SMD
2703-004862	C1018,L1060,L2045	INDUCTOR-SMD
2703-004947	L4003,L4005	INDUCTOR-SMD
2703-004976	C2120	INDUCTOR-SMD
2703-005067	L4007,L4008	INDUCTOR-SMD
2703-005085	C1017,C2055	INDUCTOR-SMD
2703-005087	C1113,C1171,C2037	INDUCTOR-SMD
2703-005087	C2041,L2019	INDUCTOR-SMD
2703-005088	C1051,C2033	INDUCTOR-SMD
2703-005101	L2015	INDUCTOR-SMD
2703-005109	L4002	INDUCTOR-SMD
2703-005116	L6005	INDUCTOR-SMD
2703-005118	L6003	INDUCTOR-SMD
2703-005224	L4006	INDUCTOR-SMD
2703-005339	L4013,L4014	INDUCTOR-SMD
2801-005300	OSC4000	CRYSTAL-UNIT
2904-002137	F1100	FILTER-SAW
2904-002143	F1001	FILTER-SAW
2904-002198	F2004	FILTER-SAW
2904-002339	F2000	FILTER-SAW
2904-002350	F1005	FILTER-SAW
2904-002355	F2002	FILTER-SAW
2904-002381	F2006	FILTER-SAW
2904-002394	F2003	FILTER-SAW
2904-002397	F1004	FILTER-SAW
2910-000401	F1006	FILTER
2911-000435	U2005	FILTER
2911-000450	U1003	FILTER
3003-001215	MIC5000	MIC-CONDENSOR
3301-001812	L6004	CORE-FERRITE BEAD
3301-001885	L5016	CORE-FERRITE BEAD
3301-001901	L6002	CORE-FERRITE BEAD
3301-002078	L5013,L5014	CORE-FERRITE BEAD

5. MAIN Electrical Parts List

3301-002122	L5019,L5020	CORE-FERRITE BEAD
3301-002223	L6001,L6010	CORE-FERRITE BEAD
3301-002236	L2016,L2023,L5005	CORE-FERRITE BEAD
3301-002236	L5007,L5009,L5011	CORE-FERRITE BEAD
3301-002236	L5012	CORE-FERRITE BEAD
3301-002237	L1001,L1017,L5000	CORE-FERRITE BEAD
3301-002237	L5001,L6006,L6007	CORE-FERRITE BEAD
3301-002238	L2006	CORE-FERRITE BEAD
3301-002248	L2053,L2063	CORE-FERRITE BEAD
3301-002254	L4000	CORE-FERRITE BEAD
3301-002286	L5010	CORE-FERRITE BEAD
3301-002309	L2041,L5004	CORE-FERRITE BEAD
3301-002312	L4004	CORE-FERRITE BEAD
3705-001708	RFS1000	CONNECTOR-COAXIA
3709-001880	CD4000	CONNECTOR-CARD
3709-001891	CD4001	CONNECTOR-CARD
3711-007107	HDC6002	CONNECTOR-HEADER
3711-007295	HDC6001	CONNECTOR-HEADER
3711-008511	HDC6000	CONNECTOR-HEADER
3711-009045	BTC4000	CONNECTOR-HEADER
3711-009357	HDC6003	CONNECTOR-HEADER
3712-001604	ANT6010,ANT6013	CONNECTOR
3712-001621	ANT6000,ANT6001	CONNECTOR
3712-001621	ANT6002,ANT6003	CONNECTOR
3712-001621	ANT6004,ANT6005	CONNECTOR
3712-001621	ANT6006,ANT6007	CONNECTOR
3712-001621	ANT6008,ANT6009	CONNECTOR
3712-001621	ANT6011,ANT6012	CONNECTOR
3712-001621	ANT6014	CONNECTOR
3712-001626	ANT5000,ANT5003	CONNECTOR
3712-001666	ANT1001,ANT1002	CONNECTOR
3712-001666	ANT2000,ANT2001	CONNECTOR
3712-001666	ANT2003,ANT2004	CONNECTOR
3712-001666	ANT5001,ANT5002	CONNECTOR
3712-001694	ANT4000,ANT4001	CONNECTOR
3712-001694	ANT4002,ANT4004	CONNECTOR
3712-001694	ANT4005,ANT4006	CONNECTOR
3712-001694	ANT4007,ANT4008	CONNECTOR
3722-003954	IFC4000	JACK-PHONE

5. MAIN Electrical Parts List

3722-004146	EAR5000	JACK-PHONE
4709-002412	CPL1000	RF-MODULE
GH61-13156A	SUS2001	SHIELD CAN
GH62-00042A	SMR6000	SHIELD CAN
GH63-09457A	SC2000	SHIELD CAN
GH63-13772A	SC2004	SHIELD CAN
GH63-15420A	SC2003	SHIELD CAN
GH63-15421A	SC2002	SHIELD CAN
GH63-16233A	SC2006	SHIELD CAN
GH63-16234A	SC2007	SHIELD CAN
GH63-16235A	SC2005	SHIELD CAN
GH02-16421A	SC2006SP	TAPE

5. MAIN Electrical Parts List

[SM-J610FN]

Parts Code	Design LOC	Description
0401-001110	ZD6000	DIODE-SWICHGING
0404-001250	D4001	DIODE-SCHOTTKY
0404-001646	D6004	DIODE-SCHOTTKY
0406-001561	D4015,D4016,D5000	DIODE-TVS
0406-001561	D5003	DIODE-TVS
0406-001592	D4012,D6011,D6013	DIODE-TVS
0406-001592	D6014,D6017	DIODE-TVS
0406-001659	D2000,D2001	DIODE-TVS
0406-001682	D5010	DIODE-TVS
0406-001709	D5013	DIODE-TVS
0406-001728	D4008	DIODE-TVS
0406-001743	D4002,D4003	DIODE-TVS
0406-001776	D4004,D4005,D4006	DIODE-TVS
0406-001776	D4007	DIODE-TVS
0406-001781	D5007,D5008	DIODE-TVS
0406-001789	D4013,D4014,D6012	DIODE-TVS
0406-001797	D4009,D4010	DIODE-TVS
0406-001807	D4000	DIODE-TVS
0406-001808	D4011	DIODE-TVS
0505-002088	TR4001,TR6000	FET-SILICON
0505-003618	TR4002	FET-SILICON
0601-003734	LED4001	LED
0601-003735	LED4000	LED
1001-001655	U4006	IC
1001-001968	U5000	IC
1001-001969	U2000	IC
1001-001970	U1004,U1007	IC
1001-002022	U2003	IC
1001-002046	U1001,U1002	IC
1108-000638	UME5000	MEMORY
1201-003786	U2006	IC
1201-003984	U1006	IC
1201-003985	U1100	IC
1201-004109	PAM1001	IC
1201-004209	PAM1000	IC
1203-008251	U6019	IC
1203-008379	U2002	IC

5. MAIN Electrical Parts List

1203-008468	U4007	IC
1203-008575	U6009	IC
1203-008603	U6014	IC
1203-008816	PM4000	IC
1203-008859	U6012	IC
1203-008865	U6001	IC
1203-008867	U2007,U6006,U6024	IC
1203-008870	U6005,U6007	IC
1203-008955	U6013	IC
1203-008995	U4004	IC
1205-005217	U6011	IC
1205-005493	U1016	IC
1205-005525	U2008	IC
1205-005979	U2009	IC
1205-006027	UCP3000	IC
1209-002413	U6015	IC
1209-002414	U6017	IC
1209-002450	U6016	IC
1404-001664	TH1000,TH3000,TH3001	THERMISTOR
1405-001404	VR6001	VARISTOR
2007-003015	R4025,R4026	R-CHIP
2007-003025	R5024,R5085	R-CHIP
2007-007142	R6005,R6011,R6012	R-CHIP
2007-007142	R6014	R-CHIP
2007-007315	R3000	R-CHIP
2007-007317	R3007,R3008	R-CHIP
2007-007741	R3034,R3035,R3037	R-CHIP
2007-007741	R3039,R4019,R5002	R-CHIP
2007-007741	R5023,R6002,R6004	R-CHIP
2007-007741	R6024	R-CHIP
2007-007798	R4027	R-CHIP
2007-008210	R1000,R4129	R-CHIP
2007-008304	R5011	R-CHIP
2007-008419	R4007,R4014	R-CHIP
2007-008531	R5008,R6000,R6001	R-CHIP
2007-008531	R6003	R-CHIP
2007-008579	R1013	R-CHIP
2007-008582	R1002,R1003	R-CHIP
2007-008588	R2002,R2003	R-CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2007-008788	R3027	R-CHIP
2007-008798	R4028,R4029	R-CHIP
2007-009111	R6006	R-CHIP
2007-009155	R5009	R-CHIP
2007-009157	R1009,R2005,R3029	R-CHIP
2007-009157	R3030,R4000,R4005	R-CHIP
2007-009157	R4016,R5016,R5026	R-CHIP
2007-009157	R5086	R-CHIP
2007-009158	R4006	R-CHIP
2007-009171	R4018	R-CHIP
2007-009212	R3032,R5006	R-CHIP
2007-009223	R5017	R-CHIP
2007-009314	R4022,R4023,R4024	R-CHIP
2007-009315	R4111,R4112,R4113	R-CHIP
2007-009315	R4114,R4115,R4116	R-CHIP
2007-009315	R4117,R4118,R4120	R-CHIP
2007-009315	R4121,R4122,R4123	R-CHIP
2007-009315	R4125,R4126,R4127	R-CHIP
2007-009408	R3015,R3016,R3017	R-CHIP
2007-009408	R3018,R3021,R3022	R-CHIP
2007-009408	R3023,R3024,R3025	R-CHIP
2007-009408	R3026	R-CHIP
2007-009793	R5019	R-CHIP
2007-009801	R4015,R5005,R5007	R-CHIP
2007-009801	R5018	R-CHIP
2007-009805	R1001,R1006,R1010	R-CHIP
2007-009805	R1024	R-CHIP
2007-009866	R5020	R-CHIP
2007-009920	R3002,R5012,R5013	R-CHIP
2007-009924	R5022	R-CHIP
2007-009969	R2011,R2016,R5010	R-CHIP
2007-010202	R5021	R-CHIP
2007-010685	R2004,R3001	R-CHIP
2007-011043	R3028	R-CHIP
2007-012068	R4021	R-CHIP
2203-000425	C6034	C-CERAMIC,CHIP
2203-001153	C2096	C-CERAMIC,CHIP
2203-001239	C2109,C2115,C6035	C-CERAMIC,CHIP
2203-002677	C2090	C-CERAMIC,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2203-005450	C2097	C-CERAMIC,CHIP
2203-005682	C1004,C1041,C1056	C-CERAMIC,CHIP
2203-005682	C1057,C1132,C1164	C-CERAMIC,CHIP
2203-005682	C1201,C1202,C2021	C-CERAMIC,CHIP
2203-005682	C2022,C2023,C2039	C-CERAMIC,CHIP
2203-005682	C2040,C5033,C6065	C-CERAMIC,CHIP
2203-005682	C6068,C6071,L2047	C-CERAMIC,CHIP
2203-005719	C6062	C-CERAMIC,CHIP
2203-005725	C1151,C1153,C1154	C-CERAMIC,CHIP
2203-005725	C1157,C1169,L1033	C-CERAMIC,CHIP
2203-005725	L1044	C-CERAMIC,CHIP
2203-005729	C1131,C5004,C5023	C-CERAMIC,CHIP
2203-005729	C5032,C5036,C5040	C-CERAMIC,CHIP
2203-005729	C6004,C6005	C-CERAMIC,CHIP
2203-005732	C5030,C5034,C5035	C-CERAMIC,CHIP
2203-005732	C5041	C-CERAMIC,CHIP
2203-005734	C1001,C1105,C2083	C-CERAMIC,CHIP
2203-005736	C1003,C1011,C1027	C-CERAMIC,CHIP
2203-005736	C1031,C1046,C1047	C-CERAMIC,CHIP
2203-005736	C1052,C1060,C1069	C-CERAMIC,CHIP
2203-005736	C1100,C1102,C1111	C-CERAMIC,CHIP
2203-005736	C1120,C1124,C1133	C-CERAMIC,CHIP
2203-005736	C1134,C1138,C1142	C-CERAMIC,CHIP
2203-005736	C1152,C1158,C1165	C-CERAMIC,CHIP
2203-005736	C1166,C1172,C1173	C-CERAMIC,CHIP
2203-005736	C1178,C1184,C1185	C-CERAMIC,CHIP
2203-005736	C1186,C1187,C2002	C-CERAMIC,CHIP
2203-005736	C2005,C2011,C2013	C-CERAMIC,CHIP
2203-005736	C2020,C2028,C2030	C-CERAMIC,CHIP
2203-005736	C2032,C2034,C2038	C-CERAMIC,CHIP
2203-005736	C2044,C2045,C2088	C-CERAMIC,CHIP
2203-005736	C2102,C2105,C6047	C-CERAMIC,CHIP
2203-005736	C6063,L1011,L1012	C-CERAMIC,CHIP
2203-005736	L1014,L1026,L1040	C-CERAMIC,CHIP
2203-005736	L1057,L1082,L1088	C-CERAMIC,CHIP
2203-005736	L1100,L1102,L2011	C-CERAMIC,CHIP
2203-005736	L2018,L2024,R1015	C-CERAMIC,CHIP
2203-005736	R1025	C-CERAMIC,CHIP
2203-005777	C1023,C1024,C1125	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-005777	C1129,C2087,L1002	C-CERAMIC,CHIP
2203-005777	L1062,L1070,L2034	C-CERAMIC,CHIP
2203-005777	L2042	C-CERAMIC,CHIP
2203-005789	C2001,C2006,C2007	C-CERAMIC,CHIP
2203-005789	C2010,C2093,L2026	C-CERAMIC,CHIP
2203-005792	L2035	C-CERAMIC,CHIP
2203-005806	C1163,C2018,C2026	C-CERAMIC,CHIP
2203-005806	C2054,C3073,C3074	C-CERAMIC,CHIP
2203-005806	C4000	C-CERAMIC,CHIP
2203-006121	C5026	C-CERAMIC,CHIP
2203-006194	C2100,C2101,C2106	C-CERAMIC,CHIP
2203-006194	C4093,C4095	C-CERAMIC,CHIP
2203-006305	C2046,L2031	C-CERAMIC,CHIP
2203-006318	C1022,C1050,C1122	C-CERAMIC,CHIP
2203-006318	C2089,L1029	C-CERAMIC,CHIP
2203-006399	C6042	C-CERAMIC,CHIP
2203-006400	C1107,C1130,C1200	C-CERAMIC,CHIP
2203-006400	C2095,C2116	C-CERAMIC,CHIP
2203-006410	C2092	C-CERAMIC,CHIP
2203-006423	C1025,C1045,C1139	C-CERAMIC,CHIP
2203-006423	C1145,C1146,C1147	C-CERAMIC,CHIP
2203-006423	C3000,C3001,C3002	C-CERAMIC,CHIP
2203-006423	C3010,C3011,C3012	C-CERAMIC,CHIP
2203-006423	C3016,C3017,C3018	C-CERAMIC,CHIP
2203-006423	C3019,C3020,C3021	C-CERAMIC,CHIP
2203-006423	C3022,C3029,C3030	C-CERAMIC,CHIP
2203-006423	C3031,C3032,C3033	C-CERAMIC,CHIP
2203-006423	C3034,C3035,C3036	C-CERAMIC,CHIP
2203-006423	C3037,C3038,C3039	C-CERAMIC,CHIP
2203-006423	C3040,C3041,C3042	C-CERAMIC,CHIP
2203-006423	C3043,C3044,C3045	C-CERAMIC,CHIP
2203-006423	C3046,C3047,C3048	C-CERAMIC,CHIP
2203-006423	C3052,C3054,C3055	C-CERAMIC,CHIP
2203-006423	C3056,C3057,C3058	C-CERAMIC,CHIP
2203-006423	C3070,C3071,C3072	C-CERAMIC,CHIP
2203-006423	C3076,C3077,C3078	C-CERAMIC,CHIP
2203-006423	C3080,C3081,C3082	C-CERAMIC,CHIP
2203-006423	C3083,C3084,C3085	C-CERAMIC,CHIP
2203-006423	C3086,C4005,C4016	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-006423	C4022,C4024,C4056	C-CERAMIC,CHIP
2203-006423	C4075,C5010,C5013	C-CERAMIC,CHIP
2203-006423	C5019,C5022,C5025	C-CERAMIC,CHIP
2203-006423	C6057,C6058	C-CERAMIC,CHIP
2203-006556	C5027	C-CERAMIC,CHIP
2203-006604	C1064,C4082,C4083	C-CERAMIC,CHIP
2203-006604	C4084,C4085,L1045	C-CERAMIC,CHIP
2203-006648	C2110	C-CERAMIC,CHIP
2203-006665	L1061	C-CERAMIC,CHIP
2203-006707	C2061	C-CERAMIC,CHIP
2203-006839	C2076,C2082,C3068	C-CERAMIC,CHIP
2203-006839	C3069,C4029,C6026	C-CERAMIC,CHIP
2203-006839	C6032,C6066	C-CERAMIC,CHIP
2203-006846	C1035,C1075	C-CERAMIC,CHIP
2203-006872	C2070,C2072	C-CERAMIC,CHIP
2203-006896	C1159,C5020,C5021	C-CERAMIC,CHIP
2203-006968	L2049	C-CERAMIC,CHIP
2203-006979	C1136,C1148,C1167	C-CERAMIC,CHIP
2203-006979	U1012	C-CERAMIC,CHIP
2203-007194	C2117,C6045,L1024	C-CERAMIC,CHIP
2203-007210	C3064,C4077,C5005	C-CERAMIC,CHIP
2203-007210	C5008,C5009,C5015	C-CERAMIC,CHIP
2203-007210	C5017	C-CERAMIC,CHIP
2203-007271	C4060,C4076	C-CERAMIC,CHIP
2203-007295	C2091	C-CERAMIC,CHIP
2203-007317	C4080,C6007,C6009	C-CERAMIC,CHIP
2203-007317	C6038,C6056	C-CERAMIC,CHIP
2203-007391	C1144,C2075,C2099	C-CERAMIC,CHIP
2203-007391	C4094,C4096,C5011	C-CERAMIC,CHIP
2203-007393	C2008,C2015,C2081	C-CERAMIC,CHIP
2203-007393	C2107,C3004,C3023	C-CERAMIC,CHIP
2203-007393	C3062,C3092,C4008	C-CERAMIC,CHIP
2203-007393	C4010,C4012,C4020	C-CERAMIC,CHIP
2203-007393	C4025,C4026,C4027	C-CERAMIC,CHIP
2203-007393	C4028,C4045,C5016	C-CERAMIC,CHIP
2203-007393	C5018	C-CERAMIC,CHIP
2203-007775	C2078	C-CERAMIC,CHIP
2203-007781	C3094,C3097,C3098	C-CERAMIC,CHIP
2203-007781	C3099,C3100,C3101	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-007781	C3102,C3103,C4030	C-CERAMIC,CHIP
2203-007781	C4031,C4053,C4054	C-CERAMIC,CHIP
2203-007781	C4055,C4057,C4098	C-CERAMIC,CHIP
2203-007796	C2068,C2077,C2103	C-CERAMIC,CHIP
2203-007796	C3005,C3024,C3025	C-CERAMIC,CHIP
2203-007796	C3026,C3050,C3051	C-CERAMIC,CHIP
2203-007796	C3053,C3060,C3061	C-CERAMIC,CHIP
2203-007796	C3065,C3090,C3091	C-CERAMIC,CHIP
2203-007796	C4004,C4006,C4007	C-CERAMIC,CHIP
2203-007796	C4009,C4011,C4013	C-CERAMIC,CHIP
2203-007796	C4014,C4019,C4023	C-CERAMIC,CHIP
2203-007796	C4050,C4062,C5001	C-CERAMIC,CHIP
2203-007796	C5002,C5003,C5006	C-CERAMIC,CHIP
2203-007796	C5007,C5014,C6006	C-CERAMIC,CHIP
2203-007796	C6012,C6018,C6020	C-CERAMIC,CHIP
2203-007796	C6029,C6030,C6041	C-CERAMIC,CHIP
2203-007796	C6049,C6051,C6059	C-CERAMIC,CHIP
2203-007796	C6060,C6073,C6078	C-CERAMIC,CHIP
2203-008094	C4073	C-CERAMIC,CHIP
2203-008097	C1033	C-CERAMIC,CHIP
2203-008572	C4035,C4038	C-CERAMIC,CHIP
2203-008654	C4091	C-CERAMIC,CHIP
2203-008749	C6036	C-CERAMIC,CHIP
2203-008860	C1141,C1149,C3066	C-CERAMIC,CHIP
2203-008860	C4033,C4037,C4049	C-CERAMIC,CHIP
2203-008860	C4051,C4069,C4071	C-CERAMIC,CHIP
2203-008860	C4079,C6016,C6019	C-CERAMIC,CHIP
2203-008860	C6021,C6027,C6040	C-CERAMIC,CHIP
2203-008860	C6053,C6070,C6072	C-CERAMIC,CHIP
2203-008876	C1026,C1032,C1135	C-CERAMIC,CHIP
2203-008876	C1140,C2079,C2080	C-CERAMIC,CHIP
2203-008876	C3049,C4002,C4003	C-CERAMIC,CHIP
2203-008876	C4034,C4036,C4039	C-CERAMIC,CHIP
2203-008876	C4040,C4043,C4044	C-CERAMIC,CHIP
2203-008876	C4046,C4047,C5000	C-CERAMIC,CHIP
2203-008876	C6031,C6061,C6064	C-CERAMIC,CHIP
2203-008876	C6067	C-CERAMIC,CHIP
2203-009167	C2094,C2108	C-CERAMIC,CHIP
2203-009733	C1034,C2012,C2073	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-009733	C2074,C2104,C4048	C-CERAMIC,CHIP
2203-009733	C4059,C4089,C6014	C-CERAMIC,CHIP
2203-009733	C6015,C6033,C6037	C-CERAMIC,CHIP
2203-009733	C6039,C6043,C6046	C-CERAMIC,CHIP
2203-009733	C6048,C6074	C-CERAMIC,CHIP
2203-009736	C6010	C-CERAMIC,CHIP
2203-010085	C4058,C4063	C-CERAMIC,CHIP
2703-002268	L2052	INDUCTOR-SMD
2703-002308	L5015	INDUCTOR-SMD
2703-002901	C1007,L1034,L2022	INDUCTOR-SMD
2703-002903	C1036,C1065,C1089	INDUCTOR-SMD
2703-002903	L1036,L1103	INDUCTOR-SMD
2703-002907	L1066	INDUCTOR-SMD
2703-002951	L1041,L4009,L4011	INDUCTOR-SMD
2703-002955	C1021,L1084,L1085	INDUCTOR-SMD
2703-002955	L1086,L1087,L4010	INDUCTOR-SMD
2703-002955	L4012	INDUCTOR-SMD
2703-002958	L1003	INDUCTOR-SMD
2703-002959	L2005,L2008,L2012	INDUCTOR-SMD
2703-002959	L2048,L2057	INDUCTOR-SMD
2703-002999	C1104,C1150	INDUCTOR-SMD
2703-003878	L5008	INDUCTOR-SMD
2703-003970	L1009	INDUCTOR-SMD
2703-004000	L1090	INDUCTOR-SMD
2703-004012	C1055,C1070,C2056	INDUCTOR-SMD
2703-004012	C2057,L1018,L2000	INDUCTOR-SMD
2703-004013	C1028,C1044,C1118	INDUCTOR-SMD
2703-004013	C1143,C2029,L1031	INDUCTOR-SMD
2703-004013	L1068,L1073	INDUCTOR-SMD
2703-004014	L1055,L1104,L2039	INDUCTOR-SMD
2703-004014	L2054	INDUCTOR-SMD
2703-004018	L1027,L1056	INDUCTOR-SMD
2703-004034	C1005,C1121,C2003	INDUCTOR-SMD
2703-004034	L1010,L1054,L2037	INDUCTOR-SMD
2703-004036	C2059,L1023	INDUCTOR-SMD
2703-004193	L5017,L5018	INDUCTOR-SMD
2703-004286	C2024,C2031,C2058	INDUCTOR-SMD
2703-004286	L1022,L1025,L1079	INDUCTOR-SMD
2703-004286	L1089,L2029,L2032	INDUCTOR-SMD

5. MAIN Electrical Parts List

2703-004286	L2038	INDUCTOR-SMD
2703-004288	C1103,L1028,L2002	INDUCTOR-SMD
2703-004288	L2044	INDUCTOR-SMD
2703-004289	C2047,L1072,L2033	INDUCTOR-SMD
2703-004300	L1004,L1007,L1078	INDUCTOR-SMD
2703-004300	L2001	INDUCTOR-SMD
2703-004301	L1064	INDUCTOR-SMD
2703-004317	C1019,C1038,C1101	INDUCTOR-SMD
2703-004317	L1000,L1008,L1021	INDUCTOR-SMD
2703-004317	L1058	INDUCTOR-SMD
2703-004328	L1059,L2007,L2061	INDUCTOR-SMD
2703-004328	L2062	INDUCTOR-SMD
2703-004362	L2059	INDUCTOR-SMD
2703-004363	C2052	INDUCTOR-SMD
2703-004366	L2043	INDUCTOR-SMD
2703-004367	L2046	INDUCTOR-SMD
2703-004368	C1116	INDUCTOR-SMD
2703-004684	L3000	INDUCTOR-SMD
2703-004763	C1048	INDUCTOR-SMD
2703-004862	C1018,L1060,L2045	INDUCTOR-SMD
2703-004947	L4003,L4005	INDUCTOR-SMD
2703-004976	C2120	INDUCTOR-SMD
2703-005067	L4007,L4008	INDUCTOR-SMD
2703-005085	C1017,C2055	INDUCTOR-SMD
2703-005087	C1113,C1171,C2037	INDUCTOR-SMD
2703-005087	C2041,L2019	INDUCTOR-SMD
2703-005088	C1051,C2033	INDUCTOR-SMD
2703-005101	L2015	INDUCTOR-SMD
2703-005109	L4002	INDUCTOR-SMD
2703-005116	L6005	INDUCTOR-SMD
2703-005118	L6003	INDUCTOR-SMD
2703-005224	L4006	INDUCTOR-SMD
2703-005339	L4013,L4014	INDUCTOR-SMD
2703-005555	L2056,L2060	INDUCTOR-SMD
2801-005300	OSC4000	CRYSTAL-UNIT
2904-002137	F1100	FILTER-SAW
2904-002143	F1001	FILTER-SAW
2904-002198	F2004	FILTER-SAW
2904-002339	F2000	FILTER-SAW

5. MAIN Electrical Parts List

2904-002350	F1005	FILTER-SAW
2904-002355	F2002	FILTER-SAW
2904-002381	F2006	FILTER-SAW
2904-002394	F2003	FILTER-SAW
2904-002397	F1004	FILTER-SAW
2910-000401	F1006	FILTER
2911-000435	U2005	FILTER
2911-000450	U1003	FILTER
3003-001215	MIC5000	MIC-CONDENSOR
3301-001812	L6004	CORE-FERRITE BEAD
3301-001885	L5016	CORE-FERRITE BEAD
3301-001901	L6002	CORE-FERRITE BEAD
3301-002078	L5013,L5014	CORE-FERRITE BEAD
3301-002122	L5019,L5020	CORE-FERRITE BEAD
3301-002223	L6001,L6010	CORE-FERRITE BEAD
3301-002236	L2016,L2023,L5005	CORE-FERRITE BEAD
3301-002236	L5007,L5009,L5011	CORE-FERRITE BEAD
3301-002236	L5012	CORE-FERRITE BEAD
3301-002237	L1001,L1017,L5000	CORE-FERRITE BEAD
3301-002237	L5001,L6006,L6007	CORE-FERRITE BEAD
3301-002238	L2006	CORE-FERRITE BEAD
3301-002248	L2053,L2063	CORE-FERRITE BEAD
3301-002254	L4000	CORE-FERRITE BEAD
3301-002286	L5010	CORE-FERRITE BEAD
3301-002309	L2041,L5004	CORE-FERRITE BEAD
3301-002312	L4004	CORE-FERRITE BEAD
3705-001708	RFS1000	CONNECTOR-COAXIAL
3709-001880	CD4000	CONNECTOR-CARD EDGE
3709-001891	CD4001	CONNECTOR-CARD EDGE
3711-007107	HDC6002	CONNECTOR-HEADER
3711-007295	HDC6001	CONNECTOR-HEADER
3711-008511	HDC6000	CONNECTOR-HEADER
3711-009045	BTC4000	CONNECTOR-HEADER
3711-009357	HDC6003	CONNECTOR-HEADER
3712-001604	ANT2005,ANT2006	CONNECTOR
3712-001604	ANT6010,ANT6013	CONNECTOR
3712-001621	ANT6000,ANT6001	CONNECTOR
3712-001621	ANT6002,ANT6003	CONNECTOR
3712-001621	ANT6004,ANT6005	CONNECTOR

5. MAIN Electrical Parts List

3712-001621	ANT6006,ANT6007	CONNECTOR
3712-001621	ANT6008,ANT6009	CONNECTOR
3712-001621	ANT6011,ANT6012	CONNECTOR
3712-001621	ANT6014	CONNECTOR
3712-001626	ANT5000,ANT5003	CONNECTOR
3712-001666	ANT1001,ANT1002	CONNECTOR
3712-001666	ANT2000,ANT2001	CONNECTOR
3712-001666	ANT2003,ANT2004	CONNECTOR
3712-001666	ANT5001,ANT5002	CONNECTOR
3712-001694	ANT4000,ANT4001	CONNECTOR
3712-001694	ANT4002,ANT4004	CONNECTOR
3712-001694	ANT4005,ANT4006	CONNECTOR
3712-001694	ANT4007,ANT4008	CONNECTOR
3722-003954	IFC4000	JACK-PHONE
3722-004146	EAR5000	JACK-PHONE
4709-002412	CPL1000	RF-MODULE
GH61-13156A	SUS2001	SUS
GH62-00042A	SMR6000	SUS
GH63-09457A	SC2000	SHIELD CAN
GH63-13772A	SC2004	SHIELD CAN
GH63-15420A	SC2003	SHIELD CAN
GH63-15421A	SC2002	SHIELD CAN
GH63-16233A	SC2006	SHIELD CAN
GH63-16234A	SC2007	SHIELD CAN
GH63-16235A	SC2005	SHIELD CAN
GH02-16421A	SC2006SP	SHIELD CAN

5. MAIN Electrical Parts List

[SM-J610G]

Parts Code	Design LOC	Description
0401-001110	ZD6000	DIODE-SWICHGING
0404-001250	D4001	DIODE-SCHOTTKY
0404-001646	D6004	DIODE-SCHOTTKY
0406-001561	D4015,D4016,D5000	DIODE-TVS
0406-001561	D5003	DIODE-TVS
0406-001592	D4012,D6011,D6013	DIODE-TVS
0406-001592	D6014,D6017	DIODE-TVS
0406-001682	D5010	DIODE-TVS
0406-001709	D5013	DIODE-TVS
0406-001728	D4008	DIODE-TVS
0406-001743	D4002,D4003	DIODE-TVS
0406-001776	D4004,D4005,D4006	DIODE-TVS
0406-001776	D4007	DIODE-TVS
0406-001781	D5007,D5008	DIODE-TVS
0406-001789	D4013,D4014,D6012	DIODE-TVS
0406-001797	D4009,D4010	DIODE-TVS
0406-001807	D4000	DIODE-TVS
0406-001808	D4011	DIODE-TVS
0505-002088	TR4001,TR6000	FET-SILICON
0505-003618	TR4002	FET-SILICON
0601-003734	LED4001	LED
0601-003735	LED4000	LED
1001-001655	U4006	IC
1001-001844	U1008	IC
1001-001968	U5000	IC
1001-001969	U2000	IC
1001-001970	U1004,U1007,U1010	IC
1001-001970	U1013	IC
1001-001999	U1011	IC
1001-002022	U2003	IC
1001-002046	U1001,U1002	IC
1108-000638	UME5000	MEMORY
1201-003786	U2006	IC
1201-003984	U1006	IC
1201-003985	U1100	IC
1201-004109	PAM1001	IC
1201-004209	PAM1000	IC

5. MAIN Electrical Parts List

1203-008251	U6019	IC
1203-008379	U2002	IC
1203-008468	U4007	IC
1203-008575	U6009	IC
1203-008603	U6014	IC
1203-008816	PM4000	IC
1203-008859	U6012	IC
1203-008865	U6001	IC
1203-008867	U6006,U6024	IC
1203-008870	U6005,U6007	IC
1203-008955	U6013	IC
1203-008995	U4004	IC
1205-005217	U6011	IC
1205-005493	U1016	IC
1205-005525	U2008	IC
1205-006027	UCP3000	IC
1209-002413	U6015	IC
1209-002414	U6017	IC
1209-002450	U6016	IC
1404-001664	TH1000,TH3000,TH3001	THERMISTOR
1405-001404	VR6001	VARISTOR
2007-003015	R4025,R4026	R-CHIP
2007-003025	R5024,R5085	R-CHIP
2007-007142	R6005,R6011,R6012	R-CHIP
2007-007142	R6014	R-CHIP
2007-007315	R3000	R-CHIP
2007-007317	R3007,R3008	R-CHIP
2007-007741	R3034,R3035,R3037	R-CHIP
2007-007741	R3039,R4019,R5002	R-CHIP
2007-007741	R5023,R6002,R6004	R-CHIP
2007-007741	R6024	R-CHIP
2007-007798	R4027	R-CHIP
2007-008210	R1000,R4129	R-CHIP
2007-008304	R5011	R-CHIP
2007-008419	R4007,R4014	R-CHIP
2007-008531	R5008,R6000,R6001	R-CHIP
2007-008531	R6003	R-CHIP
2007-008579	R1013	R-CHIP
2007-008582	R1002,R1003	R-CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2007-008788	R3027	R-CHIP
2007-008798	R4028,R4029	R-CHIP
2007-009111	R6006	R-CHIP
2007-009155	R5009	R-CHIP
2007-009157	R1009,R2009,R3029	R-CHIP
2007-009157	R3030,R4000,R4005	R-CHIP
2007-009157	R4016,R5016,R5026	R-CHIP
2007-009157	R5086	R-CHIP
2007-009158	R4006	R-CHIP
2007-009171	R4018	R-CHIP
2007-009212	R3032,R5006	R-CHIP
2007-009223	R5017	R-CHIP
2007-009314	R4022,R4023,R4024	R-CHIP
2007-009315	R4111,R4112,R4113	R-CHIP
2007-009315	R4114,R4115,R4116	R-CHIP
2007-009315	R4117,R4118,R4120	R-CHIP
2007-009315	R4121,R4122,R4123	R-CHIP
2007-009315	R4125,R4126,R4127	R-CHIP
2007-009408	R3015,R3016,R3017	R-CHIP
2007-009408	R3018,R3021,R3022	R-CHIP
2007-009408	R3023,R3024,R3025	R-CHIP
2007-009408	R3026	R-CHIP
2007-009793	R5019	R-CHIP
2007-009801	R4015,R5005,R5007	R-CHIP
2007-009801	R5018	R-CHIP
2007-009805	R1001,R1006,R1010	R-CHIP
2007-009805	R1024	R-CHIP
2007-009866	R5020	R-CHIP
2007-009920	R3002,R5012,R5013	R-CHIP
2007-009924	R5022	R-CHIP
2007-009969	R5010	R-CHIP
2007-010202	R5021	R-CHIP
2007-010685	R3001	R-CHIP
2007-011043	R3028	R-CHIP
2007-012068	R4021	R-CHIP
2203-000425	C6034	C-CERAMIC,CHIP
2203-001239	C6035	C-CERAMIC,CHIP
2203-002677	C2090	C-CERAMIC,CHIP
2203-005682	C1004,C1041,C1056	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-005682	C1057,C1110,C1132	C-CERAMIC,CHIP
2203-005682	C1164,C1201,C1202	C-CERAMIC,CHIP
2203-005682	C2021,C2022,C2023	C-CERAMIC,CHIP
2203-005682	C2039,C2040,C5033	C-CERAMIC,CHIP
2203-005682	C6065,C6068,C6071	C-CERAMIC,CHIP
2203-005682	L2047	C-CERAMIC,CHIP
2203-005719	C6062	C-CERAMIC,CHIP
2203-005725	C1151,C1153,C1154	C-CERAMIC,CHIP
2203-005725	C1157,C1169,L1033	C-CERAMIC,CHIP
2203-005725	L1044	C-CERAMIC,CHIP
2203-005729	C1131,C5004,C5023	C-CERAMIC,CHIP
2203-005729	C5032,C5036,C5040	C-CERAMIC,CHIP
2203-005729	C6004,C6005	C-CERAMIC,CHIP
2203-005732	C5030,C5034,C5035	C-CERAMIC,CHIP
2203-005732	C5041	C-CERAMIC,CHIP
2203-005734	C1001,C1105,C2083	C-CERAMIC,CHIP
2203-005736	C1003,C1011,C1027	C-CERAMIC,CHIP
2203-005736	C1031,C1046,C1047	C-CERAMIC,CHIP
2203-005736	C1052,C1060,C1069	C-CERAMIC,CHIP
2203-005736	C1085,C1100,C1102	C-CERAMIC,CHIP
2203-005736	C1111,C1120,C1124	C-CERAMIC,CHIP
2203-005736	C1137,C1138,C1142	C-CERAMIC,CHIP
2203-005736	C1152,C1158,C1172	C-CERAMIC,CHIP
2203-005736	C1173,C1178,C1184	C-CERAMIC,CHIP
2203-005736	C1187,C2002,C2005	C-CERAMIC,CHIP
2203-005736	C2011,C2013,C2020	C-CERAMIC,CHIP
2203-005736	C2028,C2030,C2032	C-CERAMIC,CHIP
2203-005736	C2034,C2038,C2044	C-CERAMIC,CHIP
2203-005736	C2045,C2062,C2064	C-CERAMIC,CHIP
2203-005736	C2065,C2088,C2102	C-CERAMIC,CHIP
2203-005736	C2105,C6047,C6063	C-CERAMIC,CHIP
2203-005736	L1011,L1012,L1014	C-CERAMIC,CHIP
2203-005736	L1026,L1040,L1057	C-CERAMIC,CHIP
2203-005736	L1082,L1088,L1100	C-CERAMIC,CHIP
2203-005736	L1102,L2011,L2018	C-CERAMIC,CHIP
2203-005736	L2024,R1015,R1025	C-CERAMIC,CHIP
2203-005777	C1023,C1024,C1092	C-CERAMIC,CHIP
2203-005777	C1125,C1129,C2087	C-CERAMIC,CHIP
2203-005777	L1002,L1062,L1070	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-005777	L2034,L2042	C-CERAMIC,CHIP
2203-005789	C1053,C1099,C2001	C-CERAMIC,CHIP
2203-005789	C2006,C2007,C2010	C-CERAMIC,CHIP
2203-005789	C2093,L2026	C-CERAMIC,CHIP
2203-005792	C1084,L2035	C-CERAMIC,CHIP
2203-005806	C1163,C2018,C2026	C-CERAMIC,CHIP
2203-005806	C2054,C3073,C3074	C-CERAMIC,CHIP
2203-005806	C4000	C-CERAMIC,CHIP
2203-006121	C5026	C-CERAMIC,CHIP
2203-006194	C2100,C2101,C2106	C-CERAMIC,CHIP
2203-006194	C4093,C4095	C-CERAMIC,CHIP
2203-006305	C2046,L2031	C-CERAMIC,CHIP
2203-006318	C1022,C1042,C1043	C-CERAMIC,CHIP
2203-006318	C1050,C1122,C2089	C-CERAMIC,CHIP
2203-006318	L1029	C-CERAMIC,CHIP
2203-006399	C6042	C-CERAMIC,CHIP
2203-006400	C1107,C1114,C1130	C-CERAMIC,CHIP
2203-006400	C1200	C-CERAMIC,CHIP
2203-006410	C1078,C2092	C-CERAMIC,CHIP
2203-006423	C1025,C1045,C1139	C-CERAMIC,CHIP
2203-006423	C1145,C1146,C1147	C-CERAMIC,CHIP
2203-006423	C3000,C3001,C3002	C-CERAMIC,CHIP
2203-006423	C3010,C3011,C3012	C-CERAMIC,CHIP
2203-006423	C3016,C3017,C3018	C-CERAMIC,CHIP
2203-006423	C3019,C3020,C3021	C-CERAMIC,CHIP
2203-006423	C3022,C3029,C3030	C-CERAMIC,CHIP
2203-006423	C3031,C3032,C3033	C-CERAMIC,CHIP
2203-006423	C3034,C3035,C3036	C-CERAMIC,CHIP
2203-006423	C3037,C3038,C3039	C-CERAMIC,CHIP
2203-006423	C3040,C3041,C3042	C-CERAMIC,CHIP
2203-006423	C3043,C3044,C3045	C-CERAMIC,CHIP
2203-006423	C3046,C3047,C3048	C-CERAMIC,CHIP
2203-006423	C3052,C3054,C3055	C-CERAMIC,CHIP
2203-006423	C3056,C3057,C3058	C-CERAMIC,CHIP
2203-006423	C3070,C3071,C3072	C-CERAMIC,CHIP
2203-006423	C3076,C3077,C3078	C-CERAMIC,CHIP
2203-006423	C3080,C3081,C3082	C-CERAMIC,CHIP
2203-006423	C3083,C3084,C3085	C-CERAMIC,CHIP
2203-006423	C3086,C4005,C4016	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-006423	C4022,C4024,C4056	C-CERAMIC,CHIP
2203-006423	C4075,C5010,C5013	C-CERAMIC,CHIP
2203-006423	C5019,C5022,C5025	C-CERAMIC,CHIP
2203-006423	C6057,C6058	C-CERAMIC,CHIP
2203-006556	C5027	C-CERAMIC,CHIP
2203-006604	C1064,C4082,C4083	C-CERAMIC,CHIP
2203-006604	C4084,C4085,L1045	C-CERAMIC,CHIP
2203-006611	C1083	C-CERAMIC,CHIP
2203-006648	C2110	C-CERAMIC,CHIP
2203-006665	L1061	C-CERAMIC,CHIP
2203-006707	C2061	C-CERAMIC,CHIP
2203-006839	C3068,C3069,C4029	C-CERAMIC,CHIP
2203-006839	C6026,C6032,C6066	C-CERAMIC,CHIP
2203-006846	C1035,C1075	C-CERAMIC,CHIP
2203-006896	C1159,C5020,C5021	C-CERAMIC,CHIP
2203-006968	L2049	C-CERAMIC,CHIP
2203-006979	C1136,C1148,C1167	C-CERAMIC,CHIP
2203-006979	U1012	C-CERAMIC,CHIP
2203-007194	C2117,C6045,L1024	C-CERAMIC,CHIP
2203-007210	C3064,C4077,C5005	C-CERAMIC,CHIP
2203-007210	C5008,C5009,C5015	C-CERAMIC,CHIP
2203-007210	C5017	C-CERAMIC,CHIP
2203-007271	C4060,C4076	C-CERAMIC,CHIP
2203-007295	C2091	C-CERAMIC,CHIP
2203-007317	C4080,C6007,C6009	C-CERAMIC,CHIP
2203-007317	C6038,C6056	C-CERAMIC,CHIP
2203-007391	C1144,C2099,C4094	C-CERAMIC,CHIP
2203-007391	C4096,C5011	C-CERAMIC,CHIP
2203-007393	C2008,C2015,C2107	C-CERAMIC,CHIP
2203-007393	C3004,C3023,C3062	C-CERAMIC,CHIP
2203-007393	C3092,C4008,C4010	C-CERAMIC,CHIP
2203-007393	C4012,C4020,C4025	C-CERAMIC,CHIP
2203-007393	C4026,C4027,C4028	C-CERAMIC,CHIP
2203-007393	C4045,C5016,C5018	C-CERAMIC,CHIP
2203-007781	C3094,C3097,C3098	C-CERAMIC,CHIP
2203-007781	C3099,C3100,C3101	C-CERAMIC,CHIP
2203-007781	C3102,C3103,C4030	C-CERAMIC,CHIP
2203-007781	C4031,C4053,C4054	C-CERAMIC,CHIP
2203-007781	C4055,C4057,C4098	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-007796	C2103,C3005,C3024	C-CERAMIC,CHIP
2203-007796	C3025,C3026,C3050	C-CERAMIC,CHIP
2203-007796	C3051,C3053,C3060	C-CERAMIC,CHIP
2203-007796	C3061,C3065,C3090	C-CERAMIC,CHIP
2203-007796	C3091,C4004,C4006	C-CERAMIC,CHIP
2203-007796	C4007,C4009,C4011	C-CERAMIC,CHIP
2203-007796	C4013,C4014,C4019	C-CERAMIC,CHIP
2203-007796	C4023,C4050,C4062	C-CERAMIC,CHIP
2203-007796	C5001,C5002,C5003	C-CERAMIC,CHIP
2203-007796	C5006,C5007,C5014	C-CERAMIC,CHIP
2203-007796	C6006,C6012,C6018	C-CERAMIC,CHIP
2203-007796	C6020,C6029,C6030	C-CERAMIC,CHIP
2203-007796	C6041,C6049,C6051	C-CERAMIC,CHIP
2203-007796	C6059,C6060,C6073	C-CERAMIC,CHIP
2203-007796	C6078	C-CERAMIC,CHIP
2203-008094	C4073	C-CERAMIC,CHIP
2203-008097	C1033	C-CERAMIC,CHIP
2203-008572	C4035,C4038	C-CERAMIC,CHIP
2203-008654	C4091	C-CERAMIC,CHIP
2203-008749	C6036	C-CERAMIC,CHIP
2203-008860	C1141,C1149,C3066	C-CERAMIC,CHIP
2203-008860	C4033,C4037,C4049	C-CERAMIC,CHIP
2203-008860	C4051,C4069,C4071	C-CERAMIC,CHIP
2203-008860	C4079,C6016,C6019	C-CERAMIC,CHIP
2203-008860	C6021,C6027,C6040	C-CERAMIC,CHIP
2203-008860	C6053,C6070,C6072	C-CERAMIC,CHIP
2203-008876	C1026,C1032,C1135	C-CERAMIC,CHIP
2203-008876	C1140,C3049,C4002	C-CERAMIC,CHIP
2203-008876	C4003,C4034,C4036	C-CERAMIC,CHIP
2203-008876	C4039,C4040,C4043	C-CERAMIC,CHIP
2203-008876	C4044,C4046,C4047	C-CERAMIC,CHIP
2203-008876	C5000,C6031,C6061	C-CERAMIC,CHIP
2203-008876	C6064,C6067	C-CERAMIC,CHIP
2203-009733	C1034,C2012,C2073	C-CERAMIC,CHIP
2203-009733	C2074,C2104,C4048	C-CERAMIC,CHIP
2203-009733	C4059,C4089,C6014	C-CERAMIC,CHIP
2203-009733	C6015,C6033,C6037	C-CERAMIC,CHIP
2203-009733	C6039,C6043,C6046	C-CERAMIC,CHIP
2203-009733	C6048,C6074	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-009736	C6010	C-CERAMIC,CHIP
2203-010085	C4058,C4063	C-CERAMIC,CHIP
2703-002268	L2052	INDUCTOR-SMD
2703-002308	L5015	INDUCTOR-SMD
2703-002649	L1030,L1039	INDUCTOR-SMD
2703-002901	C1007,L1034,L2022	INDUCTOR-SMD
2703-002903	C1036,C1065,C1089	INDUCTOR-SMD
2703-002903	L1036,L1047,L1103	INDUCTOR-SMD
2703-002907	C2067,L1066	INDUCTOR-SMD
2703-002951	L1041,L4009,L4011	INDUCTOR-SMD
2703-002955	C1021,L1084,L1085	INDUCTOR-SMD
2703-002955	L1086,L1087,L4010	INDUCTOR-SMD
2703-002955	L4012	INDUCTOR-SMD
2703-002958	L1003	INDUCTOR-SMD
2703-002959	L2005,L2008,L2012	INDUCTOR-SMD
2703-002959	L2048,L2057	INDUCTOR-SMD
2703-002999	C1104,C1150,L1063	INDUCTOR-SMD
2703-003004	C1054	INDUCTOR-SMD
2703-003878	L5008	INDUCTOR-SMD
2703-003970	C1079,L1009,L1042	INDUCTOR-SMD
2703-003970	L1049	INDUCTOR-SMD
2703-004000	L1090	INDUCTOR-SMD
2703-004012	C1055,C1070,C2056	INDUCTOR-SMD
2703-004012	C2057,C2063,L1018	INDUCTOR-SMD
2703-004012	L2000	INDUCTOR-SMD
2703-004013	C1028,C1044,C1058	INDUCTOR-SMD
2703-004013	C1059,C1094,C1118	INDUCTOR-SMD
2703-004013	C1143,C2029,L1031	INDUCTOR-SMD
2703-004013	L1068,L1073	INDUCTOR-SMD
2703-004014	L1043,L1055,L1104	INDUCTOR-SMD
2703-004014	L2039,L2054	INDUCTOR-SMD
2703-004018	L1027,L1056,L1069	INDUCTOR-SMD
2703-004034	C1005,C1097,C1109	INDUCTOR-SMD
2703-004034	C1121,C2003,L1010	INDUCTOR-SMD
2703-004034	L1054,L2037	INDUCTOR-SMD
2703-004036	C2059,L1023	INDUCTOR-SMD
2703-004193	L5017,L5018	INDUCTOR-SMD
2703-004286	C2024,C2031,C2058	INDUCTOR-SMD
2703-004286	L1019,L1022,L1025	INDUCTOR-SMD

5. MAIN Electrical Parts List

2703-004286	L1051,L1053,L1079	INDUCTOR-SMD
2703-004286	L1089,L2029,L2032	INDUCTOR-SMD
2703-004286	L2038	INDUCTOR-SMD
2703-004288	C1103,L1028,L2002	INDUCTOR-SMD
2703-004288	L2044	INDUCTOR-SMD
2703-004289	C2047,L1072,L2033	INDUCTOR-SMD
2703-004300	C1086,L1004,L1007	INDUCTOR-SMD
2703-004300	L1078,L2001	INDUCTOR-SMD
2703-004301	L1064	INDUCTOR-SMD
2703-004317	C1019,C1038,C1080	INDUCTOR-SMD
2703-004317	C1101,C1119,L1000	INDUCTOR-SMD
2703-004317	L1008,L1020,L1021	INDUCTOR-SMD
2703-004317	L1058	INDUCTOR-SMD
2703-004328	L1059,L2007,L2061	INDUCTOR-SMD
2703-004328	L2062	INDUCTOR-SMD
2703-004362	C2066,L2059	INDUCTOR-SMD
2703-004363	C2052	INDUCTOR-SMD
2703-004366	L2043	INDUCTOR-SMD
2703-004367	L2046	INDUCTOR-SMD
2703-004368	C1116	INDUCTOR-SMD
2703-004684	L3000	INDUCTOR-SMD
2703-004763	C1048	INDUCTOR-SMD
2703-004862	C1018,L1060,L2045	INDUCTOR-SMD
2703-004947	L4003,L4005	INDUCTOR-SMD
2703-004976	C2120	INDUCTOR-SMD
2703-005067	L4007,L4008	INDUCTOR-SMD
2703-005085	C1017,C2055	INDUCTOR-SMD
2703-005087	C1113,C1171,C2037	INDUCTOR-SMD
2703-005087	C2041,L1048,L2019	INDUCTOR-SMD
2703-005088	C1051,C2033	INDUCTOR-SMD
2703-005101	L2015	INDUCTOR-SMD
2703-005109	L4002	INDUCTOR-SMD
2703-005116	L6005	INDUCTOR-SMD
2703-005118	L6003	INDUCTOR-SMD
2703-005224	L4006	CRYSTAL-UNIT
2703-005339	L4013,L4014	FILTER-SAW
2801-005300	OSC4000	CRYSTAL-UNIT
2904-002137	F1100	FILTER-SAW
2904-002143	F1001	FILTER-SAW

5. MAIN Electrical Parts List

2904-002198	F2004	FILTER-SAW
2904-002326	F2005	FILTER-SAW
2904-002339	F2000	FILTER-SAW
2904-002350	F1005	FILTER-SAW
2904-002355	F2002	FILTER-SAW
2904-002381	F2006	FILTER-SAW
2904-002394	F2003	FILTER-SAW
2904-002397	F1004	FILTER-SAW
2910-000364	F1000	FILTER
2910-000401	F1006	FILTER
2910-000402	F1003	FILTER
2911-000435	U2005	FILTER
2911-000450	U1003	FILTER
3003-001215	MIC5000	MIC-CONDENSOR
3301-001812	L6004	CORE-FERRITE BEAD
3301-001885	L5016	CORE-FERRITE BEAD
3301-001901	L6002	CORE-FERRITE BEAD
3301-002078	L5013,L5014	CORE-FERRITE BEAD
3301-002122	L5019,L5020	CORE-FERRITE BEAD
3301-002223	L6001,L6010	CORE-FERRITE BEAD
3301-002236	L2016,L2023,L5005	CORE-FERRITE BEAD
3301-002236	L5007,L5009,L5011	CORE-FERRITE BEAD
3301-002236	L5012,U1009	CORE-FERRITE BEAD
3301-002237	L1001,L1017,L1077	CORE-FERRITE BEAD
3301-002237	L5000,L5001,L6006	CORE-FERRITE BEAD
3301-002237	L6007	CORE-FERRITE BEAD
3301-002238	L2006	CONNECTOR-COAXIAL
3301-002248	L2053,L2063	CORE-FERRITE BEAD
3301-002254	L4000	CORE-FERRITE BEAD
3301-002286	L5010	CORE-FERRITE BEAD
3301-002309	L2041,L5004	CORE-FERRITE BEAD
3301-002312	L4004	CORE-FERRITE BEAD
3705-001708	RFS1000	CONNECTOR-COAXIAL
3709-001880	CD4000	CONNECTOR-CARD
3709-001891	CD4001	CONNECTOR-CARD
3711-007107	HDC6002	CONNECTOR-HEADER
3711-007295	HDC6001	CONNECTOR-HEADER
3711-008511	HDC6000	CONNECTOR-HEADER
3711-009045	BTC4000	CONNECTOR-HEADER

5. MAIN Electrical Parts List

3711-009357	HDC6003	CONNECTOR-HEADER
3712-001604	ANT6010,ANT6013	CONNECTOR
3712-001621	ANT6000,ANT6001	CONNECTOR
3712-001621	ANT6002,ANT6003	CONNECTOR
3712-001621	ANT6004,ANT6005	CONNECTOR
3712-001621	ANT6006,ANT6007	CONNECTOR
3712-001621	ANT6008,ANT6009	CONNECTOR
3712-001621	ANT6011,ANT6012	CONNECTOR
3712-001621	ANT6014	CONNECTOR
3712-001626	ANT5000,ANT5003	CONNECTOR
3712-001666	ANT1001,ANT1002	CONNECTOR
3712-001666	ANT2000,ANT2001	CONNECTOR
3712-001666	ANT2003,ANT2004	CONNECTOR
3712-001666	ANT5001,ANT5002	CONNECTOR
3712-001694	ANT4000,ANT4001	CONNECTOR
3712-001694	ANT4002,ANT4004	CONNECTOR
3712-001694	ANT4005,ANT4006	CONNECTOR
3712-001694	ANT4007,ANT4008	CONNECTOR
3722-003954	IFC4000	JACK-PHONE
3722-004146	EAR5000	JACK-PHONE
4709-002412	CPL1000	RF-MODULE
GH61-13156A	SUS2001	SUS
GH62-00042A	SMR6000	SUS
GH63-09457A	SC2000	SHIELD CAN
GH63-13772A	SC2004	SHIELD CAN
GH63-15420A	SC2003	SHIELD CAN
GH63-15421A	SC2002	SHIELD CAN
GH63-16233A	SC2006	SHIELD CAN
GH63-16234A	SC2007	SHIELD CAN
GH63-16235A	SC2005	SHIELD CAN
GH02-16421A	SC2006SP	TAPE

Please consult the GSPN website (Samsung Portal) for the most recent version of the product's part list.