

5. MAIN Electrical Parts List

Parts Code	Design LOC	Description
0202-002125	R3010,R5007,R5029	PB-SHORT-0603
0202-002125	R5041,R6033,R6036	PB-SHORT-0603
0202-002126	R6039	PB-SHORT-1005
0404-001250	D6000	DIODE
0404-001646	D7000	DIODE
0406-001506	ZD1001	DIODE-TVS
0406-001561	ZD6020,ZD6026	DIODE-TVS
0406-001592	D3000,D3001,D3002	DIODE-TVS
0406-001592	ZD3007,ZD3008,ZD3009	DIODE-TVS
0406-001592	ZD3011,ZD3012	DIODE-TVS
0406-001728	ZD1000,ZD6001	DIODE-TVS
0406-001743	ZD6003,ZD6004,ZD6005	DIODE-TVS
0406-001743	ZD6017,ZD6018,ZD6019	DIODE-TVS
0406-001763	ZD6021,ZD6022,ZD6023	DIODE-TVS
0406-001763	ZD6024,ZD6025,ZD6027	DIODE-TVS
0406-001780	ZD4000	DIODE-TVS
0406-001797	ZD4002	DIODE-TVS
0406-001808	ZD6016	DIODE-TVS
0406-001809	ZD4001,ZD6013,ZD6014	DIODE-TVS
0505-003234	Q5002,TR5001,TR7000	FET-SILICON
0601-003768	LED5000	LED
0801-003639	U4000	IC
1001-001755	U4001,U5006	IC
1001-002042	U2089	IC
1001-002062	U3006	IC
1001-002063	U1001	IC
1009-001076	U3007	IC
1108-000659	UME6000	IC
1201-003869	U3005	IC
1201-003984	U2000	IC
1201-004109	PAM2000	IC
1201-004135	U1004	IC
1201-004200	U8000	IC
1201-004219	U1000,U1007	IC
1201-004229	U8015	IC
1203-008719	U3000	IC
1203-008859	U7002	IC
1203-008865	U7001	IC

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

1203-008867	U3016,U8004	IC
1203-009054	U6002	IC
1203-009220	U7000	IC
1203-009240	U2001	IC
1203-009246	U5003	IC
1203-009247	U5004	IC
1203-009252	U7003	IC
1205-005217	C7033	IC
1205-005731	U3021	IC
1205-005833	U2009	IC
1205-005881	U3004	IC
1205-006111	UCP4000	IC
1209-002450	U3003	IC
1209-002513	U3008	IC
1209-002621	U3001	IC
1404-001664	TH5000	THERMISTOR
1404-001724	TH2000,TH4000	THERMISTOR
1404-001724	THM3000	THERMISTOR
1405-001458	VR6000	VARISTOR
2007-003015	R3004,R3009,R6028	R-CHIP
2007-003015	R6029	R-CHIP
2007-007142	R7003,R7011	R-CHIP
2007-007313	R5001	R-CHIP
2007-007589	R5000	R-CHIP
2007-007741	R3002,R3006,R3007	R-CHIP
2007-007741	R4029,R5008,R6001	R-CHIP
2007-007741	R6004,R6022	R-CHIP
2007-008056	R1006,R1007	R-CHIP
2007-008210	R4018	R-CHIP
2007-008263	R4026	R-CHIP
2007-008420	R4017,R4023,R4024	R-CHIP
2007-008420	R5011,R7001	R-CHIP
2007-008483	R5002	R-CHIP
2007-008531	R5017,R7000,R7004	R-CHIP
2007-008531	R7005	R-CHIP
2007-008588	R3012,R3013,R4006	R-CHIP
2007-008588	R4008,R4009,R4010	R-CHIP
2007-008588	R4011,R4012,R4027	R-CHIP
2007-008588	R4028,R4031,R4032	R-CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2007-008588	R4033,R4034,R4037	R-CHIP
2007-008588	R4038	R-CHIP
2007-008766	R4016	R-CHIP
2007-008774	R6006,R6007,R6008	R-CHIP
2007-008774	R6009,R6010,R6012	R-CHIP
2007-008774	R6015,R6017,R6020	R-CHIP
2007-008774	R6021,R6024	R-CHIP
2007-008785	R1005	R-CHIP
2007-008798	R8000,R8001	R-CHIP
2007-008808	R7006	R-CHIP
2007-009111	R3001,R5006	R-CHIP
2007-009157	R4015,R5027	R-CHIP
2007-009171	R3008	R-CHIP
2007-009201	R4019,R4020,R8021	R-CHIP
2007-009212	R3005,R4021,R4022	R-CHIP
2007-009212	R4042,R5021,R5022	R-CHIP
2007-009212	R6018	R-CHIP
2007-009314	R6035	R-CHIP
2007-009315	R6005	R-CHIP
2007-009352	R7007,R8014,R8015	R-CHIP
2007-009361	R1008	R-CHIP
2007-009408	R4013,R4014,R6000	R-CHIP
2007-009766	R8044	R-CHIP
2007-009801	R7012	R-CHIP
2007-009805	R1000,R1001,R1002	R-CHIP
2007-009805	R2000	R-CHIP
2007-009807	R6037	R-CHIP
2007-009920	R4002,R6002,R6003	R-CHIP
2007-009954	R6038	R-CHIP
2007-009969	R3016,R3021,R4001	R-CHIP
2007-010233	R4025	R-CHIP
2007-010685	R5004,R5014	R-CHIP
2007-011043	R4000	R-CHIP
2203-000311	C7057	C-CERAMIC,CHIP
2203-000425	C7045	C-CERAMIC,CHIP
2203-000812	C7034	C-CERAMIC,CHIP
2203-000995	C3082,C3089	C-CERAMIC,CHIP
2203-001072	C3086	C-CERAMIC,CHIP
2203-005682	C1002,C1008,C1038	C-CERAMIC,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2203-005682	C1046,C2025,C2026	C-CERAMIC,CHIP
2203-005682	C2063,C2068,C2075	C-CERAMIC,CHIP
2203-005682	C2103,C3061,C3062	C-CERAMIC,CHIP
2203-005682	C3063,C7040,C7048	C-CERAMIC,CHIP
2203-005682	C7053	C-CERAMIC,CHIP
2203-005717	C1012,C1025,C1027	C-CERAMIC,CHIP
2203-005717	C1110,C2065,C2079	C-CERAMIC,CHIP
2203-005725	C1028,C3015,C3033	C-CERAMIC,CHIP
2203-005725	C7024	C-CERAMIC,CHIP
2203-005726	C4075,C8058	C-CERAMIC,CHIP
2203-005729	C7009	C-CERAMIC,CHIP
2203-005731	C3010,C7049,C7050	C-CERAMIC,CHIP
2203-005731	C7078,C7079	C-CERAMIC,CHIP
2203-005732	C8035,C8055	C-CERAMIC,CHIP
2203-005736	C1006,C1020,C1021	C-CERAMIC,CHIP
2203-005736	C1035,C1043,C1096	C-CERAMIC,CHIP
2203-005736	C1125,C1131,C2000	C-CERAMIC,CHIP
2203-005736	C2024,C2032,C2035	C-CERAMIC,CHIP
2203-005736	C2036,C2038,C2092	C-CERAMIC,CHIP
2203-005736	C2116,C3006,C3024	C-CERAMIC,CHIP
2203-005736	C3044,C3045,C3046	C-CERAMIC,CHIP
2203-005736	C3047,C3048,C3050	C-CERAMIC,CHIP
2203-005736	C3051,C3052,C3057	C-CERAMIC,CHIP
2203-005736	C3058	C-CERAMIC,CHIP
2203-005777	C1026,C1042,C1052	C-CERAMIC,CHIP
2203-005777	C1069,C1070,C2100	C-CERAMIC,CHIP
2203-005789	C1009,C1010,C1032	C-CERAMIC,CHIP
2203-005789	C1048,C1067,C1094	C-CERAMIC,CHIP
2203-005789	C1102,C2039,C2040	C-CERAMIC,CHIP
2203-005789	C2052,C2053,C2064	C-CERAMIC,CHIP
2203-005789	C2099,C2109,C2110	C-CERAMIC,CHIP
2203-005789	C3008	C-CERAMIC,CHIP
2203-005792	C1051,C1077,C2078	C-CERAMIC,CHIP
2203-006120	C6053,C6054	C-CERAMIC,CHIP
2203-006123	C3007,C3013,C3067	C-CERAMIC,CHIP
2203-006194	C6052	C-CERAMIC,CHIP
2203-006305	C1033,C3005,C3040	C-CERAMIC,CHIP
2203-006305	C7010	C-CERAMIC,CHIP
2203-006318	C2098	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-006400	C1004,C1007,C2061	C-CERAMIC,CHIP
2203-006400	C3083,C3085,C5029	C-CERAMIC,CHIP
2203-006400	C5095,C8001,C8004	C-CERAMIC,CHIP
2203-006423	C2003,C2004,C2006	C-CERAMIC,CHIP
2203-006423	C2007,C2008,C2009	C-CERAMIC,CHIP
2203-006423	C2010,C2011,C2012	C-CERAMIC,CHIP
2203-006423	C2013,C2015,C2016	C-CERAMIC,CHIP
2203-006423	C2017,C2019,C2020	C-CERAMIC,CHIP
2203-006423	C2021,C2022,C3001	C-CERAMIC,CHIP
2203-006423	C3016,C3059,C4077	C-CERAMIC,CHIP
2203-006423	C6001,C6003,C6004	C-CERAMIC,CHIP
2203-006423	C6005,C7025,C8000	C-CERAMIC,CHIP
2203-006556	C1039,C1045,C2074	C-CERAMIC,CHIP
2203-006556	C2082	C-CERAMIC,CHIP
2203-006604	C3020,C3041	C-CERAMIC,CHIP
2203-006665	C1050	C-CERAMIC,CHIP
2203-006674	C1019	C-CERAMIC,CHIP
2203-006753	C3087	C-CERAMIC,CHIP
2203-006839	C1000,C1005,C1092	C-CERAMIC,CHIP
2203-006839	C1114,C1130,C2060	C-CERAMIC,CHIP
2203-006839	C2115,C3074,C3081	C-CERAMIC,CHIP
2203-006839	C4020,C4021,C4086	C-CERAMIC,CHIP
2203-006839	C4095,C4096,C5022	C-CERAMIC,CHIP
2203-006839	C5100,C5115,C8006	C-CERAMIC,CHIP
2203-006844	C3038	C-CERAMIC,CHIP
2203-006846	C1076	C-CERAMIC,CHIP
2203-006979	C3019,C3023,C3025	C-CERAMIC,CHIP
2203-006979	C3026,C3027,C3034	C-CERAMIC,CHIP
2203-006979	C3093	C-CERAMIC,CHIP
2203-007143	C6029	C-CERAMIC,CHIP
2203-007210	C4029,C4038,C4039	C-CERAMIC,CHIP
2203-007279	C2057,C7015	C-CERAMIC,CHIP
2203-007317	C2002,C2056,C3002	C-CERAMIC,CHIP
2203-007317	C7012	C-CERAMIC,CHIP
2203-007391	C3036,C3049,C3060	C-CERAMIC,CHIP
2203-007391	C3076,C6050,C6051	C-CERAMIC,CHIP
2203-007393	C2005,C2014,C2018	C-CERAMIC,CHIP
2203-007393	C2023,C2059,C3028	C-CERAMIC,CHIP
2203-007393	C3029,C3031,C3037	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-007393	C3077,C3080,C4010	C-CERAMIC,CHIP
2203-007393	C5074,C5076,C5077	C-CERAMIC,CHIP
2203-007393	C5078,C5120,C5124	C-CERAMIC,CHIP
2203-007393	C5126,C6010,C6012	C-CERAMIC,CHIP
2203-007393	C6013,C6015,C6023	C-CERAMIC,CHIP
2203-007393	C6024,C6073,C6074	C-CERAMIC,CHIP
2203-007393	C6077,C7016,C7017	C-CERAMIC,CHIP
2203-007393	C7020,C7021,C7022	C-CERAMIC,CHIP
2203-007393	C7029	C-CERAMIC,CHIP
2203-007456	C5083,C6000,C8014	C-CERAMIC,CHIP
2203-007474	C5105,C5106,C5110	C-CERAMIC,CHIP
2203-007474	C5129,C7026,C9101	C-CERAMIC,CHIP
2203-007544	C3042,C3043	C-CERAMIC,CHIP
2203-007781	C7032	C-CERAMIC,CHIP
2203-007796	C3017,C3018,C3021	C-CERAMIC,CHIP
2203-007796	C3022,C3030,C3032	C-CERAMIC,CHIP
2203-007796	C3070,C3071,C3072	C-CERAMIC,CHIP
2203-007796	C4000,C4001,C4002	C-CERAMIC,CHIP
2203-007796	C4003,C4004,C4005	C-CERAMIC,CHIP
2203-007796	C4006,C4007,C4008	C-CERAMIC,CHIP
2203-007796	C4009,C4011,C4012	C-CERAMIC,CHIP
2203-007796	C4014,C4016,C4017	C-CERAMIC,CHIP
2203-007796	C4018,C4022,C4024	C-CERAMIC,CHIP
2203-007796	C4025,C4026,C4027	C-CERAMIC,CHIP
2203-007796	C4028,C4030,C4031	C-CERAMIC,CHIP
2203-007796	C4032,C4035,C4042	C-CERAMIC,CHIP
2203-007796	C4044,C4045,C4047	C-CERAMIC,CHIP
2203-007796	C4049,C4050,C4051	C-CERAMIC,CHIP
2203-007796	C4052,C4053,C4054	C-CERAMIC,CHIP
2203-007796	C4055,C4056,C4057	C-CERAMIC,CHIP
2203-007796	C4058,C4059,C4060	C-CERAMIC,CHIP
2203-007796	C4061,C4062,C4068	C-CERAMIC,CHIP
2203-007796	C4069,C4070,C4071	C-CERAMIC,CHIP
2203-007796	C4072,C5068,C5069	C-CERAMIC,CHIP
2203-007796	C5070,C5071,C5072	C-CERAMIC,CHIP
2203-007796	C5073,C5075,C5079	C-CERAMIC,CHIP
2203-007796	C5092,C5104,C5107	C-CERAMIC,CHIP
2203-007796	C5108,C5109,C5112	C-CERAMIC,CHIP
2203-007796	C5113,C5114,C5116	C-CERAMIC,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2203-007796	C5117,C5119,C5121	C-CERAMIC,CHIP
2203-007796	C5122,C5128,C6002	C-CERAMIC,CHIP
2203-007796	C6006,C6007,C6008	C-CERAMIC,CHIP
2203-007796	C6009,C6014,C6016	C-CERAMIC,CHIP
2203-007796	C6017,C6020,C6021	C-CERAMIC,CHIP
2203-007796	C6025,C6026,C6027	C-CERAMIC,CHIP
2203-007796	C6028,C6043,C6044	C-CERAMIC,CHIP
2203-007796	C6046,C7002,C7003	C-CERAMIC,CHIP
2203-007796	C7007,C7013,C7014	C-CERAMIC,CHIP
2203-007796	C7018,C7019,C7027	C-CERAMIC,CHIP
2203-007796	C7036,C7039,C8056	C-CERAMIC,CHIP
2203-007796	C8059	C-CERAMIC,CHIP
2203-008095	C3069,C4063	C-CERAMIC,CHIP
2203-008097	C5019,C8020	C-CERAMIC,CHIP
2203-008242	C7005	C-CERAMIC,CHIP
2203-008529	C1016,C1047	C-CERAMIC,CHIP
2203-008654	C5004,C6045	C-CERAMIC,CHIP
2203-008749	C5055,C7044	C-CERAMIC,CHIP
2203-008860	C3011,C4015,C4019	C-CERAMIC,CHIP
2203-008860	C4023,C5000,C5002	C-CERAMIC,CHIP
2203-008860	C5021,C5023,C5025	C-CERAMIC,CHIP
2203-008860	C5027,C5035,C5040	C-CERAMIC,CHIP
2203-008860	C5042,C5044,C5045	C-CERAMIC,CHIP
2203-008860	C5047,C5050,C5081	C-CERAMIC,CHIP
2203-008860	C5084,C5086,C5088	C-CERAMIC,CHIP
2203-008860	C5097,C5098,C5101	C-CERAMIC,CHIP
2203-008860	C7035,C7038,C7041	C-CERAMIC,CHIP
2203-008860	C7042,C7072,C8015	C-CERAMIC,CHIP
2203-008860	C8022,C8057	C-CERAMIC,CHIP
2203-008876	C1041,C1044,C2076	C-CERAMIC,CHIP
2203-008876	C2080,C3014,C3035	C-CERAMIC,CHIP
2203-008876	C3054,C3073,C3075	C-CERAMIC,CHIP
2203-008876	C3078,C3079,C7000	C-CERAMIC,CHIP
2203-008876	C7028,C7030,C7031	C-CERAMIC,CHIP
2203-008876	C8003,C9081,C9082	C-CERAMIC,CHIP
2203-009064	C4033,C4034,C4040	C-CERAMIC,CHIP
2203-009064	C4041,C4066,C4067	C-CERAMIC,CHIP
2203-009064	C6022	C-CERAMIC,CHIP
2203-009167	C3084,C3088	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-009444	C8060	C-CERAMIC,CHIP
2203-009618	C4076,C8010,C8061	C-CERAMIC,CHIP
2203-009733	C4043,C5026,C5028	C-CERAMIC,CHIP
2203-009733	C5032,C5033,C5036	C-CERAMIC,CHIP
2203-009733	C5038,C5049,C5052	C-CERAMIC,CHIP
2203-009733	C5056,C5064,C5065	C-CERAMIC,CHIP
2203-009733	C5066,C5085,C5090	C-CERAMIC,CHIP
2203-009733	C5096,C5103,C5111	C-CERAMIC,CHIP
2203-009733	C6072,C7001,C7006	C-CERAMIC,CHIP
2203-009733	C7008,C7011,C7043	C-CERAMIC,CHIP
2203-009733	C7046,C7047,C7051	C-CERAMIC,CHIP
2203-009733	C7052,C7062,C8008	C-CERAMIC,CHIP
2203-009733	C8051	C-CERAMIC,CHIP
2203-009735	C4073,C4074	C-CERAMIC,CHIP
2203-009787	C5067	C-CERAMIC,CHIP
2203-009812	C8044,C8062	C-CERAMIC,CHIP
2203-009858	C8005,C8007	C-CERAMIC,CHIP
2203-010085	C5087,C5094	C-CERAMIC,CHIP
2703-002649	L1002,L2029	INDUCTOR-SMD
2703-002858	L2025,L2027,L2053	INDUCTOR-SMD
2703-002900	L2002	INDUCTOR-SMD
2703-002903	L1011,L1012,L1016	INDUCTOR-SMD
2703-002903	L1018,L3013	INDUCTOR-SMD
2703-002907	L1053,L2018,L2022	INDUCTOR-SMD
2703-002951	L1019,L1050	INDUCTOR-SMD
2703-002953	L1021	INDUCTOR-SMD
2703-002959	L3009	INDUCTOR-SMD
2703-002999	L2028	INDUCTOR-SMD
2703-004012	L2001,L2003,L2045	INDUCTOR-SMD
2703-004013	L1008,L1024,L1026	INDUCTOR-SMD
2703-004013	L1042,L2038,L2040	INDUCTOR-SMD
2703-004014	L1028,L1030,L1057	INDUCTOR-SMD
2703-004014	L2005,L2010	INDUCTOR-SMD
2703-004018	L1001	INDUCTOR-SMD
2703-004032	L2051	INDUCTOR-SMD
2703-004033	L1039,L2047,L2057	INDUCTOR-SMD
2703-004034	L3000,L3001,L3003	INDUCTOR-SMD
2703-004035	L2012,L2048	INDUCTOR-SMD
2703-004038	L1007,L2006,L3002	INDUCTOR-SMD

5. MAIN Electrical Parts List

2703-004286	L1005,L1043,L2034	INDUCTOR-SMD
2703-004286	L2035,L2042	INDUCTOR-SMD
2703-004287	L1037,L1045,L2032	INDUCTOR-SMD
2703-004288	L1061,L2026,L2061	INDUCTOR-SMD
2703-004289	L1003	INDUCTOR-SMD
2703-004295	L1000	INDUCTOR-SMD
2703-004299	L2046	INDUCTOR-SMD
2703-004302	L1015,L1032,L2021	INDUCTOR-SMD
2703-004302	L2054,L3015	INDUCTOR-SMD
2703-004328	L1035	INDUCTOR-SMD
2703-004362	L2015	INDUCTOR-SMD
2703-004703	L2014	INDUCTOR-SMD
2703-004763	L1009	INDUCTOR-SMD
2703-004853	L1013,L3010,L8018	INDUCTOR-SMD
2703-004862	L1038	INDUCTOR-SMD
2703-004911	L1023,L1044	INDUCTOR-SMD
2703-005066	L2013	INDUCTOR-SMD
2703-005085	L2019,L2065	INDUCTOR-SMD
2703-005118	L7008	INDUCTOR-SMD
2703-005200	L7007	INDUCTOR-SMD
2703-005233	L8005,L8017	INDUCTOR-SMD
2703-005505	L5019,L8000,L8001	INDUCTOR-SMD
2703-005555	L3017,L3018	INDUCTOR-SMD
2703-005581	L5007	INDUCTOR-SMD
2703-005660	L5000,L5002,L5003	INDUCTOR-SMD
2703-005660	L5006,L5008,L5010	INDUCTOR-SMD
2703-005660	L5011,L5015,L5016	INDUCTOR-SMD
2703-005660	L5020,L5022,L5023	INDUCTOR-SMD
2801-005481	OSC5000	CRYSTAL-UNIT
2901-001690	C4091	C-CERAMIC,CHIP
2903-001576	F3000	FILTER
2904-002253	F1003,F2004	FILTER
2904-002257	F2002	FILTER
2904-002260	F1000	FILTER
2904-002350	F2003	FILTER
2904-002355	F3002,F3003	FILTER
2904-002381	F3009	FILTER
2904-002397	F2005,F2006	FILTER
2910-000390	F2008	FILTER

5. MAIN Electrical Parts List

2911-000430	C2070	FILTER
2911-000452	F1001	FILTER
3003-001210	MIC8001	MIC-CONDENSOR
3301-002223	L7000,L7001,L7002	CORE-FERRITE BEAD
3301-002223	L7009	CORE-FERRITE BEAD
3301-002228	L8003,L8004	CORE-FERRITE BEAD
3301-002235	L2037,L3810,L3811	CORE-FERRITE BEAD
3301-002237	L1017,L8002	CORE-FERRITE BEAD
3301-002238	L3011	CORE-FERRITE BEAD
3301-002243	L7003,L7004,L7005	CORE-FERRITE BEAD
3301-002243	L7010,L7011	CORE-FERRITE BEAD
3301-002254	L6002,L7006	CORE-FERRITE BEAD
3301-002331	L5004	CORE-FERRITE BEAD
3705-001937	RFS1000	CONNECTOR-COAXIAL
3709-001892	SIM6000	CONNECTOR-CARD EDGE
3710-004008	SOC5000	CONNECTOR
3710-004344	SOC6000,SOC7000	CONNECTOR
3711-008508	HDC7000	CONNECTOR
3711-008511	HDC7001	CONNECTOR
3711-008931	HDC7002,HDC7003	CONNECTOR
3711-008997	HEA3001	CONNECTOR
3712-001604	ANT2000,ANT2001	CONNECTOR
3712-001604	ANT2002,ANT3002	CONNECTOR
3712-001604	ANT3011	CONNECTOR
3712-001621	ANT3000,ANT3003	CONNECTOR
3712-001621	ANT3004,ANT3006	CONNECTOR
3712-001621	ANT3007,ANT3008	CONNECTOR
3712-001621	ANT3010	CONNECTOR
3712-001626	ANT1000,ANT1001	CONNECTOR
3712-001626	ANT1003,ANT1004	CONNECTOR
3712-001626	ANT1005,ANT1006	CONNECTOR
3712-001626	ANT1007	CONNECTOR
3712-001799	ANT8000,ANT8001	CONNECTOR
4709-002196	F2001	RF-MODULE
4709-002226	F1002	RF-MODULE
4709-002285	DIF3000	RF-MODULE
4709-002412	F1007	RF-MODULE
4709-002464	F1004	RF-MODULE
4709-002484	F2000	RF-MODULE

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

GH60-00010A	CON1000	2D-BARCODE
GH61-14598A	SUS1000	SUS
GH62-00042A	GA6000	GASKET
GH63-17278A	SC1003	SHIELD-CAN
GH63-17279A	SC1002	SHIELD-CAN
GH63-17280A	SC1001	SHIELD-CAN
GH63-17281A	SC1000	SHIELD-CAN
GH63-17282A	SC1004	SHIELD-CAN

Please consult the GSPN website (Samsung Portal) for the most recent version of the product's part list.