

## 5. MAIN Electrical Parts List

Parts Code	Design Loc	Description
0404-001669	D6000	DIODE-SCHOTTKY
0406-001514	ZD5000	DIODE-TVS
0406-001642	ZD5008	DIODE-TVS
0406-001642	ZD5009	DIODE-TVS
0406-001709	ZD5001	DIODE-TVS
0406-001709	ZD5002	DIODE-TVS
0406-001709	ZD5003	DIODE-TVS
0406-001709	ZD5004	DIODE-TVS
0406-001709	ZD5005	DIODE-TVS
0406-001728	ZD4000	DIODE-TVS
0406-001730	ZD4002	DIODE-TVS
0505-003234	TR4001	FET-SILICON
1001-001835	U2002	IC-RF SWITCH
1001-001849	U1001	IC-RF SWITCH
1001-001870	U6060	IC-RF SWITCH
1001-001898	U6035	IC-RF SWITCH
1001-001971	U1003	IC-RF SWITCH
1001-001972	U1004	IC-RF SWITCH
1001-001972	U6004	IC-RF SWITCH
1001-001972	U6005	IC-RF SWITCH
1001-001972	U6006	IC-RF SWITCH
1105-002737	UME3000	IC-DDR3 SDRAM
1107-002395	UME3001	IC-EMMC
1201-003786	U2005	IC-GPS AMP
1201-003812	PAM1001	IC-POWER AMP
1201-003915	PAM1000	IC-POWER AMP
1201-003990	U1006	IC-IF/RF AMP
1203-008416	U4000	IC-SWITCH REG.
1203-008715	U6000	IC-BACKLIGHT DRIVER
1203-008722	PM4000	IC-POWER SUPERVISOR
1205-005175	U4001	IC-SWITCH
1205-005244	U6001	IC-TOUCH
1205-005288	U2009	IC-GPS RECEIVER
1205-005315	U4004	IC-SWITCH
1205-005408	U2003	IC-WIFI
1205-005495	U2008	IC-TRANSCIVER
1205-005498	UCP3000	IC-MODEM

## 5. MAIN Electrical Parts List

1209-002275	U2004	IC-ACCELEROMETER SENSOR
1209-002331	U2001	IC-TOUCH SENSOR
1404-001694	TH4000	THERMISTOR-NTC
1404-001694	TH4001	THERMISTOR-NTC
1405-001183	V5000	VARISTOR
1405-001183	V5001	VARISTOR
2007-000140	R2008	R-CHIP
2007-000140	R4013	R-CHIP
2007-000140	R5010	R-CHIP
2007-000172	R6002	R-CHIP
2007-001319	R5009	R-CHIP
2007-001339	R6023	R-CHIP
2007-007156	R4044	R-CHIP
2007-007190	R4010	R-CHIP
2007-007190	R4011	R-CHIP
2007-007318	R4033	R-CHIP
2007-007517	R3015	R-CHIP
2007-007861	R4005	R-CHIP
2007-007861	R4006	R-CHIP
2007-008045	R4009	R-CHIP
2007-008052	R6007	R-CHIP
2007-008056	R103	R-CHIP
2007-008056	R104	R-CHIP
2007-008419	R2011	R-CHIP
2007-008419	R2013	R-CHIP
2007-008419	R2019	R-CHIP
2007-008419	R4014	R-CHIP
2007-008419	R4015	R-CHIP
2007-008419	R4016	R-CHIP
2007-008419	R4017	R-CHIP
2007-008419	R4018	R-CHIP
2007-008419	R6004	R-CHIP
2007-008420	U6003	R-CHIP
2007-008478	R1004	R-CHIP
2007-008478	R4000	R-CHIP
2007-008478	R4001	R-CHIP
2007-008483	R2014	R-CHIP
2007-008483	R2015	R-CHIP
2007-008483	R2016	R-CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

## 5. MAIN Electrical Parts List

2007-008483	R2017	R-CHIP
2007-008483	R2018	R-CHIP
2007-008516	R3026	R-CHIP
2007-008516	R3027	R-CHIP
2007-008516	R3028	R-CHIP
2007-008516	R3035	R-CHIP
2007-008516	R5003	R-CHIP
2007-008516	R5004	R-CHIP
2007-008516	R5005	R-CHIP
2007-008516	R5006	R-CHIP
2007-008531	R3034	R-CHIP
2007-008531	R4040	R-CHIP
2007-008531	R6003	R-CHIP
2007-008531	R6006	R-CHIP
2007-008531	R6011	R-CHIP
2007-008587	R4019	R-CHIP
2007-008587	R4020	R-CHIP
2007-008588	R2027	R-CHIP
2007-008588	R5015	R-CHIP
2007-008588	R5016	R-CHIP
2007-008588	R6008	R-CHIP
2007-008588	R6009	R-CHIP
2007-008648	R4002	R-CHIP
2007-008774	R4036	R-CHIP
2007-008774	R4038	R-CHIP
2007-008785	R102	R-CHIP
2007-008806	R1001	R-CHIP
2007-009111	R3014	R-CHIP
2007-009158	R4007	R-CHIP
2007-009158	R4008	R-CHIP
2007-009212	R5007	R-CHIP
2007-009766	R4003	R-CHIP
2007-009838	R4030	R-CHIP
2007-009920	R3031	R-CHIP
2007-009969	R5008	R-CHIP
2007-010233	R3017	R-CHIP
2007-010233	R3018	R-CHIP
2007-010233	R3019	R-CHIP
2007-010848	R4037	R-CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

## 5. MAIN Electrical Parts List

2007-011043	R3029	R-CHIP
2007-012285	R6005	R-CHIP
2203-000233	C1012	C-CER,CHIP
2203-000254	C5000	C-CER,CHIP
2203-005682	C1008	C-CER,CHIP
2203-005682	C1103	C-CER,CHIP
2203-005682	C1180	C-CER,CHIP
2203-005682	C173	C-CER,CHIP
2203-005682	C2034	C-CER,CHIP
2203-005682	C2051	C-CER,CHIP
2203-005682	C2070	C-CER,CHIP
2203-005682	C2073	C-CER,CHIP
2203-005682	C5005	C-CER,CHIP
2203-005682	C6002	C-CER,CHIP
2203-005682	C6040	C-CER,CHIP
2203-005682	C6041	C-CER,CHIP
2203-005682	C6042	C-CER,CHIP
2203-005682	L1057	C-CER,CHIP
2203-005725	C2068	C-CER,CHIP
2203-005725	C2101	C-CER,CHIP
2203-005725	L1000	C-CER,CHIP
2203-005727	C2063	C-CER,CHIP
2203-005729	C2023	C-CER,CHIP
2203-005729	C2053	C-CER,CHIP
2203-005729	C2061	C-CER,CHIP
2203-005729	C2062	C-CER,CHIP
2203-005729	C5011	C-CER,CHIP
2203-005729	C5020	C-CER,CHIP
2203-005731	C1088	C-CER,CHIP
2203-005731	C6001	C-CER,CHIP
2203-005732	C5021	C-CER,CHIP
2203-005734	C6036	C-CER,CHIP
2203-005736	C1002	C-CER,CHIP
2203-005736	C1013	C-CER,CHIP
2203-005736	C1014	C-CER,CHIP
2203-005736	C10190	C-CER,CHIP
2203-005736	C10205	C-CER,CHIP
2203-005736	C10206	C-CER,CHIP
2203-005736	C10207	C-CER,CHIP

## 5. MAIN Electrical Parts List

2203-005736	C10208	C-CER,CHIP
2203-005736	C10209	C-CER,CHIP
2203-005736	C10211	C-CER,CHIP
2203-005736	C10214	C-CER,CHIP
2203-005736	C10216	C-CER,CHIP
2203-005736	C10219	C-CER,CHIP
2203-005736	C10220	C-CER,CHIP
2203-005736	C1039	C-CER,CHIP
2203-005736	C1052	C-CER,CHIP
2203-005736	C111	C-CER,CHIP
2203-005736	C112	C-CER,CHIP
2203-005736	C1122	C-CER,CHIP
2203-005736	C1130	C-CER,CHIP
2203-005736	C1146	C-CER,CHIP
2203-005736	C1154	C-CER,CHIP
2203-005736	C1156	C-CER,CHIP
2203-005736	C201	C-CER,CHIP
2203-005736	C202	C-CER,CHIP
2203-005736	C2031	C-CER,CHIP
2203-005736	C2035	C-CER,CHIP
2203-005736	C2036	C-CER,CHIP
2203-005736	C2057	C-CER,CHIP
2203-005736	C2069	C-CER,CHIP
2203-005736	C209	C-CER,CHIP
2203-005736	C210	C-CER,CHIP
2203-005736	C2107	C-CER,CHIP
2203-005736	C211	C-CER,CHIP
2203-005736	L1011	C-CER,CHIP
2203-005736	L1018	C-CER,CHIP
2203-005736	L6010	C-CER,CHIP
2203-005777	C1101	C-CER,CHIP
2203-005789	C1019	C-CER,CHIP
2203-005789	C1028	C-CER,CHIP
2203-005789	C1050	C-CER,CHIP
2203-005789	C1106	C-CER,CHIP
2203-005789	C2060	C-CER,CHIP
2203-005792	L1020	C-CER,CHIP
2203-006048	C4022	C-CER,CHIP

## 5. MAIN Electrical Parts List

2203-006048	C4027	C-CER,CHIP
2203-006121	C1032	C-CER,CHIP
2203-006123	L1029	C-CER,CHIP
2203-006137	C4009	C-CER,CHIP
2203-006187	C1001	C-CER,CHIP
2203-006194	C3011	C-CER,CHIP
2203-006305	C1057	C-CER,CHIP
2203-006305	C2025	C-CER,CHIP
2203-006305	C2026	C-CER,CHIP
2203-006305	C2032	C-CER,CHIP
2203-006305	C2079	C-CER,CHIP
2203-006305	C2082	C-CER,CHIP
2203-006305	C2084	C-CER,CHIP
2203-006305	C2085	C-CER,CHIP
2203-006305	C2110	C-CER,CHIP
2203-006305	L1032	C-CER,CHIP
2203-006318	L1019	C-CER,CHIP
2203-006379	C4070	C-CER,CHIP
2203-006379	C4071	C-CER,CHIP
2203-006399	C2065	C-CER,CHIP
2203-006399	C3026	C-CER,CHIP
2203-006399	C3033	C-CER,CHIP
2203-006399	C4018	C-CER,CHIP
2203-006400	C1025	C-CER,CHIP
2203-006400	C1097	C-CER,CHIP
2203-006400	C2050	C-CER,CHIP
2203-006400	C2075	C-CER,CHIP
2203-006400	C2106	C-CER,CHIP
2203-006400	C5001	C-CER,CHIP
2203-006400	C5002	C-CER,CHIP
2203-006423	C10194	C-CER,CHIP
2203-006423	C10195	C-CER,CHIP
2203-006423	C10212	C-CER,CHIP
2203-006423	C10218	C-CER,CHIP
2203-006423	C1034	C-CER,CHIP
2203-006423	C1087	C-CER,CHIP
2203-006423	C1090	C-CER,CHIP
2203-006423	C1093	C-CER,CHIP
2203-006423	C1147	C-CER,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

## 5. MAIN Electrical Parts List

2203-006423	C158	C-CER,CHIP
2203-006423	C2011	C-CER,CHIP
2203-006423	C2012	C-CER,CHIP
2203-006423	C2028	C-CER,CHIP
2203-006423	C2039	C-CER,CHIP
2203-006423	C2045	C-CER,CHIP
2203-006423	C2064	C-CER,CHIP
2203-006423	C2078	C-CER,CHIP
2203-006423	C2080	C-CER,CHIP
2203-006423	C2081	C-CER,CHIP
2203-006423	C2083	C-CER,CHIP
2203-006423	C2086	C-CER,CHIP
2203-006423	C2098	C-CER,CHIP
2203-006423	C2108	C-CER,CHIP
2203-006423	C2111	C-CER,CHIP
2203-006423	C3000	C-CER,CHIP
2203-006423	C3001	C-CER,CHIP
2203-006423	C3003	C-CER,CHIP
2203-006423	C3004	C-CER,CHIP
2203-006423	C3007	C-CER,CHIP
2203-006423	C3010	C-CER,CHIP
2203-006423	C3015	C-CER,CHIP
2203-006423	C3017	C-CER,CHIP
2203-006423	C3018	C-CER,CHIP
2203-006423	C3021	C-CER,CHIP
2203-006423	C3022	C-CER,CHIP
2203-006423	C3024	C-CER,CHIP
2203-006423	C3027	C-CER,CHIP
2203-006423	C3030	C-CER,CHIP
2203-006423	C3031	C-CER,CHIP
2203-006423	C3034	C-CER,CHIP
2203-006423	C3038	C-CER,CHIP
2203-006423	C3039	C-CER,CHIP
2203-006423	C3040	C-CER,CHIP
2203-006423	C3041	C-CER,CHIP
2203-006423	C3045	C-CER,CHIP
2203-006423	C4010	C-CER,CHIP
2203-006423	C4076	C-CER,CHIP
2203-006423	C5006	C-CER,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

## 5. MAIN Electrical Parts List

2203-006423	C5009	C-CER,CHIP
2203-006423	C5018	C-CER,CHIP
2203-006423	C5019	C-CER,CHIP
2203-006423	C6037	C-CER,CHIP
2203-006423	C6038	C-CER,CHIP
2203-006462	C2066	C-CER,CHIP
2203-006556	C10217	C-CER,CHIP
2203-006562	C1024	C-CER,CHIP
2203-006562	C1031	C-CER,CHIP
2203-006562	C4008	C-CER,CHIP
2203-006562	C4058	C-CER,CHIP
2203-006562	C6020	C-CER,CHIP
2203-006665	C1029	C-CER,CHIP
2203-006665	C1036	C-CER,CHIP
2203-006668	C4035	C-CER,CHIP
2203-006674	C1033	C-CER,CHIP
2203-006674	C1048	C-CER,CHIP
2203-006674	C1108	C-CER,CHIP
2203-006707	C1037	C-CER,CHIP
2203-006707	C2054	C-CER,CHIP
2203-006707	C2055	C-CER,CHIP
2203-006707	C2056	C-CER,CHIP
2203-006707	C2058	C-CER,CHIP
2203-006707	C2059	C-CER,CHIP
2203-006839	C3054	C-CER,CHIP
2203-006872	C2077	C-CER,CHIP
2203-006872	C2096	C-CER,CHIP
2203-006872	C2099	C-CER,CHIP
2203-006872	C2102	C-CER,CHIP
2203-006872	C3002	C-CER,CHIP
2203-006872	C3005	C-CER,CHIP
2203-006872	C3006	C-CER,CHIP
2203-006872	C3012	C-CER,CHIP
2203-006872	C3013	C-CER,CHIP
2203-006872	C3020	C-CER,CHIP
2203-006872	C4015	C-CER,CHIP
2203-006872	C4026	C-CER,CHIP
2203-006872	C4030	C-CER,CHIP
2203-006872	C4031	C-CER,CHIP



## 5. MAIN Electrical Parts List

2203-006872	C4036	C-CER,CHIP
2203-006872	C4073	C-CER,CHIP
2203-006872	C4075	C-CER,CHIP
2203-006872	C6006	C-CER,CHIP
2203-006872	C6009	C-CER,CHIP
2203-006872	C6024	C-CER,CHIP
2203-006872	C6026	C-CER,CHIP
2203-006890	C4065	C-CER,CHIP
2203-006890	C4067	C-CER,CHIP
2203-006890	C4086	C-CER,CHIP
2203-006896	L2024	C-CER,CHIP
2203-006978	C4083	C-CER,CHIP
2203-006978	C6010	C-CER,CHIP
2203-006979	C3052	C-CER,CHIP
2203-006979	C3053	C-CER,CHIP
2203-007194	C1066	C-CER,CHIP
2203-007194	C1145	C-CER,CHIP
2203-007194	C1181	C-CER,CHIP
2203-007210	C2030	C-CER,CHIP
2203-007210	C2048	C-CER,CHIP
2203-007210	C2049	C-CER,CHIP
2203-007240	C4063	C-CER,CHIP
2203-007240	C4066	C-CER,CHIP
2203-007240	C4068	C-CER,CHIP
2203-007240	C4069	C-CER,CHIP
2203-007271	C2067	C-CER,CHIP
2203-007271	C3044	C-CER,CHIP
2203-007271	C4006	C-CER,CHIP
2203-007271	C4055	C-CER,CHIP
2203-007271	C4081	C-CER,CHIP
2203-007279	C4007	C-CER,CHIP
2203-007279	C4023	C-CER,CHIP
2203-007279	C4032	C-CER,CHIP
2203-007279	C4077	C-CER,CHIP
2203-007279	C6003	C-CER,CHIP
2203-007317	C3025	C-CER,CHIP
2203-007317	C4000	C-CER,CHIP
2203-007317	C4002	C-CER,CHIP
2203-007317	C4052	C-CER,CHIP

## 5. MAIN Electrical Parts List

2203-007317	C4053	C-CER,CHIP
2203-007317	C6014	C-CER,CHIP
2203-007369	C1003	C-CER,CHIP
2203-007369	C1004	C-CER,CHIP
2203-007369	C1017	C-CER,CHIP
2203-007369	C1018	C-CER,CHIP
2203-007369	C1094	C-CER,CHIP
2203-007369	C2044	C-CER,CHIP
2203-007391	C2047	C-CER,CHIP
2203-007391	C2097	C-CER,CHIP
2203-007393	C2027	C-CER,CHIP
2203-007393	C2040	C-CER,CHIP
2203-007393	C2042	C-CER,CHIP
2203-007393	C2046	C-CER,CHIP
2203-007449	C1091	C-CER,CHIP
2203-007449	C2029	C-CER,CHIP
2203-007449	C2089	C-CER,CHIP
2203-007449	C2090	C-CER,CHIP
2203-007449	C2091	C-CER,CHIP
2203-007449	C2100	C-CER,CHIP
2203-007449	C2112	C-CER,CHIP
2203-007449	C3019	C-CER,CHIP
2203-007449	C3035	C-CER,CHIP
2203-007449	C3036	C-CER,CHIP
2203-007449	C3037	C-CER,CHIP
2203-007449	C3046	C-CER,CHIP
2203-007449	C4001	C-CER,CHIP
2203-007449	C4004	C-CER,CHIP
2203-007449	C4012	C-CER,CHIP
2203-007449	C4013	C-CER,CHIP
2203-007449	C4014	C-CER,CHIP
2203-007449	C4016	C-CER,CHIP
2203-007449	C4017	C-CER,CHIP
2203-007449	C4019	C-CER,CHIP
2203-007449	C4020	C-CER,CHIP
2203-007449	C4021	C-CER,CHIP
2203-007449	C4024	C-CER,CHIP
2203-007449	C4025	C-CER,CHIP
2203-007449	C4037	C-CER,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

## 5. MAIN Electrical Parts List

2203-007449	C4048	C-CER,CHIP
2203-007449	C4049	C-CER,CHIP
2203-007449	C4054	C-CER,CHIP
2203-007449	C4059	C-CER,CHIP
2203-007449	C4060	C-CER,CHIP
2203-007449	C4061	C-CER,CHIP
2203-007449	C4062	C-CER,CHIP
2203-007449	C6005	C-CER,CHIP
2203-007449	C6008	C-CER,CHIP
2203-007449	C6015	C-CER,CHIP
2203-007449	C6017	C-CER,CHIP
2203-007449	C6018	C-CER,CHIP
2203-007449	C6019	C-CER,CHIP
2203-007449	C6023	C-CER,CHIP
2203-007449	C6031	C-CER,CHIP
2203-007449	C6035	C-CER,CHIP
2203-007474	C3009	C-CER,CHIP
2203-007474	C3014	C-CER,CHIP
2203-007474	C3016	C-CER,CHIP
2203-007474	C4041	C-CER,CHIP
2203-007693	C6000	C-CER,CHIP
2203-007775	C1023	C-CER,CHIP
2203-007775	C4033	C-CER,CHIP
2203-007775	C4038	C-CER,CHIP
2203-007775	C4039	C-CER,CHIP
2203-007775	C4040	C-CER,CHIP
2203-007775	C4045	C-CER,CHIP
2203-007775	C4047	C-CER,CHIP
2203-007775	C4074	C-CER,CHIP
2203-007781	C4046	C-CER,CHIP
2203-008097	C2103	C-CER,CHIP
2203-008097	C2104	C-CER,CHIP
2203-008097	C2105	C-CER,CHIP
2203-008242	C2041	C-CER,CHIP
2203-008242	C2043	C-CER,CHIP
2203-008242	C4042	C-CER,CHIP
2203-008242	C4043	C-CER,CHIP
2203-008242	C4050	C-CER,CHIP
2203-008394	C4005	C-CER,CHIP

## 5. MAIN Electrical Parts List

2203-008394	C4011	C-CER,CHIP
2203-008654	C4057	C-CER,CHIP
2203-008876	C4051	C-CER,CHIP
2203-009328	C3008	C-CER,CHIP
2203-009328	C4064	C-CER,CHIP
2703-002309	L5000	INDUCTOR-SMD
2703-002649	C1049	INDUCTOR-SMD
2703-002858	C1026	INDUCTOR-SMD
2703-002858	U6064	INDUCTOR-SMD
2703-002901	C1041	INDUCTOR-SMD
2703-002901	C1067	INDUCTOR-SMD
2703-002901	L1041	INDUCTOR-SMD
2703-002907	L1050	INDUCTOR-SMD
2703-002951	L1044	INDUCTOR-SMD
2703-002951	L2011	INDUCTOR-SMD
2703-002953	L2012	INDUCTOR-SMD
2703-002958	L2015	INDUCTOR-SMD
2703-002959	L5022	INDUCTOR-SMD
2703-003004	L2023	INDUCTOR-SMD
2703-003064	L2014	INDUCTOR-SMD
2703-003878	L5001	INDUCTOR-SMD
2703-003970	L1043	INDUCTOR-SMD
2703-003970	L6024	INDUCTOR-SMD
2703-004000	C1016	INDUCTOR-SMD
2703-004000	L110	INDUCTOR-SMD
2703-004000	L5025	INDUCTOR-SMD
2703-004000	U6016	INDUCTOR-SMD
2703-004012	C212	INDUCTOR-SMD
2703-004012	L1056	INDUCTOR-SMD
2703-004012	L6019	INDUCTOR-SMD
2703-004012	L6025	INDUCTOR-SMD
2703-004013	L1005	INDUCTOR-SMD
2703-004013	L1051	INDUCTOR-SMD
2703-004013	L1052	INDUCTOR-SMD
2703-004013	L1059	INDUCTOR-SMD
2703-004013	L2007	INDUCTOR-SMD
2703-004013	L6018	INDUCTOR-SMD
2703-004014	L1004	INDUCTOR-SMD
2703-004014	L1053	INDUCTOR-SMD

## 5. MAIN Electrical Parts List

2703-004018	L1023	INDUCTOR-SMD
2703-004018	L1024	INDUCTOR-SMD
2703-004018	L1026	INDUCTOR-SMD
2703-004018	L1037	INDUCTOR-SMD
2703-004032	C1109	INDUCTOR-SMD
2703-004032	L1047	INDUCTOR-SMD
2703-004032	L2019	INDUCTOR-SMD
2703-004032	L6023	INDUCTOR-SMD
2703-004034	C1047	INDUCTOR-SMD
2703-004034	L1010	INDUCTOR-SMD
2703-004034	L2025	INDUCTOR-SMD
2703-004034	L6013	INDUCTOR-SMD
2703-004034	L6027	INDUCTOR-SMD
2703-004034	L6028	INDUCTOR-SMD
2703-004035	C1102	INDUCTOR-SMD
2703-004035	L1012	INDUCTOR-SMD
2703-004035	L1040	INDUCTOR-SMD
2703-004035	L6026	INDUCTOR-SMD
2703-004036	C1044	INDUCTOR-SMD
2703-004036	L1022	INDUCTOR-SMD
2703-004036	L1036	INDUCTOR-SMD
2703-004037	L1013	INDUCTOR-SMD
2703-004037	L1035	INDUCTOR-SMD
2703-004038	C1112	INDUCTOR-SMD
2703-004038	C203	INDUCTOR-SMD
2703-004038	L1033	INDUCTOR-SMD
2703-004038	L2008	INDUCTOR-SMD
2703-004038	L2027	INDUCTOR-SMD
2703-004038	L2028	INDUCTOR-SMD
2703-004038	L6016	INDUCTOR-SMD
2703-004299	L1174	INDUCTOR-SMD
2703-004299	L1205	INDUCTOR-SMD
2703-004328	L2009	INDUCTOR-SMD
2703-004328	L5020	INDUCTOR-SMD
2703-004362	L2021	INDUCTOR-SMD
2703-004363	L1177	INDUCTOR-SMD
2703-004364	L2016	INDUCTOR-SMD
2703-004366	C1045	INDUCTOR-SMD
2703-004366	C1056	INDUCTOR-SMD

## 5. MAIN Electrical Parts List

2703-004366	C214	INDUCTOR-SMD
2703-004366	L1027	INDUCTOR-SMD
2703-004366	L1028	INDUCTOR-SMD
2703-004367	C200	INDUCTOR-SMD
2703-004367	L2022	INDUCTOR-SMD
2703-004367	L5016	INDUCTOR-SMD
2703-004368	L1178	INDUCTOR-SMD
2703-004371	L1031	INDUCTOR-SMD
2703-004371	L5018	INDUCTOR-SMD
2703-004599	L4003	INDUCTOR-SMD
2703-004671	L6000	INDUCTOR-SMD
2703-004764	C1043	INDUCTOR-SMD
2703-004764	L1038	INDUCTOR-SMD
2703-004914	L2006	INDUCTOR-SMD
2703-004976	L134	INDUCTOR-SMD
2703-005116	L4002	INDUCTOR-SMD
2703-005116	L4004	INDUCTOR-SMD
2703-005116	L4007	INDUCTOR-SMD
2703-005340	L4000	INDUCTOR-SMD
2703-005340	L4001	INDUCTOR-SMD
2703-005340	L4005	INDUCTOR-SMD
2703-005366	L1016	INDUCTOR-SMD
2801-005406	OSC2000	CRYSTAL-SMD
2801-005455	OSC4000	CRYSTAL-SMD
2805-001098	OSC2002	OSCILLATOR-TCXO
2901-001647	F6000	FILTER-EMI SMD
2901-001647	F6002	FILTER-EMI SMD
2901-001674	F6001	FILTER-EMI SMD
2901-001674	F6005	FILTER-EMI SMD
2901-001786	F6003	FILTER-EMI/ESD
2901-001786	F6004	FILTER-EMI/ESD
2904-002143	F1001	FILTER-SAW
2904-002169	F2003	FILTER-SAW
2904-002169	U2006	FILTER-SAW
2904-002198	F1003	FILTER-SAW
2904-002257	F1000	FILTER-SAW
2904-002269	F201	FILTER-SAW
2904-002285	F1005	FILTER-SAW
2904-002314	F2002	FILTER-SAW

## 5. MAIN Electrical Parts List

2904-002326	F200	FILTER-SAW
2910-000352	F1004	DUPLEXER-SAW
2910-000365	F6013	DUPLEXER-SAW
2911-000379	U1033	DUPLEXER-FEM
2911-000382	U6057	DUPLEXER-FEM
3301-001438	L1002	BEAD-SMD
3301-001682	L5008	BEAD-SMD
3301-001682	L5010	BEAD-SMD
3301-001812	L6003	BEAD-SMD
3301-001885	L5003	BEAD-SMD
3301-001885	L5006	BEAD-SMD
3301-001885	L5013	BEAD-SMD
3301-001885	L5014	BEAD-SMD
3301-001885	U5000	BEAD-SMD
3301-001895	L1007	BEAD-SMD
3301-001895	L1017	BEAD-SMD
3301-001895	L2026	BEAD-SMD
3301-001917	L5004	BEAD-SMD
3301-001917	L5011	BEAD-SMD
3301-001917	L5012	BEAD-SMD
3301-002078	L5002	BEAD-SMD
3301-002078	L5005	BEAD-SMD
3301-002122	L6001	BEAD-SMD
3301-002228	L1006	BEAD-SMD
3301-002236	L1003	BEAD-SMD
3301-002237	L5007	BEAD-SMD
3301-002237	L5009	BEAD-SMD
3301-002238	L2020	BEAD-SMD
3301-002254	L4008	BEAD-SMD
3301-002254	L4009	BEAD-SMD
3404-001547	TAC2000	SWITCH-TACT
3404-001547	TAC2001	SWITCH-TACT
3404-001547	TAC2002	SWITCH-TACT
3705-001708	RFS1000	CONNECTOR-COAXIAL
3705-001708	U6034	CONNECTOR-COAXIAL
3705-001937	U6015	CONNECTOR-COAXIAL
3708-003254	HDC5001	CONNECTOR-FPC/FFC/PIC
3708-003254	HDC6001	CONNECTOR-FPC/FFC/PIC
3708-003254	SLC6000	CONNECTOR-FPC/FFC/PIC

## 5. MAIN Electrical Parts List

3708-003263	SLC4000	CONNECTOR-FPC/FFC/PIC
3709-001811	CD6000	CONNECTOR-CARD EDGE
3709-001813	SIM6000	CONNECTOR-CARD EDGE
3711-006843	HDC6002	HEADER-BOARD TO BOARD
3711-007173	U3002	HEADER-BOARD TO BOARD
3711-007295	HDC6000	HEADER-BOARD TO BOARD
3711-008347	HEA5000	HEADER-BOARD TO BOARD
3712-001501	ANT4000	CONNECTOR-TERMINAL
3712-001501	ANT4001	CONNECTOR-TERMINAL
3712-001621	ANT5000	CONNECTOR-TERMINAL
3712-001621	ANT5001	CONNECTOR-TERMINAL
3712-001626	CON5000	CONNECTOR-TERMINAL
3712-001626	CON5001	CONNECTOR-TERMINAL
3712-001634	ANT1000	CONNECTOR-TERMINAL
3712-001634	ANT1001	CONNECTOR-TERMINAL
3712-001634	ANT1003	CONNECTOR-TERMINAL
3712-001634	ANT2001	CONNECTOR-TERMINAL
3712-001634	ANT2002	CONNECTOR-TERMINAL
3712-001634	U6026	CONNECTOR-TERMINAL
3722-003700	IFC4000	JACK-MICRO USB
4709-002187	CPL100	COUPLER-DIRECTION
4709-002193	U1000	COUPLER-DIRECTION
4709-002284	F2001	FREQ-DISTRIBUTER
GH61-05260A	SUS2000	PLATE-SUS SMD SIM
GH62-00042A	CON1000	PAD GAP-SMD GASKET
GH62-00042A	CON1001	PAD GAP-SMD GASKET
GH62-00042A	CON1002	PAD GAP-SMD GASKET
GH62-00042A	CON1003	PAD GAP-SMD GASKET
GH62-00042A	CON1004	PAD GAP-SMD GASKET
GH63-06372A	SUS2001	SHIELD-SD SUS
GH80-03320A	R2009	SOLDER-CREAM
GH80-03320A	R2010	SOLDER-CREAM
GH80-03320A	R4023	SOLDER-CREAM
GH80-03320A	R4024	SOLDER-CREAM
GH80-03320A	R4026	SOLDER-CREAM
GH80-03320A	R4027	SOLDER-CREAM
GH80-03320A	R4028	SOLDER-CREAM
GH80-03320A	R4029	SOLDER-CREAM
GH80-03320A	R4035	SOLDER-CREAM

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.



## 5. MAIN Electrical Parts List

GH80-03320A	U3001	SOLDER-CREAM
GH80-03321A	R2001	SOLDER-CREAM
GH80-03321A	R2004	SOLDER-CREAM
GH80-03321A	R2007	SOLDER-CREAM
GH80-03321A	R2020	SOLDER-CREAM
GH80-03321A	R2021	SOLDER-CREAM
GH80-03321A	R2022	SOLDER-CREAM
GH80-03321A	R2023	SOLDER-CREAM
GH80-03321A	R2024	SOLDER-CREAM
GH80-03321A	R2025	SOLDER-CREAM
GH80-03321A	R2028	SOLDER-CREAM
GH80-03321A	R3022	SOLDER-CREAM
GH80-03321A	R4004	SOLDER-CREAM
GH80-03321A	R4021	SOLDER-CREAM
GH80-03321A	R4022	SOLDER-CREAM
GH80-03321A	R4031	SOLDER-CREAM
GH80-03321A	R5000	SOLDER-CREAM
GH80-03321A	R5001	SOLDER-CREAM
GH80-03321A	R5002	SOLDER-CREAM
GH80-03321A	R5012	SOLDER-CREAM
GH80-03321A	R5013	SOLDER-CREAM
GH80-03321A	R5014	SOLDER-CREAM
GH80-03321A	R6000	SOLDER-CREAM
GH80-03321A	R6024	SOLDER-CREAM

Please consult the GSPN website (Samsung Portal) for the most recent version of the product's part list.