

5. MAIN Electrical Parts List

Parts Code	Design LOC	Description
0401-001110	D8000	DIODE-SWITCHING
0404-001250	D6000	DIODE-SCHOTTKY
0406-001561	ZD3002,ZD4001,ZD6003	DIODE-TVS
0406-001561	ZD6005,ZD6021,ZD8000	DIODE-TVS
0406-001561	ZD8001	DIODE-TVS
0406-001728	ZD1000,ZD5000	DIODE-TVS
0406-001808	D6001	DIODE-TVS
0406-001809	ZD6017,ZD6018	DIODE-TVS
0505-003234	TR5001,TR5002	FET-SILICON
0601-003768	LED5000	LED
1001-001755	U5006	IC
1001-001911	U1008,U2005	IC
1001-001970	U1006,U2001,U2006	IC
1001-002062	U3002	IC
1001-002063	U1001	IC
1009-001076	U3006	IC
1201-003869	U3005	IC
1201-004029	U1000,U2011	IC
1201-004109	PAM2000	IC
1201-004200	U8000	IC
1201-004209	U1004	IC
1203-008251	U6001	IC
1203-008859	U7002	IC
1203-008865	U6000,U7001	IC
1203-008867	U3016,U7010	IC
1203-008872	U6004,U7009	IC
1203-009054	U6002	IC
1203-009220	U7000	IC
1203-009221	U7016	IC
1203-009240	U2000	IC
1203-009246	U5003	IC
1203-009247	U5004	IC
1203-009248	U5002	IC
1205-005106	U6003	IC
1205-005217	U7003	IC
1205-005731	U3021	IC
1205-005833	U2009	IC
1205-005881	U3004	IC

5. MAIN Electrical Parts List

1205-006106	U8001	IC
1205-006111	UCP400	IC
1209-002450	U3003	IC
1209-002513	U3009	IC
1209-002628	U3000	IC
1209-002629	U3001	IC
1404-001724	TH2000,TH4000	THERMISTOR
1404-001724	THM3000	THERMISTOR
1405-001404	VR6000	VARISTOR
2007-003015	ZD6015,ZD6016	R-CHIP
2007-007099	R5004	R-CHIP
2007-007142	R7003	R-CHIP
2007-007313	R5001	R-CHIP
2007-007741	R3002,R3006,R3007	R-CHIP
2007-007741	R4007,R4010,R5008	R-CHIP
2007-007741	R5016,R5025,R5030	R-CHIP
2007-007741	R6009	R-CHIP
2007-008056	R1006,R1007	R-CHIP
2007-008167	R5000	R-CHIP
2007-008263	R4006	R-CHIP
2007-008420	R5019,R7001	R-CHIP
2007-008483	R5023	R-CHIP
2007-008516	C6037	R-CHIP
2007-008531	R7000,R7004	R-CHIP
2007-008587	R8040	R-CHIP
2007-008588	R3012,R3013	R-CHIP
2007-008766	R4016	R-CHIP
2007-008785	R1005	R-CHIP
2007-008788	R7005	R-CHIP
2007-008798	R8000,R8001	R-CHIP
2007-008808	R7006	R-CHIP
2007-009111	R3001,R5006	R-CHIP
2007-009157	R5027,R6004,R6005	R-CHIP
2007-009171	R3008	R-CHIP
2007-009212	R3005,R4021,R4022	R-CHIP
2007-009212	R4042,R5021,R5022	R-CHIP
2007-009212	R6018	R-CHIP
2007-009314	R6001	R-CHIP
2007-009315	R6007	R-CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2007-009352	R6017	R-CHIP
2007-009408	R4008,R4009,R4013	R-CHIP
2007-009408	R4014,R4025,R4026	R-CHIP
2007-009408	R4027,R4028,R4031	R-CHIP
2007-009408	R4032,R4033,R4034	R-CHIP
2007-009408	R4037,R4038,R4040	R-CHIP
2007-009408	R4041,R6016,R8008	R-CHIP
2007-009408	R8011	R-CHIP
2007-009766	R7002	R-CHIP
2007-009801	R4015	R-CHIP
2007-009805	R1000,R1001,R1002	R-CHIP
2007-009805	R1004,R2000	R-CHIP
2007-009807	R6006	R-CHIP
2007-009920	R4002,R6002,R6003	R-CHIP
2007-009954	R6008	R-CHIP
2007-009969	R3016,R3021,R4001	R-CHIP
2007-010202	R5002	R-CHIP
2007-010233	C4094	R-CHIP
2007-011043	R4000	R-CHIP
2203-000386	C8153	C-CERAMIC,CHIP
2203-001153	C8045	C-CERAMIC,CHIP
2203-001239	C3082,C3086,C3089	C-CERAMIC,CHIP
2203-005446	C3087	C-CERAMIC,CHIP
2203-005682	C1006,C1007,C1016	C-CERAMIC,CHIP
2203-005682	C2031,C2063,C2073	C-CERAMIC,CHIP
2203-005682	C2075,C2081,C2082	C-CERAMIC,CHIP
2203-005682	C2087,C2115,C2122	C-CERAMIC,CHIP
2203-005682	C3061,C3062,C3063	C-CERAMIC,CHIP
2203-005682	C7004,L1001,L1003	C-CERAMIC,CHIP
2203-005682	L1017,L2043	C-CERAMIC,CHIP
2203-005725	C7040,L1032	C-CERAMIC,CHIP
2203-005729	C8013,C8022,C8039	C-CERAMIC,CHIP
2203-005729	L3001	C-CERAMIC,CHIP
2203-005731	C3001,C3007,C3008	C-CERAMIC,CHIP
2203-005731	C8028,C8029,C8031	C-CERAMIC,CHIP
2203-005732	C8038	C-CERAMIC,CHIP
2203-005736	C1010,C1023,C1035	C-CERAMIC,CHIP
2203-005736	C1054,C1055,C1124	C-CERAMIC,CHIP
2203-005736	C1125,C1126,C1129	C-CERAMIC,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2203-005736	C1134,C1135,C2001	C-CERAMIC,CHIP
2203-005736	C2024,C2038,C2043	C-CERAMIC,CHIP
2203-005736	C2045,C2058,C2067	C-CERAMIC,CHIP
2203-005736	C2068,C2084,C2092	C-CERAMIC,CHIP
2203-005736	C2094,C2123,C2124	C-CERAMIC,CHIP
2203-005736	C3006,C3024,C3039	C-CERAMIC,CHIP
2203-005736	C3044,C3045,C3047	C-CERAMIC,CHIP
2203-005736	C3048,C3058,L1023	C-CERAMIC,CHIP
2203-005736	L1030,L1080,L2000	C-CERAMIC,CHIP
2203-005736	L2003,L2006,L2018	C-CERAMIC,CHIP
2203-005736	L2020,L2023,L2031	C-CERAMIC,CHIP
2203-005736	L2039,L2040,L2046	C-CERAMIC,CHIP
2203-005736	L2048,L2050,L2062	C-CERAMIC,CHIP
2203-005736	L2067,L3003	C-CERAMIC,CHIP
2203-005740	C8027,C8030	C-CERAMIC,CHIP
2203-005777	C1051,C1052,C1069	C-CERAMIC,CHIP
2203-005777	C2046,C2090,C2100	C-CERAMIC,CHIP
2203-005777	C3055	C-CERAMIC,CHIP
2203-005789	C1036,C1062,C1066	C-CERAMIC,CHIP
2203-005789	C2028,C2033,C2069	C-CERAMIC,CHIP
2203-005789	C2091,C2099,C2109	C-CERAMIC,CHIP
2203-005789	C2110	C-CERAMIC,CHIP
2203-005792	C1046	C-CERAMIC,CHIP
2203-005806	C2083	C-CERAMIC,CHIP
2203-006120	C6047,C6048	C-CERAMIC,CHIP
2203-006123	C1020	C-CERAMIC,CHIP
2203-006194	C6019	C-CERAMIC,CHIP
2203-006305	C2066,C3009,C3040	C-CERAMIC,CHIP
2203-006305	C7009,C7010,C7024	C-CERAMIC,CHIP
2203-006318	L1035	C-CERAMIC,CHIP
2203-006400	C3083,C3085,C5095	C-CERAMIC,CHIP
2203-006400	C6065	C-CERAMIC,CHIP
2203-006410	C1050	C-CERAMIC,CHIP
2203-006423	C1004,C1043,C2003	C-CERAMIC,CHIP
2203-006423	C2004,C2006,C2007	C-CERAMIC,CHIP
2203-006423	C2008,C2009,C2010	C-CERAMIC,CHIP
2203-006423	C2011,C2012,C2013	C-CERAMIC,CHIP
2203-006423	C2015,C2016,C2017	C-CERAMIC,CHIP
2203-006423	C2019,C2020,C2021	C-CERAMIC,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2203-006423	C2022,C2061,C3059	C-CERAMIC,CHIP
2203-006423	C3060,C5115,C6033	C-CERAMIC,CHIP
2203-006423	C7025,C8000,C8007	C-CERAMIC,CHIP
2203-006423	C8009,C8023,C8024	C-CERAMIC,CHIP
2203-006423	C8025,C8034,C8044	C-CERAMIC,CHIP
2203-006556	C1039,C1042,C1045	C-CERAMIC,CHIP
2203-006556	C2074	C-CERAMIC,CHIP
2203-006604	C3020,C3041	C-CERAMIC,CHIP
2203-006611	C1136,C3010	C-CERAMIC,CHIP
2203-006665	L1027,L1051	C-CERAMIC,CHIP
2203-006674	C2088	C-CERAMIC,CHIP
2203-006839	C1000,C1005,C1114	C-CERAMIC,CHIP
2203-006839	C1123,C2044,C2060	C-CERAMIC,CHIP
2203-006839	C3074,C3081,C4020	C-CERAMIC,CHIP
2203-006839	C4021,C4086,C4095	C-CERAMIC,CHIP
2203-006839	C4096,C5022,C5054	C-CERAMIC,CHIP
2203-006839	C5100,C8006,C8050	C-CERAMIC,CHIP
2203-006844	C3038,C6077	C-CERAMIC,CHIP
2203-006846	C1076	C-CERAMIC,CHIP
2203-006979	C3019,C3023,C3025	C-CERAMIC,CHIP
2203-006979	C3026,C3027,C3033	C-CERAMIC,CHIP
2203-006979	C3034	C-CERAMIC,CHIP
2203-007143	C6043	C-CERAMIC,CHIP
2203-007210	C4029,C4030,C4058	C-CERAMIC,CHIP
2203-007210	C6003,C6004,C6005	C-CERAMIC,CHIP
2203-007210	C6016,C6017,C8004	C-CERAMIC,CHIP
2203-007317	C2002,C3002,C3014	C-CERAMIC,CHIP
2203-007317	C3015,C3056,C6011	C-CERAMIC,CHIP
2203-007317	C6012,C7012	C-CERAMIC,CHIP
2203-007391	C3036,C3076,C6036	C-CERAMIC,CHIP
2203-007391	C6039,C8011,C8012	C-CERAMIC,CHIP
2203-007391	C8019	C-CERAMIC,CHIP
2203-007393	C2005,C2014,C2018	C-CERAMIC,CHIP
2203-007393	C2023,C2059,C3017	C-CERAMIC,CHIP
2203-007393	C3028,C3031,C3037	C-CERAMIC,CHIP
2203-007393	C5074,C5076,C5077	C-CERAMIC,CHIP
2203-007393	C5078,C5105,C5106	C-CERAMIC,CHIP
2203-007393	C5120,C5124,C5126	C-CERAMIC,CHIP
2203-007393	C6013,C6015,C6032	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-007393	C6073,C6074,C7016	C-CERAMIC,CHIP
2203-007393	C7017,C7020,C7021	C-CERAMIC,CHIP
2203-007393	C7022,C7029,C8001	C-CERAMIC,CHIP
2203-007456	C2056,C5083	C-CERAMIC,CHIP
2203-007474	C5110,C5111,C5129	C-CERAMIC,CHIP
2203-007474	C7026	C-CERAMIC,CHIP
2203-007544	C3042,C3043	C-CERAMIC,CHIP
2203-007781	C8005	C-CERAMIC,CHIP
2203-007796	C3013,C3018,C3021	C-CERAMIC,CHIP
2203-007796	C3022,C3030,C3032	C-CERAMIC,CHIP
2203-007796	C3070,C3071,C4000	C-CERAMIC,CHIP
2203-007796	C4001,C4002,C4003	C-CERAMIC,CHIP
2203-007796	C4004,C4006,C4007	C-CERAMIC,CHIP
2203-007796	C4008,C4009,C4010	C-CERAMIC,CHIP
2203-007796	C4011,C4012,C4013	C-CERAMIC,CHIP
2203-007796	C4014,C4016,C4017	C-CERAMIC,CHIP
2203-007796	C4018,C4022,C4024	C-CERAMIC,CHIP
2203-007796	C4025,C4026,C4027	C-CERAMIC,CHIP
2203-007796	C4028,C4032,C4036	C-CERAMIC,CHIP
2203-007796	C4038,C4039,C4042	C-CERAMIC,CHIP
2203-007796	C4043,C4044,C4045	C-CERAMIC,CHIP
2203-007796	C4047,C4049,C4050	C-CERAMIC,CHIP
2203-007796	C4051,C4052,C4054	C-CERAMIC,CHIP
2203-007796	C4055,C4056,C4057	C-CERAMIC,CHIP
2203-007796	C4059,C4060,C4061	C-CERAMIC,CHIP
2203-007796	C4062,C4068,C4069	C-CERAMIC,CHIP
2203-007796	C4070,C4071,C4072	C-CERAMIC,CHIP
2203-007796	C4076,C4097,C4098	C-CERAMIC,CHIP
2203-007796	C5068,C5069,C5070	C-CERAMIC,CHIP
2203-007796	C5071,C5072,C5073	C-CERAMIC,CHIP
2203-007796	C5075,C5079,C5092	C-CERAMIC,CHIP
2203-007796	C5104,C5107,C5108	C-CERAMIC,CHIP
2203-007796	C5109,C5112,C5113	C-CERAMIC,CHIP
2203-007796	C5114,C5116,C5122	C-CERAMIC,CHIP
2203-007796	C5123,C5125,C5128	C-CERAMIC,CHIP
2203-007796	C6000,C6001,C6006	C-CERAMIC,CHIP
2203-007796	C6007,C6008,C6009	C-CERAMIC,CHIP
2203-007796	C6014,C6020,C6021	C-CERAMIC,CHIP
2203-007796	C6025,C6026,C6028	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-007796	C6029,C6030,C6031	C-CERAMIC,CHIP
2203-007796	C6049,C6050,C6076	C-CERAMIC,CHIP
2203-007796	C7001,C7002,C7003	C-CERAMIC,CHIP
2203-007796	C7007,C7013,C7014	C-CERAMIC,CHIP
2203-007796	C7018,C7019,C7027	C-CERAMIC,CHIP
2203-007796	C7036,C8008,C8015	C-CERAMIC,CHIP
2203-008095	C3069,C4063,C4064	C-CERAMIC,CHIP
2203-008097	C1044,C5019	C-CERAMIC,CHIP
2203-008126	C3077,C3080	C-CERAMIC,CHIP
2203-008177	C6072	C-CERAMIC,CHIP
2203-008242	C3035,C6035,C6041	C-CERAMIC,CHIP
2203-008242	C6060,C7005	C-CERAMIC,CHIP
2203-008572	C5132,C5133	C-CERAMIC,CHIP
2203-008654	C6045,C6068,L5005	C-CERAMIC,CHIP
2203-008749	C5055	C-CERAMIC,CHIP
2203-008860	C2080,C3072,C4015	C-CERAMIC,CHIP
2203-008860	C4019,C4023,C5002	C-CERAMIC,CHIP
2203-008860	C5004,C5021,C5023	C-CERAMIC,CHIP
2203-008860	C5025,C5027,C5035	C-CERAMIC,CHIP
2203-008860	C5040,C5042,C5044	C-CERAMIC,CHIP
2203-008860	C5045,C5046,C5047	C-CERAMIC,CHIP
2203-008860	C5050,C5053,C5081	C-CERAMIC,CHIP
2203-008860	C5084,C5086,C5088	C-CERAMIC,CHIP
2203-008860	C5097,C5098,C5101	C-CERAMIC,CHIP
2203-008860	C6051,C6056,C6057	C-CERAMIC,CHIP
2203-008860	C6075,C6078,C7038	C-CERAMIC,CHIP
2203-008860	C7058,C7059,C8016	C-CERAMIC,CHIP
2203-008860	C8021,C8026	C-CERAMIC,CHIP
2203-008876	C1041,C2076,C3073	C-CERAMIC,CHIP
2203-008876	C3075,C3078,C3079	C-CERAMIC,CHIP
2203-008876	C6042,C6044,C6058	C-CERAMIC,CHIP
2203-008876	C6067,C7028,C7030	C-CERAMIC,CHIP
2203-008876	C7031,C7033,C7055	C-CERAMIC,CHIP
2203-008876	C7056,C8003,C8035	C-CERAMIC,CHIP
2203-008916	C4033,C4034,C4040	C-CERAMIC,CHIP
2203-008916	C4041,C4066,C4067	C-CERAMIC,CHIP
2203-008916	C6022	C-CERAMIC,CHIP
2203-009167	C3084,C3088	C-CERAMIC,CHIP
2203-009444	C8041	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-009618	C5030,C5031,C5034	C-CERAMIC,CHIP
2203-009618	C5037,C7061,C8042	C-CERAMIC,CHIP
2203-009618	C8052	C-CERAMIC,CHIP
2203-009733	C1047,C2057,C3029	C-CERAMIC,CHIP
2203-009733	C5000,C5026,C5028	C-CERAMIC,CHIP
2203-009733	C5032,C5033,C5036	C-CERAMIC,CHIP
2203-009733	C5038,C5043,C5049	C-CERAMIC,CHIP
2203-009733	C5052,C5056,C5064	C-CERAMIC,CHIP
2203-009733	C5065,C5066,C5085	C-CERAMIC,CHIP
2203-009733	C5090,C5096,C5103	C-CERAMIC,CHIP
2203-009733	C7000,C7006,C7008	C-CERAMIC,CHIP
2203-009733	C7011,C7015,C7035	C-CERAMIC,CHIP
2203-009733	C7042,C7062,C7063	C-CERAMIC,CHIP
2203-009733	C7064,C7065,C7066	C-CERAMIC,CHIP
2203-009733	C7067,C7068,C7071	C-CERAMIC,CHIP
2203-009733	C7072,C7073,C7074	C-CERAMIC,CHIP
2203-009733	C7075,C7076	C-CERAMIC,CHIP
2203-009735	C4073,C4074	C-CERAMIC,CHIP
2203-009787	C5039,C5067	C-CERAMIC,CHIP
2203-009859	C7032	C-CERAMIC,CHIP
2203-010085	C4075,C5087,C5094	C-CERAMIC,CHIP
2703-002309	L8017,L8018	INDUCTOR-SMD
2703-002649	C2089,L1002,L2019	INDUCTOR-SMD
2703-002901	C1032,C3053,L1015	INDUCTOR-SMD
2703-002903	L1012,L1018,L3006	INDUCTOR-SMD
2703-002903	L3013	INDUCTOR-SMD
2703-002951	C1028,C2098,L1050	INDUCTOR-SMD
2703-002953	C3049	INDUCTOR-SMD
2703-002959	L3009,L3016,L8016	INDUCTOR-SMD
2703-002961	L8010	INDUCTOR-SMD
2703-002999	C2049	INDUCTOR-SMD
2703-004000	L1022,L1041	INDUCTOR-SMD
2703-004012	C2032,C2095,L1039	INDUCTOR-SMD
2703-004012	L2010,L2034,L2064	INDUCTOR-SMD
2703-004013	L1008,L2045,L2054	INDUCTOR-SMD
2703-004014	L1009	INDUCTOR-SMD
2703-004018	L2053,L2057	INDUCTOR-SMD
2703-004034	L1028	INDUCTOR-SMD
2703-004036	L2002,L2009	INDUCTOR-SMD

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2703-004038	L1007,L2001,L2004	INDUCTOR-SMD
2703-004038	L2021,L2024	INDUCTOR-SMD
2703-004286	C3046,C3050,L1037	INDUCTOR-SMD
2703-004286	L1058,L2028,L2029	INDUCTOR-SMD
2703-004286	L2035,L2042,L3014	INDUCTOR-SMD
2703-004286	L2051	INDUCTOR-SMD
2703-004287	C1033,C1137,L1005	INDUCTOR-SMD
2703-004287	L1042,L1043,L1045	INDUCTOR-SMD
2703-004287	L1053,L2032,L2038	INDUCTOR-SMD
2703-004287	L3007,L3008	INDUCTOR-SMD
2703-004288	C3051,L2005,L2026	INDUCTOR-SMD
2703-004288	L2049,L2061	INDUCTOR-SMD
2703-004289	L2047	INDUCTOR-SMD
2703-004295	L1036	INDUCTOR-SMD
2703-004300	L1044	INDUCTOR-SMD
2703-004302	C2085,L1040,L3015	INDUCTOR-SMD
2703-004317	C3052,L3000	INDUCTOR-SMD
2703-004328	C3000	INDUCTOR-SMD
2703-004362	L2016	INDUCTOR-SMD
2703-004703	L2007,L2014,L6001	INDUCTOR-SMD
2703-004763	L2065	INDUCTOR-SMD
2703-004853	L3010	INDUCTOR-SMD
2703-004862	L1038,L2058,L2063	INDUCTOR-SMD
2703-004862	L3002	INDUCTOR-SMD
2703-005058	L2017	INDUCTOR-SMD
2703-005066	L2025	INDUCTOR-SMD
2703-005088	L2030	INDUCTOR-SMD
2703-005295	L2013	INDUCTOR-SMD
2703-005418	L7006	INDUCTOR-SMD
2703-005419	L7007	INDUCTOR-SMD
2703-005505	L8000	INDUCTOR-SMD
2703-005555	L3017,L3018	INDUCTOR-SMD
2703-005581	L5007	INDUCTOR-SMD
2703-005660	L5000,L5002,L5003	INDUCTOR-SMD
2703-005660	L5006,L5008,L5009	INDUCTOR-SMD
2703-005660	L5010,L5011,L5016	INDUCTOR-SMD
2703-005660	L5020,L5022,L5023	INDUCTOR-SMD
2703-005731	L7009	INDUCTOR-SMD
2703-005738	L5019	INDUCTOR-SMD

5. MAIN Electrical Parts List

2801-005506	OSC5000	CRYSTAL-UNIT
2901-001690	C4091	FILTER-EMI SMD
2903-001576	F3000	FILTER-CERAMIC
2904-002134	F1000	FILTER-SAW
2904-002198	F2006	FILTER-SAW
2904-002339	F2002	FILTER-SAW
2904-002350	F2003	FILTER-SAW
2904-002355	F3002,F3003	FILTER-SAW
2904-002381	F3009	FILTER-SAW
2904-002397	F2004,F2005	FILTER-SAW
2910-000390	F2008	FILTER-SAW
2911-000435	U2002	FILTER-SAW
2911-000452	U1009	FILTER-SAW
3003-001237	MIC8000	MIC-CONDENSOR
3301-001534	L8002,L8003	CORE-FERRITE BEAD
3301-001885	L8019	CORE-FERRITE BEAD
3301-002078	L3810,L3811	CORE-FERRITE BEAD
3301-002085	L8001,L8005	CORE-FERRITE BEAD
3301-002223	L7000,L7001,L7002	CORE-FERRITE BEAD
3301-002223	L7003	CORE-FERRITE BEAD
3301-002235	L8012	CORE-FERRITE BEAD
3301-002237	L1000,L8004	CORE-FERRITE BEAD
3301-002238	L3011,L3012,L5001	CORE-FERRITE BEAD
3301-002312	L7005,L7008,L7010	CORE-FERRITE BEAD
3301-002356	L8007,L8008	CORE-FERRITE BEAD
3705-001708	RFS1001	CONNECTOR-COAXIAL
3705-001937	RFS1000	CONNECTOR-COAXIAL
3709-001932	SIM4UP	CONNECTOR-CARD EDGE
3709-001933	SIM1	CONNECTOR-CARD EDGE
3709-001934	SIM2,SIM3	CONNECTOR-CARD EDGE
3710-004285	HDC6000	CONNECTOR-SOCKET
3711-007107	HDC7003	CONNECTOR-HEADER
3711-008508	HDC7000	CONNECTOR-HEADER
3711-008511	HDC7001	CONNECTOR-HEADER
3711-008847	HDC5000	CONNECTOR-HEADER
3711-008931	HDC7002	CONNECTOR-HEADER
3712-001604	ANT1005,ANT2000	CONNECTOR
3712-001604	ANT2001,ANT2002	CONNECTOR
3712-001604	ANT3002,ANT3011	CONNECTOR

5. MAIN Electrical Parts List

3712-001621	ANT3003,ANT3004	CONNECTOR
3712-001621	ANT3006,ANT3007	CONNECTOR
3712-001626	ANT1000,ANT1001	CONNECTOR
3712-001626	ANT1002,ANT1003	CONNECTOR
3712-001626	ANT1004,ANT3000	CONNECTOR
3712-001626	ANT3010	CONNECTOR
3712-001633	ANT8100,ANT8101	CONNECTOR
3712-001666	ANT8000,ANT8001	CONNECTOR
4709-002196	F2001	RF-MODULE
4709-002226	F1004	RF-MODULE
4709-002285	F3001	RF-MODULE
4709-002484	F2000	RF-MODULE
4709-002589	F1002,F1005	RF-MODULE
GH62-00042A	GAS6000	SHIELDCAN
GH63-17097A	SC6000	SHIELDCAN
GH63-17098A	SC6006	SHIELDCAN
GH63-17099A	SC6001	SHIELDCAN
GH63-17100A	SC6002	SHIELDCAN
GH63-17106A	SC6005	SHIELDCAN
GH81-16836A	SC6000SP	TAPE-SHIELDCAN
GH81-16835A	SC6006SP	ATAPE-SHIELDCAN
1108-000660	UME6000	MEMORY

Please consult the GSPN website (Samsung Portal) for the most recent version of the product's part list.