

## 5. MAIN Electrical Parts List

### [SM-C900F]

Parts Code	Design Loc	Description
0202-002125	R4031,R4045	PB-SHORT-0603
0404-001250	D5000,D6001	DIODE-SCHOTTKY
0404-001782	D3000	DIODE-SCHOTTKY
0406-001413	ZD8000,ZD8001	DIODE-TVS
0406-001465	ZD6018,ZD6019,ZD6022	DIODE-TVS
0406-001465	ZD6023	DIODE-TVS
0406-001505	D6000	DIODE-TVS
0406-001592	ZD3000,ZD3001,ZD3002	DIODE-TVS
0406-001592	ZD3003,ZD3004,ZD3005	DIODE-TVS
0406-001592	ZD3006,ZD3007,ZD3008	DIODE-TVS
0406-001592	ZD6020,ZD6021,ZD7000	DIODE-TVS
0406-001592	ZD7001,ZD7002,ZD7003	DIODE-TVS
0406-001592	ZD7004,ZD7005,ZD7006	DIODE-TVS
0406-001645	ZD6027	DIODE-TVS
0406-001675	ZD5001	DIODE-TVS
0406-001682	ZD6031,ZD6032	DIODE-TVS
0406-001690	ZD6011,ZD6012,ZD6013	DIODE-TVS
0406-001690	ZD6014,ZD6015	DIODE-TVS
0406-001709	ZD6025,ZD6026	DIODE-TVS
0406-001717	ZD6010	DIODE-TVS
0406-001763	ZD6000,ZD6001,ZD6002	DIODE-TVS
0406-001763	ZD6003,ZD6004,ZD6005	DIODE-TVS
0406-001763	ZD6006,ZD6007,ZD6008	DIODE-TVS
0406-001763	ZD6009	DIODE-TVS
0505-002088	TR5001,TR7000,U8033	FET-SILICON
0505-002388	TR5000	FET-SILICON
0601-001905	LED3000	LED
0601-003575	LED5000	LED
0903-002171	U3007	IC
1001-001655	U5003,U5004,U5006	IC
1001-001849	U1001	IC
1001-001972	U1009,U2004,U2005	IC
1001-001992	U1011	IC
1001-002001	U1007	IC
1003-002415	U6001	IC
1107-002504	UME6000	IC-FLASH
1201-003786	U3005	IC

## 5. MAIN Electrical Parts List

1201-003964	U8001,U8013	IC
1201-003974	F1009	IC
1201-003975	F1007	IC
1201-003990	U1017	IC
1201-004091	PAM1000	IC
1201-004100	U1013	IC
1203-008011	U4001	IC
1203-008249	U3001	IC
1203-008250	U3000,U3009,U3010	IC
1203-008250	U5012,U5019	IC
1203-008251	U5013,U6004,U6005	IC
1203-008326	U5011	IC
1203-008379	U2000	IC
1203-008395	U5018	IC
1203-008459	U5016	IC
1203-008603	U3012	IC
1203-008689	U5008	IC
1203-008700	U5001	IC
1203-008717	U7002	IC
1203-008819	U5007	IC
1203-008830	U6003	IC
1203-008858	U8002	IC
1203-008859	U8000	IC
1203-008860	U7000	IC
1205-005037	U4000	IC
1205-005106	U3008	IC
1205-005262	U3002	IC
1205-005493	U1015,U1016	IC
1205-005652	U6002	IC
1205-005680	U3011	IC
1205-005693	U8003	IC
1205-005705	UCP400	IC
1209-002344	U3006	IC
1209-002400	U3003	IC
1209-002401	U3014	IC
1404-001724	TH2000,TH4000,TH5000	THERMISTOR
1404-001724	TH5001	THERMISTOR
1405-001395	C3002,V1000,V1001	VARISTOR
1405-001395	V3000,V3001,V3002	VARISTOR

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

## 5. MAIN Electrical Parts List

1405-001395	V3003,V3004,VR2000	VARISTOR
1405-001395	VR2001	VARISTOR
1405-001398	VR2003	VARISTOR
1405-001404	V6000,V6001,V6002	VARISTOR
1405-001404	VR7000	VARISTOR
1405-001410	V6003	VARISTOR
2007-003015	R6040,R6041	R-CHIP
2007-007107	R2000	R-CHIP
2007-007193	R6043,R6044	R-CHIP
2007-007313	R4010	R-CHIP
2007-007741	R3000,R3015,R4002	R-CHIP
2007-007741	R4025,R4026,R4046	R-CHIP
2007-007741	R5041,R6003,R6005	R-CHIP
2007-007741	R6007,R6010,R6012	R-CHIP
2007-007741	R6016,R6030,R7006	R-CHIP
2007-007942	R6014	R-CHIP
2007-008053	R3014	R-CHIP
2007-008210	R6015	R-CHIP
2007-008420	R4000,R5007,R5013	R-CHIP
2007-008420	U5002	R-CHIP
2007-008531	R3025	R-CHIP
2007-008579	R1005,R1006	R-CHIP
2007-008774	R3011,R3012,R3013	R-CHIP
2007-008774	R3027,R3028,R6013	R-CHIP
2007-008800	R4041,R4042	R-CHIP
2007-009111	R3001,R6011	R-CHIP
2007-009155	R5008,R5016	R-CHIP
2007-009157	R3003,R3005,R4027	R-CHIP
2007-009157	R5000,R5001,R5018	R-CHIP
2007-009157	R5019,R5020,R5030	R-CHIP
2007-009157	R6019,R6020,R6021	R-CHIP
2007-009158	R5048	R-CHIP
2007-009182	R6028	R-CHIP
2007-009212	R3002,R6000,R6001	R-CHIP
2007-009212	R6009,R6017,R6018	R-CHIP
2007-009212	R6031,R8008	R-CHIP
2007-009223	R5017	R-CHIP
2007-009233	R5034	R-CHIP
2007-009315	R5010,R6045,R6046	R-CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

## 5. MAIN Electrical Parts List

2007-009315	R6047,R6048,R6049	R-CHIP
2007-009315	R6050,R6051,R6052	R-CHIP
2007-009315	R6053,R6054,R6055	R-CHIP
2007-009352	R3006,R3007,R4015	R-CHIP
2007-009352	R4030,R7005	R-CHIP
2007-009408	R3008,R3009,R3019	R-CHIP
2007-009408	R3020,R3021,R3022	R-CHIP
2007-009408	R4011,R4012,R4013	R-CHIP
2007-009408	R4014,R4016,R4017	R-CHIP
2007-009408	R4018,R4019,R4020	R-CHIP
2007-009408	R4021,R4023,R4024	R-CHIP
2007-009408	R4028,R4029,R4035	R-CHIP
2007-009408	R4036	R-CHIP
2007-009766	R5033	R-CHIP
2007-009801	R7002	R-CHIP
2007-009805	R1001,R1003,R1004	R-CHIP
2007-009805	R3004	R-CHIP
2007-009866	R5002,R5012	R-CHIP
2007-009920	R4003,R4004,R4005	R-CHIP
2007-009920	R4006,R4007,R4008	R-CHIP
2007-009969	R8009	R-CHIP
2007-010029	R6024,R6026	R-CHIP
2007-010202	R3016,R6022	R-CHIP
2007-010685	R4001,R6002,R6004	R-CHIP
2007-010856	R5031	R-CHIP
2007-011043	R4009	R-CHIP
2007-011648	R6059	R-CHIP
2203-000627	C3082,C3086,C3091	C-CERAMIC,CHIP
2203-000725	C6018	C-CERAMIC,CHIP
2203-000854	C6026	C-CERAMIC,CHIP
2203-001153	C3083,C3089	C-CERAMIC,CHIP
2203-001221	C3084,C3088	C-CERAMIC,CHIP
2203-001239	C3085	C-CERAMIC,CHIP
2203-005344	C5058	C-CERAMIC,CHIP
2203-005682	C1014,C1036,C1044	C-CERAMIC,CHIP
2203-005682	C1047,C1056,C1078	C-CERAMIC,CHIP
2203-005682	C1092,C1099,C1101	C-CERAMIC,CHIP
2203-005682	C1115,C1116,C1129	C-CERAMIC,CHIP
2203-005682	C1145,C1149,C1152	C-CERAMIC,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

## 5. MAIN Electrical Parts List

2203-005682	C2019,C2023,C2024	C-CERAMIC,CHIP
2203-005682	C2032,C2038,C2040	C-CERAMIC,CHIP
2203-005682	C3050,C3051,C3077	C-CERAMIC,CHIP
2203-005682	C3095,C6001,C6006	C-CERAMIC,CHIP
2203-005682	C6010,C7010,C7012	C-CERAMIC,CHIP
2203-005682	C7014,L1056,L2014	C-CERAMIC,CHIP
2203-005682	L2016	C-CERAMIC,CHIP
2203-005717	C1084,C2035	C-CERAMIC,CHIP
2203-005719	C1059,C7032,C7033	C-CERAMIC,CHIP
2203-005725	C1124,C1130,C1131	C-CERAMIC,CHIP
2203-005725	C1134,C1143,C1147	C-CERAMIC,CHIP
2203-005725	L1000	C-CERAMIC,CHIP
2203-005727	C3029	C-CERAMIC,CHIP
2203-005731	C3025,C3035,C3038	C-CERAMIC,CHIP
2203-005731	C3113,C3116,C6044	C-CERAMIC,CHIP
2203-005731	C6045,C6054,C8044	C-CERAMIC,CHIP
2203-005732	C5095,C6030,C6031	C-CERAMIC,CHIP
2203-005732	C6055,C8011,C8025	C-CERAMIC,CHIP
2203-005732	C8037,C8043,C8049	C-CERAMIC,CHIP
2203-005734	C3114,C3119,C3120	C-CERAMIC,CHIP
2203-005734	C5023,C5064,C5086	C-CERAMIC,CHIP
2203-005734	C5087,C7034,C7035	C-CERAMIC,CHIP
2203-005734	C7036,C7037,C7038	C-CERAMIC,CHIP
2203-005736	C1000,C1007,C1020	C-CERAMIC,CHIP
2203-005736	C1023,C1026,C1027	C-CERAMIC,CHIP
2203-005736	C1032,C1042,C1051	C-CERAMIC,CHIP
2203-005736	C1060,C1067,C1068	C-CERAMIC,CHIP
2203-005736	C1072,C1073,C1076	C-CERAMIC,CHIP
2203-005736	C1085,C1088,C1091	C-CERAMIC,CHIP
2203-005736	C1093,C1141,C1142	C-CERAMIC,CHIP
2203-005736	C2005,C2009,C2012	C-CERAMIC,CHIP
2203-005736	C2016,C2017,C2018	C-CERAMIC,CHIP
2203-005736	C2025,C2026,C2028	C-CERAMIC,CHIP
2203-005736	C2034,C3009,C3011	C-CERAMIC,CHIP
2203-005736	C3012,C3014,C3015	C-CERAMIC,CHIP
2203-005736	C3031,C3033,C3042	C-CERAMIC,CHIP
2203-005736	C3052,C3058,C3101	C-CERAMIC,CHIP
2203-005736	L1027,L2011,L3012	C-CERAMIC,CHIP
2203-005777	C1034,C1035,C1045	C-CERAMIC,CHIP

## 5. MAIN Electrical Parts List

2203-005777	C1049,C1057,C2021	C-CERAMIC,CHIP
2203-005777	C3022,L3016	C-CERAMIC,CHIP
2203-005779	C3030	C-CERAMIC,CHIP
2203-005789	C1052,C1061,C1080	C-CERAMIC,CHIP
2203-005789	C1108,C1125,U1003	C-CERAMIC,CHIP
2203-005789	U1006,U8035	C-CERAMIC,CHIP
2203-005792	C1021,C1024,C1033	C-CERAMIC,CHIP
2203-005792	C2015	C-CERAMIC,CHIP
2203-005806	C4103,C5021,C5061	C-CERAMIC,CHIP
2203-006123	C1019	C-CERAMIC,CHIP
2203-006137	C3020	C-CERAMIC,CHIP
2203-006194	C3005,C3006,C3007	C-CERAMIC,CHIP
2203-006194	C3010,C3013,C3016	C-CERAMIC,CHIP
2203-006305	C5024,C5025,U1012	C-CERAMIC,CHIP
2203-006318	C3045,C3117	C-CERAMIC,CHIP
2203-006348	C6023	C-CERAMIC,CHIP
2203-006399	C3003,C5032,C8060	C-CERAMIC,CHIP
2203-006399	C8061	C-CERAMIC,CHIP
2203-006400	C1095,C1096,C3036	C-CERAMIC,CHIP
2203-006400	C3081	C-CERAMIC,CHIP
2203-006401	C6020,C6021	C-CERAMIC,CHIP
2203-006410	L1057	C-CERAMIC,CHIP
2203-006423	C1005,C1008,C1028	C-CERAMIC,CHIP
2203-006423	C1089,C1109,C1110	C-CERAMIC,CHIP
2203-006423	C1111,C1117,C1118	C-CERAMIC,CHIP
2203-006423	C1119,C1148,C2030	C-CERAMIC,CHIP
2203-006423	C3046,C3048,C3049	C-CERAMIC,CHIP
2203-006423	C3055,C3059,C3060	C-CERAMIC,CHIP
2203-006423	C3061,C3062,C4000	C-CERAMIC,CHIP
2203-006423	C4001,C4002,C4003	C-CERAMIC,CHIP
2203-006423	C4005,C4013,C4014	C-CERAMIC,CHIP
2203-006423	C4015,C4016,C4017	C-CERAMIC,CHIP
2203-006423	C4041,C4059,C4089	C-CERAMIC,CHIP
2203-006423	C4101,C4102,C4111	C-CERAMIC,CHIP
2203-006423	C4112,C4115,C4116	C-CERAMIC,CHIP
2203-006423	C5053,C5080,C5082	C-CERAMIC,CHIP
2203-006423	C6002,C6005,C6011	C-CERAMIC,CHIP
2203-006423	C6012,C8008	C-CERAMIC,CHIP
2203-006426	C8046	C-CERAMIC,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

## 5. MAIN Electrical Parts List

2203-006556	C1004,C1009,C1011	C-CERAMIC,CHIP
2203-006556	C2011,C5044	C-CERAMIC,CHIP
2203-006562	C3027,C3092,C5062	C-CERAMIC,CHIP
2203-006562	C5065,C5074,C5078	C-CERAMIC,CHIP
2203-006562	C5090,C6035,C6056	C-CERAMIC,CHIP
2203-006562	C7015,C7027,C7030	C-CERAMIC,CHIP
2203-006562	C9080	C-CERAMIC,CHIP
2203-006604	C3028,C6016	C-CERAMIC,CHIP
2203-006611	C3032,L1052	C-CERAMIC,CHIP
2203-006648	C4004,C4006	C-CERAMIC,CHIP
2203-006674	C1065	C-CERAMIC,CHIP
2203-006707	C3026	C-CERAMIC,CHIP
2203-006839	C3040,C3064,C4125	C-CERAMIC,CHIP
2203-006839	C4126,C5007,C5063	C-CERAMIC,CHIP
2203-006839	C5096	C-CERAMIC,CHIP
2203-006841	C6022	C-CERAMIC,CHIP
2203-006846	C1022,C1046	C-CERAMIC,CHIP
2203-006872	C7011,C7013	C-CERAMIC,CHIP
2203-006896	C1137,C1138	C-CERAMIC,CHIP
2203-006979	C1097,C1102,C1112	C-CERAMIC,CHIP
2203-006979	C1113,C1120,C1121	C-CERAMIC,CHIP
2203-007143	C6017	C-CERAMIC,CHIP
2203-007194	C1001,C7003,C7007	C-CERAMIC,CHIP
2203-007240	C4038,C4105,C4121	C-CERAMIC,CHIP
2203-007240	C4123	C-CERAMIC,CHIP
2203-007269	C7020,C7022	C-CERAMIC,CHIP
2203-007270	C7026	C-CERAMIC,CHIP
2203-007271	C1006,C1150,C4061	C-CERAMIC,CHIP
2203-007271	C5003,C5008,C5009	C-CERAMIC,CHIP
2203-007271	C5010,C5011,C5012	C-CERAMIC,CHIP
2203-007271	C5013,C5070,C5071	C-CERAMIC,CHIP
2203-007271	C5072,C5073,C6029	C-CERAMIC,CHIP
2203-007271	C8002,C8045	C-CERAMIC,CHIP
2203-007279	C4120	C-CERAMIC,CHIP
2203-007317	C2000,C3021,C3024	C-CERAMIC,CHIP
2203-007317	C3037,C3047,C3063	C-CERAMIC,CHIP
2203-007317	C4071,C5030,C5031	C-CERAMIC,CHIP
2203-007317	C5033,C5039,C5041	C-CERAMIC,CHIP
2203-007317	C5046,C5047,C5048	C-CERAMIC,CHIP

## 5. MAIN Electrical Parts List

2203-007317	C5049,C6003,C6004	C-CERAMIC,CHIP
2203-007317	C8006,C8023,C8024	C-CERAMIC,CHIP
2203-007369	C6008	C-CERAMIC,CHIP
2203-007385	C5084	C-CERAMIC,CHIP
2203-007391	C1104,C1106,C3017	C-CERAMIC,CHIP
2203-007391	C3018	C-CERAMIC,CHIP
2203-007392	C5045	C-CERAMIC,CHIP
2203-007393	C2002,C4007	C-CERAMIC,CHIP
2203-007449	C1048,C1098,C1105	C-CERAMIC,CHIP
2203-007449	C1114,C1122,C3004	C-CERAMIC,CHIP
2203-007449	C3093,C3094,C4009	C-CERAMIC,CHIP
2203-007449	C4010,C4011,C4019	C-CERAMIC,CHIP
2203-007449	C4020,C4021,C4022	C-CERAMIC,CHIP
2203-007449	C4024,C4025,C4027	C-CERAMIC,CHIP
2203-007449	C4028,C4031,C4032	C-CERAMIC,CHIP
2203-007449	C4033,C4034,C4035	C-CERAMIC,CHIP
2203-007449	C4036,C4039,C4040	C-CERAMIC,CHIP
2203-007449	C4042,C4044,C4045	C-CERAMIC,CHIP
2203-007449	C4046,C4047,C4048	C-CERAMIC,CHIP
2203-007449	C4049,C4050,C4051	C-CERAMIC,CHIP
2203-007449	C4052,C4053,C4054	C-CERAMIC,CHIP
2203-007449	C4055,C4056,C4057	C-CERAMIC,CHIP
2203-007449	C4058,C4060,C4062	C-CERAMIC,CHIP
2203-007449	C4063,C4064,C4065	C-CERAMIC,CHIP
2203-007449	C4066,C4067,C4068	C-CERAMIC,CHIP
2203-007449	C4069,C4070,C4072	C-CERAMIC,CHIP
2203-007449	C4073,C4074,C4075	C-CERAMIC,CHIP
2203-007449	C4076,C4077,C4078	C-CERAMIC,CHIP
2203-007449	C4079,C4080,C4081	C-CERAMIC,CHIP
2203-007449	C4082,C4083,C4084	C-CERAMIC,CHIP
2203-007449	C4085,C4086,C4087	C-CERAMIC,CHIP
2203-007449	C4088,C4093,C4094	C-CERAMIC,CHIP
2203-007449	C4095,C4096,C4097	C-CERAMIC,CHIP
2203-007449	C4098,C4099,C4100	C-CERAMIC,CHIP
2203-007449	C4106,C4107,C4108	C-CERAMIC,CHIP
2203-007449	C4109,C4110,C4113	C-CERAMIC,CHIP
2203-007449	C4117,C4118,C4127	C-CERAMIC,CHIP
2203-007449	C4128,C5027,C5029	C-CERAMIC,CHIP
2203-007449	C5035,C5038,C5040	C-CERAMIC,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.



## 5. MAIN Electrical Parts List

2203-007449	C5042,C5043,C5050	C-CERAMIC,CHIP
2203-007449	C5051,C5052,C5055	C-CERAMIC,CHIP
2203-007449	C5068,C5075,C5076	C-CERAMIC,CHIP
2203-007449	C5077,C5079,C5083	C-CERAMIC,CHIP
2203-007449	C5088,C5089,C6013	C-CERAMIC,CHIP
2203-007449	C6036,C6046,C6047	C-CERAMIC,CHIP
2203-007449	C6048,C6049,C6050	C-CERAMIC,CHIP
2203-007449	C7028,C7029,C8007	C-CERAMIC,CHIP
2203-007449	C8009,C8017,C8026	C-CERAMIC,CHIP
2203-007449	C8027,C8028,C8029	C-CERAMIC,CHIP
2203-007449	C8058,C8063,C8064	C-CERAMIC,CHIP
2203-007474	C3001,C3008,C3019	C-CERAMIC,CHIP
2203-007474	C3039,C3111,C5067	C-CERAMIC,CHIP
2203-007474	C7002,C7009	C-CERAMIC,CHIP
2203-007634	C6024	C-CERAMIC,CHIP
2203-007775	C3023,C3041,C3043	C-CERAMIC,CHIP
2203-007775	C6028	C-CERAMIC,CHIP
2203-007796	C3034,C3065,C3066	C-CERAMIC,CHIP
2203-007796	C3068,C3070,C3071	C-CERAMIC,CHIP
2203-007796	C3072,C3079,C3080	C-CERAMIC,CHIP
2203-007796	C4122,C5017,C6019	C-CERAMIC,CHIP
2203-007796	C7018,C7024,C8057	C-CERAMIC,CHIP
2203-008097	C1012	C-CERAMIC,CHIP
2203-008123	C4012,C4018,C4029	C-CERAMIC,CHIP
2203-008123	C4030,C4037,C4104	C-CERAMIC,CHIP
2203-008123	C5056,C5057,C5085	C-CERAMIC,CHIP
2203-008242	C3098,C3099,C5091	C-CERAMIC,CHIP
2203-008242	C5093,C7001,C7016	C-CERAMIC,CHIP
2203-008242	C7025,C8016,C8018	C-CERAMIC,CHIP
2203-008242	C8019,C8022	C-CERAMIC,CHIP
2203-008243	C5018	C-CERAMIC,CHIP
2203-008394	C2033	C-CERAMIC,CHIP
2203-008572	C5006	C-CERAMIC,CHIP
2203-008860	C1146,C1151,C3074	C-CERAMIC,CHIP
2203-008860	C3075,C3076,C6057	C-CERAMIC,CHIP
2203-008860	C8059,C9065	C-CERAMIC,CHIP
2203-008876	C5000,C5002	C-CERAMIC,CHIP
2203-009328	C3000,C4091,C4092	C-CERAMIC,CHIP
2203-009618	C5015,C5022,C5054	C-CERAMIC,CHIP

## 5. MAIN Electrical Parts List

2203-009618	C6027,C7019,C7021	C-CERAMIC,CHIP
2203-009618	C7023,C8033,C9070	C-CERAMIC,CHIP
2203-009733	C1010,C1013,C2001	C-CERAMIC,CHIP
2203-009733	C3073,C5014,C5016	C-CERAMIC,CHIP
2203-009733	C5059,C5060,C5066	C-CERAMIC,CHIP
2203-009733	C5081,C7005,C8000	C-CERAMIC,CHIP
2203-009733	C8001,C8034,C9067	C-CERAMIC,CHIP
2203-009733	C9068,C9069,C9071	C-CERAMIC,CHIP
2703-002858	L1043	INDUCTOR-SMD
2703-002900	U1000,U1008	INDUCTOR-SMD
2703-002907	L1042	INDUCTOR-SMD
2703-002955	L1047,L1048,L1050	INDUCTOR-SMD
2703-002955	L1051	INDUCTOR-SMD
2703-002958	L3004	INDUCTOR-SMD
2703-002959	L7011,L7012	INDUCTOR-SMD
2703-003293	L3013,L3014	INDUCTOR-SMD
2703-004000	L1028,L1032,L1033	INDUCTOR-SMD
2703-004000	L1037	INDUCTOR-SMD
2703-004012	C1025,C1038,C1079	INDUCTOR-SMD
2703-004012	C2004,C2039,C3115	INDUCTOR-SMD
2703-004012	L1003,L1006,L1007	INDUCTOR-SMD
2703-004012	L1034,L1039,L1041	INDUCTOR-SMD
2703-004012	L2017	INDUCTOR-SMD
2703-004013	C1070,L3006	INDUCTOR-SMD
2703-004018	L1029,L2003,U1014	INDUCTOR-SMD
2703-004032	C2020,C2031,L2007	INDUCTOR-SMD
2703-004033	C1123,C1144	INDUCTOR-SMD
2703-004034	C1043,C1054,C3044	INDUCTOR-SMD
2703-004034	L1015,L1031,L1035	INDUCTOR-SMD
2703-004034	L1049,L1053,L2009	INDUCTOR-SMD
2703-004034	L2012	INDUCTOR-SMD
2703-004035	C1040,L1001,L1017	INDUCTOR-SMD
2703-004035	L1059,L2002	INDUCTOR-SMD
2703-004037	C2013,C2014,L1012	INDUCTOR-SMD
2703-004037	L1022,L1036,L1040	INDUCTOR-SMD
2703-004037	L1046,L2005	INDUCTOR-SMD
2703-004038	C2006,C2008,C3056	INDUCTOR-SMD
2703-004038	L1004,L2001,L2013	INDUCTOR-SMD
2703-004230	L6008,L6009	INDUCTOR-SMD

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

## 5. MAIN Electrical Parts List

2703-004286	C3054	INDUCTOR-SMD
2703-004295	L6000,L6001	INDUCTOR-SMD
2703-004328	C1100,C1139,L1011	INDUCTOR-SMD
2703-004328	L1019,L1023,L1054	INDUCTOR-SMD
2703-004328	L1055	INDUCTOR-SMD
2703-004363	C1015	INDUCTOR-SMD
2703-004366	L3010	INDUCTOR-SMD
2703-004367	C1050,L1005,L1038	INDUCTOR-SMD
2703-004367	L2006	INDUCTOR-SMD
2703-004369	L3017	INDUCTOR-SMD
2703-004371	L6003	INDUCTOR-SMD
2703-004684	L4000	INDUCTOR-SMD
2703-004718	L5004,L5005	INDUCTOR-SMD
2703-004763	L2010,L2015	INDUCTOR-SMD
2703-004764	C1058,C1107,C1126	INDUCTOR-SMD
2703-004764	L2008	INDUCTOR-SMD
2703-004862	C3053,L1013	INDUCTOR-SMD
2703-004901	L5006,L5007	INDUCTOR-SMD
2703-004911	L1018	INDUCTOR-SMD
2703-004947	L5002,L5003	INDUCTOR-SMD
2703-004976	C1087,C1090	INDUCTOR-SMD
2703-005007	L7006	INDUCTOR-SMD
2703-005058	L1008	INDUCTOR-SMD
2703-005066	L8000,L8003	INDUCTOR-SMD
2703-005070	L7005,L7007	INDUCTOR-SMD
2703-005086	L3001,L3002	INDUCTOR-SMD
2703-005089	L1016,L1020	INDUCTOR-SMD
2703-005100	U8025,U8038	INDUCTOR-SMD
2703-005101	L2000	INDUCTOR-SMD
2703-005136	L4001,L5000,L5008	INDUCTOR-SMD
2703-005200	L5009	INDUCTOR-SMD
2703-005201	L5010,L5011,L5012	INDUCTOR-SMD
2703-005219	L8001,L8002	INDUCTOR-SMD
2801-005300	OSC5000	CRYSTAL-UNIT
2801-005323	OSC3000	CRYSTAL-UNIT
2901-001786	F7010,F7011,F7012	FILTER-EMI
2901-001786	F7013,F7014	FILTER-EMI
2901-001798	F7000,F7001,F7002	FILTER-EMI
2901-001798	F7003,F7004,F7005	FILTER-EMI

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

## 5. MAIN Electrical Parts List

2901-001798	F7006,F7007,F7008	FILTER-EMI
2901-001798	F7009	FILTER-EMI
2903-001535	F1003	FILTER-CERAMIC
2904-002257	F2004	FILTER-SAW
2904-002266	F2003	FILTER-SAW
2904-002269	F2002	FILTER-SAW
2904-002306	F1010	FILTER-SAW
2904-002314	F3000	FILTER-SAW
2904-002336	F2006	FILTER-SAW
2904-002349	U8039	FILTER-SAW
2904-002350	F1011	FILTER-SAW
2904-002355	F3003,F3004	FILTER-SAW
2910-000365	F1006	FILTER
2910-000367	F1008	FILTER
2911-000308	U3004	FILTER
2911-000407	F1002	FILTER
2911-000430	F2005	FILTER
3003-001233	MIC8000	MIC-CONDENSOR
3301-002078	L8004	CORE-FERRITE
3301-002223	L7000,L7004	CORE-FERRITE
3301-002235	L8008	CORE-FERRITE
3301-002236	L1058	CORE-FERRITE
3301-002237	L6005,L6007,R6056	CORE-FERRITE
3301-002238	L3009	CORE-FERRITE
3301-002286	L6014,L8006	CORE-FERRITE
3301-002309	L7002,L7003	CORE-FERRITE
3301-002312	L7008,L7009,L7010	CORE-FERRITE
3301-002313	L3000	CORE-FERRITE
3301-002331	L5001,L6006	CORE-FERRITE
3301-002335	L8007	CORE-FERRITE
3705-001937	CN1000,CN1001,CN1002	CONNECTOR-COAXIAL
3705-001937	CN1003	CONNECTOR-COAXIAL
3709-001873	SIM6000	CONNECTOR-CARD
3709-001879	CN6000	CONNECTOR-CARD
3711-007107	HEA7000	CONNECTOR-HEADER
3711-008182	HDC7001	CONNECTOR-HEADER
3711-008508	HDC7000	CONNECTOR-HEADER
3711-008847	BTC5000	CONNECTOR-HEADER
3711-009058	HEA3000	CONNECTOR-HEADER

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

## 5. MAIN Electrical Parts List

3711-009073	HEA6000	CONNECTOR-HEADER
3712-001604	ANT1000,ANT1001	CONNECTOR
3712-001604	ANT2002,ANT2003	CONNECTOR
3712-001604	ANT2009,ANT3000	CONNECTOR
3712-001604	ANT3001,ANT3003	CONNECTOR
3712-001604	ANT3007,ANT3010	CONNECTOR
3712-001621	ANT3005,ANT3006	CONNECTOR
3712-001621	ANT8002,ANT8003	CONNECTOR
3712-001626	ANT8000,ANT8001	CONNECTOR
3712-001633	ANT3008,ANT6005	CONNECTOR
3712-001633	ANT6006	CONNECTOR
3712-001656	ANT3004	CONNECTOR
3712-001666	ANT6000,ANT6001	CONNECTOR
3712-001666	ANT6002,ANT6003	CONNECTOR
3712-001666	ANT6004	CONNECTOR
3712-001694	ANT2000,ANT2001	CONNECTOR
3712-001694	ANT2004,ANT2006	CONNECTOR
3712-001694	ANT3002	CONNECTOR
4709-002150	F3002	RF-MODULE
4709-002196	F1004	RF-MODULE
4709-002285	F3005	RF-MODULE
4709-002351	F3001	RF-MODULE
4709-002387	F1001	RF-MODULE
4709-002412	F1005	RF-MODULE
4709-002416	F2001	RF-MODULE
4709-002464	F2000	RF-MODULE
4709-002484	F1000	RF-MODULE
GH60-00009A	CON1001,CON1002	C-CLIP
GH60-00009A	CON1003	C-CLIP
GH60-00010A	CON1005,CON1006	C-CLIP
GH61-08634A	CON1000,CON1004	C-CLIP
GH61-09798A	SUS2000	PLATE
GH62-00040A	CON7000	Heat Part-ETC
GH63-13669A	SC1002	SHIELD CAN
GH63-13670A	SC1004	SHIELD CAN
GH63-13671A	SC1006	SHIELD CAN
GH63-13672A	SC1003	SHIELD CAN
GH63-13674A	SC1000	SHIELD CAN
GH63-13675A	SC1007	SHIELD CAN

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

## 5. MAIN Electrical Parts List

---

GH63-13676A	SC1001	SHIELD CAN
GH63-14299A	SC1005	SHIELD CAN
1105-002841	UCP400UP	IC
GH02-13822A	SC1006SP	TAPE
GH02-13823A	SC1007SP	TAPE

## 5. MAIN Electrical Parts List

### [SM-C900Y]

Parts Code	Design Loc	Description
0202-002125	R4031,R4032,R4045	PB-SHORT-0603
0404-001250	D5000,D6001	DIODE-SCHOTTKY
0404-001782	D3000	DIODE-SCHOTTKY
0406-001413	ZD8000,ZD8001	DIODE-TVS
0406-001465	ZD6018,ZD6019,ZD6022	DIODE-TVS
0406-001465	ZD6023	DIODE-TVS
0406-001505	D6000	DIODE-TVS
0406-001592	ZD3000,ZD3001,ZD3002	DIODE-TVS
0406-001592	ZD3003,ZD3004,ZD3005	DIODE-TVS
0406-001592	ZD3006,ZD3007,ZD3008	DIODE-TVS
0406-001592	ZD6020,ZD6021,ZD7000	DIODE-TVS
0406-001592	ZD7001,ZD7002,ZD7003	DIODE-TVS
0406-001592	ZD7004,ZD7005,ZD7006	DIODE-TVS
0406-001645	ZD6027	DIODE-TVS
0406-001675	ZD5001	DIODE-TVS
0406-001682	ZD6031,ZD6032	DIODE-TVS
0406-001690	ZD6011,ZD6012,ZD6013	DIODE-TVS
0406-001690	ZD6014,ZD6015	DIODE-TVS
0406-001709	ZD6025,ZD6026	DIODE-TVS
0406-001717	ZD6010	DIODE-TVS
0406-001763	ZD6000,ZD6001,ZD6002	DIODE-TVS
0406-001763	ZD6003,ZD6004,ZD6005	DIODE-TVS
0406-001763	ZD6006,ZD6007,ZD6008	DIODE-TVS
0406-001763	ZD6009	DIODE-TVS
0505-002088	TR5001,TR7000,U8033	FET-SILICON
0505-002388	TR5000	FET-SILICON
0601-001905	LED3000	LED
0601-003575	LED5000	LED
0903-002171	U3007	IC
1001-001655	U5003,U5004,U5006	IC
1001-001849	U1001	IC
1001-001972	U1009,U2004,U2005	IC
1001-001992	U1011	IC
1001-002001	U1007	IC
1003-002415	U6001	IC
1107-002504	UME6000	IC-FLASH
1201-003786	U3005	IC

## 5. MAIN Electrical Parts List

1201-003964	U8001,U8013	IC
1201-003974	F1009	IC
1201-003975	F1007	IC
1201-003990	U1017	IC
1201-004091	PAM1000	IC
1201-004100	U1013	IC
1203-008011	U4001	IC
1203-008249	U3001	IC
1203-008250	U3000,U3009,U3010	IC
1203-008250	U5012,U5019	IC
1203-008251	U5013,U6004,U6005	IC
1203-008326	U5011	IC
1203-008379	U2000	IC
1203-008395	U5018	IC
1203-008459	U5016	IC
1203-008603	U3012	IC
1203-008689	U5008	IC
1203-008700	U5001	IC
1203-008717	U7002	IC
1203-008819	U5007	IC
1203-008830	U6003	IC
1203-008858	U8002	IC
1203-008859	U8000	IC
1203-008860	U7000	IC
1205-005037	U4000	IC
1205-005106	U3008	IC
1205-005262	U3002	IC
1205-005493	U1015,U1016	IC
1205-005652	U6002	IC
1205-005680	U3011	IC
1205-005693	U8003	IC
1205-005705	UCP400	IC
1209-002344	U3006	IC
1209-002400	U3003	IC
1209-002401	U3014	IC
1404-001724	TH2000,TH4000,TH5000	THERMISTOR
1404-001724	TH5001	THERMISTOR
1405-001395	C3002,V1000,V1001	VARISTOR
1405-001395	V3000,V3001,V3002	VARISTOR



## 5. MAIN Electrical Parts List

1405-001395	V3003,V3004,VR2000	VARISTOR
1405-001395	VR2001	VARISTOR
1405-001398	VR2002,VR2003	VARISTOR
1405-001404	V6000,V6001,V6002	VARISTOR
1405-001404	VR7000	VARISTOR
1405-001410	V6003	VARISTOR
2007-003015	R6040,R6041	R-CHIP
2007-007107	R2000	R-CHIP
2007-007193	R6043,R6044	R-CHIP
2007-007313	R4010	R-CHIP
2007-007741	R3000,R3015,R4002	R-CHIP
2007-007741	R4025,R4026,R4046	R-CHIP
2007-007741	R5041,R6003,R6005	R-CHIP
2007-007741	R6007,R6010,R6012	R-CHIP
2007-007741	R6016,R6030,R7006	R-CHIP
2007-007942	R6014	R-CHIP
2007-008053	R3014	R-CHIP
2007-008210	R6015	R-CHIP
2007-008420	R4000,R5007,R5013	R-CHIP
2007-008420	U5002	R-CHIP
2007-008531	R3025	R-CHIP
2007-008579	R1005,R1006	R-CHIP
2007-008774	R3011,R3012,R3013	R-CHIP
2007-008774	R3027,R3028,R6013	R-CHIP
2007-008800	R4041,R4042	R-CHIP
2007-009111	R3001,R6011	R-CHIP
2007-009155	R5008,R5016	R-CHIP
2007-009157	R3003,R3005,R4027	R-CHIP
2007-009157	R5000,R5001,R5018	R-CHIP
2007-009157	R5019,R5020,R5030	R-CHIP
2007-009157	R6019,R6020,R6021	R-CHIP
2007-009158	R5048	R-CHIP
2007-009182	R6028	R-CHIP
2007-009212	R3002,R6000,R6001	R-CHIP
2007-009212	R6009,R6017,R6018	R-CHIP
2007-009212	R6031,R8008	R-CHIP
2007-009223	R5017	R-CHIP
2007-009233	R5034	R-CHIP
2007-009315	R5010,R6045,R6046	R-CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

## 5. MAIN Electrical Parts List

2007-009315	R6047,R6048,R6049	R-CHIP
2007-009315	R6050,R6051,R6052	R-CHIP
2007-009315	R6053,R6054,R6055	R-CHIP
2007-009352	R3006,R3007,R4015	R-CHIP
2007-009352	R4030,R7005	R-CHIP
2007-009408	R3008,R3009,R3019	R-CHIP
2007-009408	R3020,R3021,R3022	R-CHIP
2007-009408	R4011,R4012,R4013	R-CHIP
2007-009408	R4014,R4016,R4017	R-CHIP
2007-009408	R4018,R4019,R4020	R-CHIP
2007-009408	R4021,R4023,R4024	R-CHIP
2007-009408	R4028,R4029,R4035	R-CHIP
2007-009408	R4036	R-CHIP
2007-009766	R5033	R-CHIP
2007-009801	R7002	R-CHIP
2007-009805	R1001,R1003,R1004	R-CHIP
2007-009805	R3004	R-CHIP
2007-009866	R5002,R5012	R-CHIP
2007-009920	R4003,R4004,R4005	R-CHIP
2007-009920	R4006,R4007,R4008	R-CHIP
2007-009969	R8009	R-CHIP
2007-010029	R6024,R6026	R-CHIP
2007-010202	R3016,R6022	R-CHIP
2007-010685	R4001,R6002,R6004	R-CHIP
2007-010856	R5031	R-CHIP
2007-011043	R4009	R-CHIP
2007-011648	R6059	R-CHIP
2203-000627	C3082,C3086,C3091	C-CERAMIC,CHIP
2203-000725	C6018	C-CERAMIC,CHIP
2203-000854	C6026	C-CERAMIC,CHIP
2203-001153	C3083,C3089	C-CERAMIC,CHIP
2203-001221	C3084,C3088	C-CERAMIC,CHIP
2203-001239	C3085	C-CERAMIC,CHIP
2203-005344	C5058	C-CERAMIC,CHIP
2203-005682	C1014,C1036,C1044	C-CERAMIC,CHIP
2203-005682	C1047,C1056,C1078	C-CERAMIC,CHIP
2203-005682	C1092,C1099,C1101	C-CERAMIC,CHIP
2203-005682	C1115,C1116,C1129	C-CERAMIC,CHIP
2203-005682	C1145,C1149,C1152	C-CERAMIC,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

## 5. MAIN Electrical Parts List

2203-005682	C2019,C2023,C2024	C-CERAMIC,CHIP
2203-005682	C2032,C2038,C2040	C-CERAMIC,CHIP
2203-005682	C3050,C3051,C3077	C-CERAMIC,CHIP
2203-005682	C3095,C6001,C6006	C-CERAMIC,CHIP
2203-005682	C6010,C7010,C7012	C-CERAMIC,CHIP
2203-005682	C7014,L1056,L2014	C-CERAMIC,CHIP
2203-005682	L2016	C-CERAMIC,CHIP
2203-005717	C1084,C2035	C-CERAMIC,CHIP
2203-005719	C1059,C7032,C7033	C-CERAMIC,CHIP
2203-005725	C1124,C1130,C1131	C-CERAMIC,CHIP
2203-005725	C1134,C1143,C1147	C-CERAMIC,CHIP
2203-005725	L1000	C-CERAMIC,CHIP
2203-005727	C3029	C-CERAMIC,CHIP
2203-005731	C3025,C3035,C3038	C-CERAMIC,CHIP
2203-005731	C3113,C3116,C6044	C-CERAMIC,CHIP
2203-005731	C6045,C6054,C8044	C-CERAMIC,CHIP
2203-005732	C5095,C6030,C6031	C-CERAMIC,CHIP
2203-005732	C6055,C8011,C8025	C-CERAMIC,CHIP
2203-005732	C8037,C8043,C8049	C-CERAMIC,CHIP
2203-005734	C3114,C3119,C3120	C-CERAMIC,CHIP
2203-005734	C5023,C5064,C5086	C-CERAMIC,CHIP
2203-005734	C5087,C7034,C7035	C-CERAMIC,CHIP
2203-005734	C7036,C7037,C7038	C-CERAMIC,CHIP
2203-005736	C1000,C1007,C1020	C-CERAMIC,CHIP
2203-005736	C1023,C1026,C1027	C-CERAMIC,CHIP
2203-005736	C1032,C1042,C1051	C-CERAMIC,CHIP
2203-005736	C1060,C1067,C1068	C-CERAMIC,CHIP
2203-005736	C1072,C1073,C1076	C-CERAMIC,CHIP
2203-005736	C1085,C1088,C1091	C-CERAMIC,CHIP
2203-005736	C1093,C1141,C1142	C-CERAMIC,CHIP
2203-005736	C2005,C2009,C2012	C-CERAMIC,CHIP
2203-005736	C2016,C2017,C2018	C-CERAMIC,CHIP
2203-005736	C2025,C2026,C2028	C-CERAMIC,CHIP
2203-005736	C2034,C3009,C3011	C-CERAMIC,CHIP
2203-005736	C3012,C3014,C3015	C-CERAMIC,CHIP
2203-005736	C3031,C3033,C3042	C-CERAMIC,CHIP
2203-005736	C3052,C3058,C3101	C-CERAMIC,CHIP
2203-005736	L1027,L2011,L3012	C-CERAMIC,CHIP
2203-005777	C1034,C1035,C1045	C-CERAMIC,CHIP

## 5. MAIN Electrical Parts List

2203-005777	C1049,C1057,C2021	C-CERAMIC,CHIP
2203-005777	C3022,L3016	C-CERAMIC,CHIP
2203-005779	C3030	C-CERAMIC,CHIP
2203-005789	C1052,C1061,C1080	C-CERAMIC,CHIP
2203-005789	C1108,C1125,U1003	C-CERAMIC,CHIP
2203-005789	U1006,U8035	C-CERAMIC,CHIP
2203-005792	C1021,C1024,C1033	C-CERAMIC,CHIP
2203-005792	C2015	C-CERAMIC,CHIP
2203-005806	C4103,C5021,C5061	C-CERAMIC,CHIP
2203-006123	C1019	C-CERAMIC,CHIP
2203-006137	C3020	C-CERAMIC,CHIP
2203-006194	C3005,C3006,C3007	C-CERAMIC,CHIP
2203-006194	C3010,C3013,C3016	C-CERAMIC,CHIP
2203-006305	C5024,C5025,U1012	C-CERAMIC,CHIP
2203-006318	C1037,C3045,C3117	C-CERAMIC,CHIP
2203-006348	C6023	C-CERAMIC,CHIP
2203-006399	C3003,C5032,C8060	C-CERAMIC,CHIP
2203-006399	C8061	C-CERAMIC,CHIP
2203-006400	C1095,C1096,C3036	C-CERAMIC,CHIP
2203-006400	C3081	C-CERAMIC,CHIP
2203-006401	C6020,C6021	C-CERAMIC,CHIP
2203-006410	C1153,L1057	C-CERAMIC,CHIP
2203-006423	C1005,C1008,C1028	C-CERAMIC,CHIP
2203-006423	C1089,C1109,C1110	C-CERAMIC,CHIP
2203-006423	C1111,C1117,C1118	C-CERAMIC,CHIP
2203-006423	C1119,C1148,C2030	C-CERAMIC,CHIP
2203-006423	C3046,C3048,C3049	C-CERAMIC,CHIP
2203-006423	C3055,C3059,C3060	C-CERAMIC,CHIP
2203-006423	C3061,C3062,C4000	C-CERAMIC,CHIP
2203-006423	C4001,C4002,C4003	C-CERAMIC,CHIP
2203-006423	C4005,C4013,C4014	C-CERAMIC,CHIP
2203-006423	C4015,C4016,C4017	C-CERAMIC,CHIP
2203-006423	C4041,C4059,C4089	C-CERAMIC,CHIP
2203-006423	C4101,C4102,C4111	C-CERAMIC,CHIP
2203-006423	C4112,C4115,C4116	C-CERAMIC,CHIP
2203-006423	C5053,C5080,C5082	C-CERAMIC,CHIP
2203-006423	C6002,C6005,C6011	C-CERAMIC,CHIP
2203-006423	C6012,C8008	C-CERAMIC,CHIP
2203-006426	C8046	C-CERAMIC,CHIP

## 5. MAIN Electrical Parts List

2203-006556	C1004,C1009,C1011	C-CERAMIC,CHIP
2203-006556	C2011,C5044	C-CERAMIC,CHIP
2203-006562	C3027,C3092,C5062	C-CERAMIC,CHIP
2203-006562	C5065,C5074,C5078	C-CERAMIC,CHIP
2203-006562	C5090,C6035,C6056	C-CERAMIC,CHIP
2203-006562	C7015,C7027,C7030	C-CERAMIC,CHIP
2203-006562	C9080	C-CERAMIC,CHIP
2203-006604	C3028,C6016	C-CERAMIC,CHIP
2203-006611	C3032	C-CERAMIC,CHIP
2203-006648	C4004,C4006	C-CERAMIC,CHIP
2203-006674	C1065	C-CERAMIC,CHIP
2203-006707	C3026	C-CERAMIC,CHIP
2203-006839	C3040,C3064,C4125	C-CERAMIC,CHIP
2203-006839	C4126,C5007,C5063	C-CERAMIC,CHIP
2203-006839	C5096	C-CERAMIC,CHIP
2203-006841	C6022	C-CERAMIC,CHIP
2203-006846	C1022,C1046	C-CERAMIC,CHIP
2203-006872	C7011,C7013	C-CERAMIC,CHIP
2203-006896	C1137,C1138	C-CERAMIC,CHIP
2203-006979	C1097,C1102,C1112	C-CERAMIC,CHIP
2203-006979	C1113,C1120,C1121	C-CERAMIC,CHIP
2203-007143	C6017	C-CERAMIC,CHIP
2203-007194	C1001,C7003,C7007	C-CERAMIC,CHIP
2203-007240	C4038,C4105,C4121	C-CERAMIC,CHIP
2203-007240	C4123	C-CERAMIC,CHIP
2203-007269	C7020,C7022	C-CERAMIC,CHIP
2203-007270	C7026	C-CERAMIC,CHIP
2203-007271	C1006,C1150,C4061	C-CERAMIC,CHIP
2203-007271	C5003,C5008,C5009	C-CERAMIC,CHIP
2203-007271	C5010,C5011,C5012	C-CERAMIC,CHIP
2203-007271	C5013,C5070,C5071	C-CERAMIC,CHIP
2203-007271	C5072,C5073,C6029	C-CERAMIC,CHIP
2203-007271	C8002,C8045	C-CERAMIC,CHIP
2203-007279	C4120	C-CERAMIC,CHIP
2203-007317	C2000,C3021,C3024	C-CERAMIC,CHIP
2203-007317	C3037,C3047,C3063	C-CERAMIC,CHIP
2203-007317	C4071,C5030,C5031	C-CERAMIC,CHIP
2203-007317	C5033,C5039,C5041	C-CERAMIC,CHIP
2203-007317	C5046,C5047,C5048	C-CERAMIC,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

## 5. MAIN Electrical Parts List

2203-007317	C5049,C6003,C6004	C-CERAMIC,CHIP
2203-007317	C8006,C8023,C8024	C-CERAMIC,CHIP
2203-007369	C6008	C-CERAMIC,CHIP
2203-007385	C5084	C-CERAMIC,CHIP
2203-007391	C1104,C1106,C3017	C-CERAMIC,CHIP
2203-007391	C3018	C-CERAMIC,CHIP
2203-007392	C5045	C-CERAMIC,CHIP
2203-007393	C2002,C4007	C-CERAMIC,CHIP
2203-007449	C1048,C1098,C1105	C-CERAMIC,CHIP
2203-007449	C1114,C1122,C3004	C-CERAMIC,CHIP
2203-007449	C3093,C3094,C4009	C-CERAMIC,CHIP
2203-007449	C4010,C4011,C4019	C-CERAMIC,CHIP
2203-007449	C4020,C4021,C4022	C-CERAMIC,CHIP
2203-007449	C4024,C4025,C4027	C-CERAMIC,CHIP
2203-007449	C4028,C4031,C4032	C-CERAMIC,CHIP
2203-007449	C4033,C4034,C4035	C-CERAMIC,CHIP
2203-007449	C4036,C4039,C4040	C-CERAMIC,CHIP
2203-007449	C4042,C4044,C4045	C-CERAMIC,CHIP
2203-007449	C4046,C4047,C4048	C-CERAMIC,CHIP
2203-007449	C4049,C4050,C4051	C-CERAMIC,CHIP
2203-007449	C4052,C4053,C4054	C-CERAMIC,CHIP
2203-007449	C4055,C4056,C4057	C-CERAMIC,CHIP
2203-007449	C4058,C4060,C4062	C-CERAMIC,CHIP
2203-007449	C4063,C4064,C4065	C-CERAMIC,CHIP
2203-007449	C4066,C4067,C4068	C-CERAMIC,CHIP
2203-007449	C4069,C4070,C4072	C-CERAMIC,CHIP
2203-007449	C4073,C4074,C4075	C-CERAMIC,CHIP
2203-007449	C4076,C4077,C4078	C-CERAMIC,CHIP
2203-007449	C4079,C4080,C4081	C-CERAMIC,CHIP
2203-007449	C4082,C4083,C4084	C-CERAMIC,CHIP
2203-007449	C4085,C4086,C4087	C-CERAMIC,CHIP
2203-007449	C4088,C4093,C4094	C-CERAMIC,CHIP
2203-007449	C4095,C4096,C4097	C-CERAMIC,CHIP
2203-007449	C4098,C4099,C4100	C-CERAMIC,CHIP
2203-007449	C4106,C4107,C4108	C-CERAMIC,CHIP
2203-007449	C4109,C4110,C4113	C-CERAMIC,CHIP
2203-007449	C4117,C4118,C4127	C-CERAMIC,CHIP
2203-007449	C4128,C5027,C5029	C-CERAMIC,CHIP
2203-007449	C5035,C5038,C5040	C-CERAMIC,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

## 5. MAIN Electrical Parts List

2203-007449	C5042,C5043,C5050	C-CERAMIC,CHIP
2203-007449	C5051,C5052,C5055	C-CERAMIC,CHIP
2203-007449	C5068,C5075,C5076	C-CERAMIC,CHIP
2203-007449	C5077,C5079,C5083	C-CERAMIC,CHIP
2203-007449	C5088,C5089,C6013	C-CERAMIC,CHIP
2203-007449	C6036,C6046,C6047	C-CERAMIC,CHIP
2203-007449	C6048,C6049,C6050	C-CERAMIC,CHIP
2203-007449	C7028,C7029,C8007	C-CERAMIC,CHIP
2203-007449	C8009,C8017,C8026	C-CERAMIC,CHIP
2203-007449	C8027,C8028,C8029	C-CERAMIC,CHIP
2203-007449	C8058,C8063,C8064	C-CERAMIC,CHIP
2203-007474	C3001,C3008,C3019	C-CERAMIC,CHIP
2203-007474	C3039,C3111,C5067	C-CERAMIC,CHIP
2203-007474	C7002,C7009	C-CERAMIC,CHIP
2203-007634	C6024	C-CERAMIC,CHIP
2203-007775	C3023,C3041,C3043	C-CERAMIC,CHIP
2203-007775	C6028	C-CERAMIC,CHIP
2203-007796	C3034,C3065,C3066	C-CERAMIC,CHIP
2203-007796	C3068,C3070,C3071	C-CERAMIC,CHIP
2203-007796	C3072,C3079,C3080	C-CERAMIC,CHIP
2203-007796	C4122,C5017,C6019	C-CERAMIC,CHIP
2203-007796	C7018,C7024,C8057	C-CERAMIC,CHIP
2203-008097	C1012	C-CERAMIC,CHIP
2203-008123	C4012,C4018,C4029	C-CERAMIC,CHIP
2203-008123	C4030,C4037,C4104	C-CERAMIC,CHIP
2203-008123	C5056,C5057,C5085	C-CERAMIC,CHIP
2203-008242	C3098,C3099,C5091	C-CERAMIC,CHIP
2203-008242	C5093,C7001,C7016	C-CERAMIC,CHIP
2203-008242	C7025,C8016,C8018	C-CERAMIC,CHIP
2203-008242	C8019,C8022	C-CERAMIC,CHIP
2203-008243	C5018	C-CERAMIC,CHIP
2203-008394	C2033	C-CERAMIC,CHIP
2203-008572	C5006	C-CERAMIC,CHIP
2203-008860	C1146,C1151,C3074	C-CERAMIC,CHIP
2203-008860	C3075,C3076,C6057	C-CERAMIC,CHIP
2203-008860	C8059,C9065	C-CERAMIC,CHIP
2203-008876	C5000,C5002	C-CERAMIC,CHIP
2203-009328	C3000,C4091,C4092	C-CERAMIC,CHIP
2203-009618	C5015,C5022,C5054	C-CERAMIC,CHIP

## 5. MAIN Electrical Parts List

2203-009618	C6027,C7019,C7021	C-CERAMIC,CHIP
2203-009618	C7023,C8033,C9070	C-CERAMIC,CHIP
2203-009733	C1010,C1013,C2001	C-CERAMIC,CHIP
2203-009733	C3073,C5014,C5016	C-CERAMIC,CHIP
2203-009733	C5059,C5060,C5066	C-CERAMIC,CHIP
2203-009733	C5081,C7005,C8000	C-CERAMIC,CHIP
2203-009733	C8001,C8034,C9067	C-CERAMIC,CHIP
2203-009733	C9068,C9069,C9071	C-CERAMIC,CHIP
2703-002858	L1043	INDUCTOR-SMD
2703-002900	U1000,U1008	INDUCTOR-SMD
2703-002907	L1042	INDUCTOR-SMD
2703-002955	L1047,L1048,L1050	INDUCTOR-SMD
2703-002955	L1051	INDUCTOR-SMD
2703-002958	L3004	INDUCTOR-SMD
2703-002959	L7011,L7012	INDUCTOR-SMD
2703-003293	L3013,L3014	INDUCTOR-SMD
2703-004000	L1028,L1032,L1033	INDUCTOR-SMD
2703-004000	L1037	INDUCTOR-SMD
2703-004012	C1025,C1038,C1079	INDUCTOR-SMD
2703-004012	C2004,C2039,C3115	INDUCTOR-SMD
2703-004012	L1003,L1006,L1007	INDUCTOR-SMD
2703-004012	L1034,L1039,L1041	INDUCTOR-SMD
2703-004012	L2017	INDUCTOR-SMD
2703-004013	C1070,L3006	INDUCTOR-SMD
2703-004018	L1029,L2003	INDUCTOR-SMD
2703-004032	C2020,C2031,L2007	INDUCTOR-SMD
2703-004033	C1123,C1144	INDUCTOR-SMD
2703-004034	C1043,C1054,C3044	INDUCTOR-SMD
2703-004034	L1015,L1031,L1049	INDUCTOR-SMD
2703-004034	L2009,L2012	INDUCTOR-SMD
2703-004035	C1040,L1001,L1017	INDUCTOR-SMD
2703-004035	L1059,L2002	INDUCTOR-SMD
2703-004037	C2013,C2014,L1012	INDUCTOR-SMD
2703-004037	L1022,L1036,L1040	INDUCTOR-SMD
2703-004037	L1046,L2005	INDUCTOR-SMD
2703-004038	C2006,C2008,C3056	INDUCTOR-SMD
2703-004038	L1004,L2001,L2013	INDUCTOR-SMD
2703-004230	L6008,L6009	INDUCTOR-SMD
2703-004286	C3054	INDUCTOR-SMD

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.



## 5. MAIN Electrical Parts List

2703-004295	L6000,L6001	INDUCTOR-SMD
2703-004328	C1100,L1011,L1013	INDUCTOR-SMD
2703-004328	L1019,L1023,L1055	INDUCTOR-SMD
2703-004363	C1015	INDUCTOR-SMD
2703-004366	L1035,L3010	INDUCTOR-SMD
2703-004367	C1050,L1005,L1038	INDUCTOR-SMD
2703-004367	L2006	INDUCTOR-SMD
2703-004369	L3017	INDUCTOR-SMD
2703-004371	L6003	INDUCTOR-SMD
2703-004684	L4000	INDUCTOR-SMD
2703-004718	L5004,L5005	INDUCTOR-SMD
2703-004763	L2010,L2015	INDUCTOR-SMD
2703-004764	C1058,C1107,C1126	INDUCTOR-SMD
2703-004764	L2008	INDUCTOR-SMD
2703-004862	C3053	INDUCTOR-SMD
2703-004901	L5006,L5007	INDUCTOR-SMD
2703-004911	L1018	INDUCTOR-SMD
2703-004947	L5002,L5003	INDUCTOR-SMD
2703-004976	C1090	INDUCTOR-SMD
2703-005007	L7006	INDUCTOR-SMD
2703-005058	L1008	INDUCTOR-SMD
2703-005066	L8000,L8003	INDUCTOR-SMD
2703-005070	L7005,L7007	INDUCTOR-SMD
2703-005086	L3001,L3002	INDUCTOR-SMD
2703-005089	L1016,L1020	INDUCTOR-SMD
2703-005100	U8025,U8038	INDUCTOR-SMD
2703-005101	L2000	INDUCTOR-SMD
2703-005136	L4001,L5000,L5008	INDUCTOR-SMD
2703-005200	L5009	INDUCTOR-SMD
2703-005201	L5010,L5011,L5012	INDUCTOR-SMD
2703-005219	L8001,L8002	INDUCTOR-SMD
2801-005300	OSC5000	CRYSTAL-UNIT
2801-005323	OSC3000	CRYSTAL-UNIT
2901-001786	F7010,F7011,F7012	FILTER-EMI
2901-001786	F7013,F7014	FILTER-EMI
2901-001798	F7000,F7001,F7002	FILTER-EMI
2901-001798	F7003,F7004,F7005	FILTER-EMI
2901-001798	F7006,F7007,F7008	FILTER-EMI
2901-001798	F7009	FILTER-EMI

## 5. MAIN Electrical Parts List

2903-001535	F1003	FILTER-CERAMIC
2904-002257	F2004	FILTER-SAW
2904-002266	F2003	FILTER-SAW
2904-002269	F2002	FILTER-SAW
2904-002306	F1010	FILTER-SAW
2904-002314	F3000	FILTER-SAW
2904-002336	F2006	FILTER-SAW
2904-002349	U8039	FILTER-SAW
2904-002355	F3003,F3004	FILTER-SAW
2910-000365	F1006	FILTER
2910-000367	F1008	FILTER
2911-000308	U3004	FILTER
2911-000407	F1002	FILTER
2911-000430	F2005	FILTER
3003-001233	MIC8000	MIC-CONDENSOR
3301-002078	L8004	CORE-FERRITE
3301-002223	L7000,L7004	CORE-FERRITE
3301-002235	L8008	CORE-FERRITE
3301-002236	L1058	CORE-FERRITE
3301-002237	L6005,L6007,R6056	CORE-FERRITE
3301-002238	L3009	CORE-FERRITE
3301-002286	L6014,L8006	CORE-FERRITE
3301-002309	L7002,L7003	CORE-FERRITE
3301-002312	L7008,L7009,L7010	CORE-FERRITE
3301-002313	L3000	CORE-FERRITE
3301-002331	L5001,L6006	CORE-FERRITE
3301-002335	L8007	CORE-FERRITE
3705-001937	CN1000,CN1001,CN1002	CONNECTOR-COAXIAL
3705-001937	CN1003	CONNECTOR-COAXIAL
3709-001873	SIM6000	CONNECTOR-CARD
3709-001879	CN6000	CONNECTOR-CARD
3711-007107	HEA7000	CONNECTOR-HEADER
3711-008182	HDC7001	CONNECTOR-HEADER
3711-008508	HDC7000	CONNECTOR-HEADER
3711-008847	BTC5000	CONNECTOR-HEADER
3711-009058	HEA3000	CONNECTOR-HEADER
3711-009073	HEA6000	CONNECTOR-HEADER
3712-001604	ANT1000,ANT1001	CONNECTOR
3712-001604	ANT2002,ANT2003	CONNECTOR

## 5. MAIN Electrical Parts List

3712-001604	ANT2009,ANT3000	CONNECTOR
3712-001604	ANT3001,ANT3003	CONNECTOR
3712-001604	ANT3007,ANT3010	CONNECTOR
3712-001621	ANT3005,ANT3006	CONNECTOR
3712-001621	ANT8002,ANT8003	CONNECTOR
3712-001626	ANT8000,ANT8001	CONNECTOR
3712-001633	ANT3008,ANT6005	CONNECTOR
3712-001633	ANT6006	CONNECTOR
3712-001634	ANT2007	CONNECTOR
3712-001656	ANT3004	CONNECTOR
3712-001666	ANT6000,ANT6001	CONNECTOR
3712-001666	ANT6002,ANT6003	CONNECTOR
3712-001666	ANT6004	CONNECTOR
3712-001694	ANT2000,ANT2001	CONNECTOR
3712-001694	ANT2004,ANT2006	CONNECTOR
3712-001694	ANT3002	CONNECTOR
4709-002150	F3002	RF-MODULE
4709-002196	F1004	RF-MODULE
4709-002285	F3005	RF-MODULE
4709-002351	F3001	RF-MODULE
4709-002387	F1001	RF-MODULE
4709-002412	F1005	RF-MODULE
4709-002416	F2001	RF-MODULE
4709-002464	F2000	RF-MODULE
4709-002484	F1000	RF-MODULE
GH60-00009A	CON1001,CON1002	C-CLIP
GH60-00009A	CON1003	C-CLIP
GH60-00010A	CON1005,CON1006	C-CLIP
GH61-08634A	CON1000,CON1004	C-CLIP
GH61-09798A	SUS2000	PLATE
GH62-00040A	CON7000	Heat Part-ETC
GH63-13669A	SC1002	SHIELD CAN
GH63-13670A	SC1004	SHIELD CAN
GH63-13671A	SC1006	SHIELD CAN
GH63-13672A	SC1003	SHIELD CAN
GH63-13674A	SC1000	SHIELD CAN
GH63-13675A	SC1007	SHIELD CAN
GH63-13676A	SC1001	SHIELD CAN
GH63-14299A	SC1005	SHIELD CAN

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

## 5. MAIN Electrical Parts List

---

Please consult the GSPN website (Samsung Portal) for the most recent version of the product's part list.