

5. MAIN Electrical Parts List

[SM-A805F]

Parts Code	Design LOC	Description
0404-001250	D6000	DIODE-SCHOTTKY
0406-001592	ZD4002	DIODE-TVS
0406-001728	ZD1000,ZD5000	DIODE-TVS
0406-001809	ZD6003,ZD6004	DIODE-TVS
0406-001829	ZD5001	DIODE-TVS
0505-003234	Q5002,TR5001	FET-SILICON
0505-003618	TR4001	FET-SILICON
0801-003639	U4001	IC
1001-001755	U5000	IC
1001-001844	U1005	IC
1001-002046	U2005	IC
1001-002063	U1002	IC
1001-002065	U2000,U3001,U3003	IC
1003-003042	U8000	IC
1009-001074	U3015	IC
1009-001079	U3004,U3014	IC
1108-000662	UME6000	MEMORY
1201-003869	U3008	IC
1201-004029	U1001,U1003	IC
1201-004109	PAM1001	IC
1201-004200	U8431	IC
1201-004209	PAM1000	IC
1201-004229	U8002	IC
1203-007365	U8001	IC
1203-008249	U3000	IC
1203-008322	U7000	IC
1203-008859	U8004	IC
1203-008865	U7004	IC
1203-008867	U3012,U7010	IC
1203-008872	U6004,U7009	IC
1203-008989	U3002	IC
1203-009054	U6006	IC
1203-009220	U7007	IC
1203-009221	U7016	IC
1203-009227	U7002	IC
1203-009240	U2006	IC
1203-009248	U5002	IC

5. MAIN Electrical Parts List

1203-009253	U5007	IC
1203-009254	U5009	IC
1204-003781	U8426	IC
1205-005731	U3017	IC
1205-005833	U2003	IC
1205-006037	U4000	IC
1205-006115	U3010	IC
1205-006119	UCP400	IC
1209-002450	U3007	IC
1209-002513	U3006	IC
1209-002629	U3005	IC
1209-002649	U3011	IC
1404-001724	TH2000,TH3000,TH4000	THERMISTOR
1405-001403	V6002,V6004	VARISTOR
1405-001415	V2000,V2003,VR2002	VARISTOR
1405-001415	VR3000,VR3001	VARISTOR
1405-001416	V6000	VARISTOR
2007-003015	R6002,R6003	R-CHIP
2007-007099	R5011	R-CHIP
2007-007741	R2001,R3001,R4013	R-CHIP
2007-007741	R4032,R4035,R4036	R-CHIP
2007-007741	R4039,R5002,R6009	R-CHIP
2007-007741	R6012,R6015	R-CHIP
2007-008050	R3003,R3008	R-CHIP
2007-008054	R4043	R-CHIP
2007-008056	R1000,R1001	R-CHIP
2007-008263	R4041	R-CHIP
2007-008420	R4005,R5013	R-CHIP
2007-008516	R6004,R6005,R6006	R-CHIP
2007-008531	R4002,R7000,R7001	R-CHIP
2007-008588	R3005,R3006,R4003	R-CHIP
2007-008588	R4004,R4006,R4007	R-CHIP
2007-008588	R4008,R4009,R4010	R-CHIP
2007-008588	R4011,R4014,R4015	R-CHIP
2007-008588	R4016,R4017,R4018	R-CHIP
2007-008588	R4019,R4020,R4021	R-CHIP
2007-008588	R4022,R4023	R-CHIP
2007-008766	R4024,R4025	R-CHIP
2007-008785	R1004	R-CHIP

5. MAIN Electrical Parts List

2007-008798	R8000,R8001	R-CHIP
2007-008808	R7002	R-CHIP
2007-009111	R3000,R3004,R5000	R-CHIP
2007-009157	R4045,R5021	R-CHIP
2007-009171	R3007,R6014	R-CHIP
2007-009212	R4033,R4040,R5019	R-CHIP
2007-009212	R5020,R6020,R8014	R-CHIP
2007-009352	R4026,R6007,R8006	R-CHIP
2007-009352	R8007	R-CHIP
2007-009408	R4027,R4028,R6010	R-CHIP
2007-009408	R8004,R8005	R-CHIP
2007-009410	R8012	R-CHIP
2007-009801	R4037,R4038	R-CHIP
2007-009805	R1002,R1003,R2000	R-CHIP
2007-009805	R3002	R-CHIP
2007-009920	R4000,R6000,R6001	R-CHIP
2007-009954	R6008	R-CHIP
2007-009969	R3009,R3010	R-CHIP
2007-010202	R5010,R8015	R-CHIP
2007-010685	R4034	R-CHIP
2007-011043	R4044	R-CHIP
2007-011648	R8002,R8003,R8023	R-CHIP
2007-011648	R8024	R-CHIP
2203-000311	C3097,C3105	C-CERAMIC,CHIP
2203-000386	C3102	C-CERAMIC,CHIP
2203-001153	C3101	C-CERAMIC,CHIP
2203-005682	C2074,C2076,C2078	C-CERAMIC,CHIP
2203-005682	C4069,C4070,C6037	C-CERAMIC,CHIP
2203-005682	C6038,C6039	C-CERAMIC,CHIP
2203-005719	C1108	C-CERAMIC,CHIP
2203-005725	C1020	C-CERAMIC,CHIP
2203-005729	C7003	C-CERAMIC,CHIP
2203-005734	C1017,C1117,C1118	C-CERAMIC,CHIP
2203-005736	C1004,C1005,C1010	C-CERAMIC,CHIP
2203-005736	C1014,C1018,C1025	C-CERAMIC,CHIP
2203-005736	C1027,C1028,C1031	C-CERAMIC,CHIP
2203-005736	C1035,C1054,C1069	C-CERAMIC,CHIP
2203-005736	C1073,C1078,C2003	C-CERAMIC,CHIP
2203-005736	C2027,C2028,C2030	C-CERAMIC,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2203-005736	C2031,C2032,C2035	C-CERAMIC,CHIP
2203-005736	C2047,C2053,C2070	C-CERAMIC,CHIP
2203-005736	C2080,C2081,C2082	C-CERAMIC,CHIP
2203-005736	C3003,C3005,C3009	C-CERAMIC,CHIP
2203-005736	C3025,C3061,C3062	C-CERAMIC,CHIP
2203-005736	C3068,C3069,C3071	C-CERAMIC,CHIP
2203-005736	C3077,C3111	C-CERAMIC,CHIP
2203-005740	C8030	C-CERAMIC,CHIP
2203-005777	C1012,C1032,C1033	C-CERAMIC,CHIP
2203-005777	C1074,C1106,C1112	C-CERAMIC,CHIP
2203-005777	C2004,C3006	C-CERAMIC,CHIP
2203-005789	C1001,C1015,C1022	C-CERAMIC,CHIP
2203-005789	C1034,C1036,C1044	C-CERAMIC,CHIP
2203-005789	C1047,C1050,C1071	C-CERAMIC,CHIP
2203-005789	C1075,C1082,C1084	C-CERAMIC,CHIP
2203-005789	C1115,C1116,C1119	C-CERAMIC,CHIP
2203-005789	C1120,C2001,L3026	C-CERAMIC,CHIP
2203-005792	C1046,C3002	C-CERAMIC,CHIP
2203-005806	C1097	C-CERAMIC,CHIP
2203-006047	C5021,C5063	C-CERAMIC,CHIP
2203-006120	C5120,C5121	C-CERAMIC,CHIP
2203-006305	C1093,C3010,C3012	C-CERAMIC,CHIP
2203-006305	C3076	C-CERAMIC,CHIP
2203-006318	C1045,C1068,C2040	C-CERAMIC,CHIP
2203-006318	C3000	C-CERAMIC,CHIP
2203-006400	C3067,C3098,C3100	C-CERAMIC,CHIP
2203-006400	C5087	C-CERAMIC,CHIP
2203-006410	C1067	C-CERAMIC,CHIP
2203-006426	C8010,C8012	C-CERAMIC,CHIP
2203-006556	C1061,C1062,C1096	C-CERAMIC,CHIP
2203-006611	C1081	C-CERAMIC,CHIP
2203-006648	C8121	C-CERAMIC,CHIP
2203-006665	C3079	C-CERAMIC,CHIP
2203-006674	C1016	C-CERAMIC,CHIP
2203-006839	C3087,C3094,C4067	C-CERAMIC,CHIP
2203-006839	C4080,C5027,C5091	C-CERAMIC,CHIP
2203-006839	C8001,C8006,C8129	C-CERAMIC,CHIP
2203-006846	C1066	C-CERAMIC,CHIP
2203-007143	C5001	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-007194	C3016,C3019	C-CERAMIC,CHIP
2203-007210	C3056,C3084,C4025	C-CERAMIC,CHIP
2203-007210	C4026,C4033,C4034	C-CERAMIC,CHIP
2203-007271	C1098,C1123,C7009	C-CERAMIC,CHIP
2203-007271	C7020	C-CERAMIC,CHIP
2203-007317	C3036,C3038,C3044	C-CERAMIC,CHIP
2203-007317	C5070,C5072,C5073	C-CERAMIC,CHIP
2203-007317	C5074,C5095,C5096	C-CERAMIC,CHIP
2203-007317	C5105,C5109,C5110	C-CERAMIC,CHIP
2203-007317	C5115,C5118,C6003	C-CERAMIC,CHIP
2203-007317	C6008,C7006,C7010	C-CERAMIC,CHIP
2203-007317	C7038,C7039,C7043	C-CERAMIC,CHIP
2203-007317	C8022,C8128	C-CERAMIC,CHIP
2203-007391	C3049,C3051,C3052	C-CERAMIC,CHIP
2203-007391	C3090,C8016	C-CERAMIC,CHIP
2203-007392	C8048,C8130	C-CERAMIC,CHIP
2203-007393	C2005,C2008,C2017	C-CERAMIC,CHIP
2203-007393	C2021,C2026,C2075	C-CERAMIC,CHIP
2203-007393	C3092,C3093,C6012	C-CERAMIC,CHIP
2203-007393	C6014,C6047,C6048	C-CERAMIC,CHIP
2203-007393	C7042,C8013	C-CERAMIC,CHIP
2203-007403	C2029	C-CERAMIC,CHIP
2203-007456	C5039	C-CERAMIC,CHIP
2203-007474	C4046,C5088,C5093	C-CERAMIC,CHIP
2203-007474	C7019	C-CERAMIC,CHIP
2203-007503	C8000	C-CERAMIC,CHIP
2203-007544	C3004,C3011,C3064	C-CERAMIC,CHIP
2203-007621	C1000,C1002,C1038	C-CERAMIC,CHIP
2203-007621	C2006,C2007,C2009	C-CERAMIC,CHIP
2203-007621	C2010,C2011,C2012	C-CERAMIC,CHIP
2203-007621	C2013,C2014,C2015	C-CERAMIC,CHIP
2203-007621	C2016,C2018,C2019	C-CERAMIC,CHIP
2203-007621	C2020,C2022,C2023	C-CERAMIC,CHIP
2203-007621	C2024,C2025,C2054	C-CERAMIC,CHIP
2203-007621	C2058,C3014,C3015	C-CERAMIC,CHIP
2203-007621	C3020,C3065,C3066	C-CERAMIC,CHIP
2203-007621	C3075,C3096,C3103	C-CERAMIC,CHIP
2203-007621	C4016,C4017,C5119	C-CERAMIC,CHIP
2203-007621	C7054	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-007687	C6043	C-CERAMIC,CHIP
2203-007796	C3007,C3008,C3023	C-CERAMIC,CHIP
2203-007796	C3037,C3081,C3082	C-CERAMIC,CHIP
2203-007796	C3083,C4002,C4003	C-CERAMIC,CHIP
2203-007796	C4004,C4005,C4006	C-CERAMIC,CHIP
2203-007796	C4007,C4008,C4009	C-CERAMIC,CHIP
2203-007796	C4010,C4011,C4013	C-CERAMIC,CHIP
2203-007796	C4014,C4015,C4019	C-CERAMIC,CHIP
2203-007796	C4020,C4021,C4023	C-CERAMIC,CHIP
2203-007796	C4024,C4027,C4028	C-CERAMIC,CHIP
2203-007796	C4030,C4031,C4032	C-CERAMIC,CHIP
2203-007796	C4037,C4038,C4039	C-CERAMIC,CHIP
2203-007796	C4040,C4041,C4042	C-CERAMIC,CHIP
2203-007796	C4044,C4045,C4047	C-CERAMIC,CHIP
2203-007796	C4048,C4050,C4052	C-CERAMIC,CHIP
2203-007796	C4053,C4054,C4055	C-CERAMIC,CHIP
2203-007796	C4056,C4061,C4063	C-CERAMIC,CHIP
2203-007796	C4064,C4065,C4066	C-CERAMIC,CHIP
2203-007796	C4068,C4073,C4074	C-CERAMIC,CHIP
2203-007796	C4076,C4077,C4078	C-CERAMIC,CHIP
2203-007796	C4081,C4085,C4086	C-CERAMIC,CHIP
2203-007796	C4087,C4093,C4094	C-CERAMIC,CHIP
2203-007796	C4095,C5049,C5064	C-CERAMIC,CHIP
2203-007796	C5065,C5066,C5067	C-CERAMIC,CHIP
2203-007796	C5068,C5069,C5071	C-CERAMIC,CHIP
2203-007796	C5075,C5084,C5089	C-CERAMIC,CHIP
2203-007796	C5094,C5097,C5098	C-CERAMIC,CHIP
2203-007796	C5099,C5102,C5103	C-CERAMIC,CHIP
2203-007796	C5104,C5106,C5108	C-CERAMIC,CHIP
2203-007796	C5111,C5113,C5117	C-CERAMIC,CHIP
2203-007796	C6000,C6002,C6005	C-CERAMIC,CHIP
2203-007796	C6006,C6007,C6009	C-CERAMIC,CHIP
2203-007796	C6013,C6015,C6016	C-CERAMIC,CHIP
2203-007796	C6020,C6022,C6024	C-CERAMIC,CHIP
2203-007796	C6025,C6028,C6029	C-CERAMIC,CHIP
2203-007796	C6030,C6032,C6035	C-CERAMIC,CHIP
2203-007796	C6036,C7004,C7011	C-CERAMIC,CHIP
2203-007796	C7015,C7021,C7022	C-CERAMIC,CHIP
2203-007796	C7041,C7059,C8015	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-007796	C8033,C8034,C8040	C-CERAMIC,CHIP
2203-007796	C8049,C8050,C8052	C-CERAMIC,CHIP
2203-007796	C8053,C8122,C8123	C-CERAMIC,CHIP
2203-007796	C8124	C-CERAMIC,CHIP
2203-008095	C4000	C-CERAMIC,CHIP
2203-008097	C1056,C1060,C1063	C-CERAMIC,CHIP
2203-008097	C5032,C5050,C8018	C-CERAMIC,CHIP
2203-008242	C3053,C3086,C3088	C-CERAMIC,CHIP
2203-008242	C6017,C6018,C7007	C-CERAMIC,CHIP
2203-008242	C7023,C7053	C-CERAMIC,CHIP
2203-008243	C8023	C-CERAMIC,CHIP
2203-008394	C1053	C-CERAMIC,CHIP
2203-008400	C1049,C1104,C2063	C-CERAMIC,CHIP
2203-008400	C3039,C3040,C3041	C-CERAMIC,CHIP
2203-008400	C3043,C3045,C3046	C-CERAMIC,CHIP
2203-008400	C3047,C3054,C3055	C-CERAMIC,CHIP
2203-008400	C3057,C3058,C3059	C-CERAMIC,CHIP
2203-008400	C3060	C-CERAMIC,CHIP
2203-008403	C3001,C3030,C3032	C-CERAMIC,CHIP
2203-008403	C8025,C8029	C-CERAMIC,CHIP
2203-008463	C1003,C1013,C7001	C-CERAMIC,CHIP
2203-008466	C1023,C2046,C2057	C-CERAMIC,CHIP
2203-008572	C5024,C5045	C-CERAMIC,CHIP
2203-008654	C6042	C-CERAMIC,CHIP
2203-008749	C5056	C-CERAMIC,CHIP
2203-008844	C7033	C-CERAMIC,CHIP
2203-008860	C1101,C2059,C3022	C-CERAMIC,CHIP
2203-008860	C3085,C5000,C5017	C-CERAMIC,CHIP
2203-008860	C5022,C5026,C5028	C-CERAMIC,CHIP
2203-008860	C5029,C5030,C5031	C-CERAMIC,CHIP
2203-008860	C5037,C5042,C5046	C-CERAMIC,CHIP
2203-008860	C5047,C5048,C5051	C-CERAMIC,CHIP
2203-008860	C5053,C5076,C5077	C-CERAMIC,CHIP
2203-008860	C5079,C5081,C5090	C-CERAMIC,CHIP
2203-008860	C5092,C6010,C6019	C-CERAMIC,CHIP
2203-008860	C6023,C6027,C6051	C-CERAMIC,CHIP
2203-008860	C7014,C7028,C7035	C-CERAMIC,CHIP
2203-008860	C7058,C8017,C8027	C-CERAMIC,CHIP
2203-008860	C8035	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-008876	C3089,C3091,C6026	C-CERAMIC,CHIP
2203-008876	C6033,C6034,C7018	C-CERAMIC,CHIP
2203-008876	C7026,C7036,C7044	C-CERAMIC,CHIP
2203-008876	C7050,C7051,C7055	C-CERAMIC,CHIP
2203-008876	C7056,C7136,C8042	C-CERAMIC,CHIP
2203-009064	C4018,C4029,C4035	C-CERAMIC,CHIP
2203-009064	C4036,C4079,C4083	C-CERAMIC,CHIP
2203-009064	C4084	C-CERAMIC,CHIP
2203-009167	C3099,C3104	C-CERAMIC,CHIP
2203-009444	C8038	C-CERAMIC,CHIP
2203-009618	C5016,C5018,C5019	C-CERAMIC,CHIP
2203-009618	C5020,C7061,C8004	C-CERAMIC,CHIP
2203-009618	C8011,C8019,C8037	C-CERAMIC,CHIP
2203-009733	C5004,C5008,C5010	C-CERAMIC,CHIP
2203-009733	C5011,C5034,C5035	C-CERAMIC,CHIP
2203-009733	C5038,C5040,C5041	C-CERAMIC,CHIP
2203-009733	C5043,C5044,C5052	C-CERAMIC,CHIP
2203-009733	C5054,C5057,C5060	C-CERAMIC,CHIP
2203-009733	C5061,C5062,C5078	C-CERAMIC,CHIP
2203-009733	C5082,C5086,C7008	C-CERAMIC,CHIP
2203-009733	C7012,C7013,C7016	C-CERAMIC,CHIP
2203-009733	C7017,C7071,C7072	C-CERAMIC,CHIP
2203-009733	C7073,C7074,C7075	C-CERAMIC,CHIP
2203-009733	C7076,C7078,C7079	C-CERAMIC,CHIP
2203-009733	C7080,C7081,C7082	C-CERAMIC,CHIP
2203-009734	C6021	C-CERAMIC,CHIP
2203-009735	C4057,C4058	C-CERAMIC,CHIP
2203-009858	C1064,C2060,C5036	C-CERAMIC,CHIP
2203-009858	C7027,C7062,C7063	C-CERAMIC,CHIP
2203-009858	C7064,C7065,C7066	C-CERAMIC,CHIP
2203-009858	C7067,C7068,C8007	C-CERAMIC,CHIP
2203-009858	C8055	C-CERAMIC,CHIP
2203-009859	C7005,C8020	C-CERAMIC,CHIP
2203-010066	C5025,C6046	C-CERAMIC,CHIP
2203-010085	C4001,C4012,C5080	C-CERAMIC,CHIP
2703-002649	L1032,L1045,L1070	INDUCTOR-SMD
2703-002901	L2008,L3019	INDUCTOR-SMD
2703-002903	L1004,L3018,L3025	INDUCTOR-SMD
2703-002907	L1027,L3027	INDUCTOR-SMD

5. MAIN Electrical Parts List

2703-002951	L1021,L2014,L3032	INDUCTOR-SMD
2703-002953	L1025	INDUCTOR-SMD
2703-002955	L3007	INDUCTOR-SMD
2703-002958	L1020,L1026	INDUCTOR-SMD
2703-002959	L2013,L3036,L8009	INDUCTOR-SMD
2703-002961	L6003	INDUCTOR-SMD
2703-002999	L1029,L2009	INDUCTOR-SMD
2703-004001	L1017,L2000	INDUCTOR-SMD
2703-004012	L1033,L1051,L2016	INDUCTOR-SMD
2703-004013	L1006,L2041,L3010	INDUCTOR-SMD
2703-004013	L3011	INDUCTOR-SMD
2703-004014	L1010,L1016,L1041	INDUCTOR-SMD
2703-004014	L2036,L3006,L3014	INDUCTOR-SMD
2703-004014	L3015,L3017	INDUCTOR-SMD
2703-004018	L1037	INDUCTOR-SMD
2703-004034	L2012,L2033	INDUCTOR-SMD
2703-004037	L2005,L2010,L2021	INDUCTOR-SMD
2703-004038	L1013,L1042,L1077	INDUCTOR-SMD
2703-004038	L2024,L2031,L2032	INDUCTOR-SMD
2703-004038	L2040	INDUCTOR-SMD
2703-004193	L6004,L6005	INDUCTOR-SMD
2703-004286	L1002,L1031,L1036	INDUCTOR-SMD
2703-004286	L1038,L1063,L1065	INDUCTOR-SMD
2703-004286	L1079,L2004,L2020	INDUCTOR-SMD
2703-004286	L2025,L2027,L2028	INDUCTOR-SMD
2703-004287	L1007,L1024,L1039	INDUCTOR-SMD
2703-004287	L2003,L2023,L2026	INDUCTOR-SMD
2703-004288	L1005,L1011,L1028	INDUCTOR-SMD
2703-004288	L1034,L1056,L1078	INDUCTOR-SMD
2703-004288	L2002,L2018,L2037	INDUCTOR-SMD
2703-004288	L3034	INDUCTOR-SMD
2703-004289	L3016	INDUCTOR-SMD
2703-004299	L3012	INDUCTOR-SMD
2703-004302	L1003,L1019,L1055	INDUCTOR-SMD
2703-004302	L3001,L3003,L3013	INDUCTOR-SMD
2703-004302	L6001,L6002	INDUCTOR-SMD
2703-004317	L2034	INDUCTOR-SMD
2703-004328	L1043,L3022,L3033	INDUCTOR-SMD
2703-004362	L2029	INDUCTOR-SMD

5. MAIN Electrical Parts List

2703-004368	L1014,L1018,L1022	INDUCTOR-SMD
2703-004703	L2011	INDUCTOR-SMD
2703-004763	L1080	INDUCTOR-SMD
2703-004853	L2006,L3037	INDUCTOR-SMD
2703-004862	L1030,L1035	INDUCTOR-SMD
2703-005098	L2030	INDUCTOR-SMD
2703-005224	L7009	INDUCTOR-SMD
2703-005295	L2022	INDUCTOR-SMD
2703-005418	L7006	INDUCTOR-SMD
2703-005419	L7007	INDUCTOR-SMD
2703-005445	L2019	INDUCTOR-SMD
2703-005505	L7003,L8002,L8003	INDUCTOR-SMD
2703-005505	L8008	INDUCTOR-SMD
2703-005555	L3042,L3045	INDUCTOR-SMD
2703-005581	L5001,L5002,L5005	INDUCTOR-SMD
2703-005581	L5006,L5007,L5009	INDUCTOR-SMD
2703-005581	L5012,L5013,L5014	INDUCTOR-SMD
2703-005660	L5000,L5003,L5004	INDUCTOR-SMD
2703-005660	L5008,L5010	INDUCTOR-SMD
2703-005738	L5011	INDUCTOR-SMD
2801-005481	OSC5000	CRYSTAL-UNIT
2901-001690	C4059	FILTER-EMI SMD
2903-001576	F3000,F3001	FILTER-CERAMIC
2904-002143	F1012	FILTER-SAW
2904-002257	F2005	FILTER-SAW
2904-002285	F1006	FILTER-SAW
2904-002326	F2006	FILTER-SAW
2904-002339	F2003	FILTER-SAW
2904-002356	F3006,F3007	FILTER-SAW
2904-002381	F3003,F3004	FILTER-SAW
2904-002397	F1005,F2004	FILTER-SAW
2910-000401	F1011	FILTER
2911-000435	U2007	FILTER
2911-000458	U1004	FILTER
3301-002122	L7013,L8000,L8001	CORE-FERRITE BEAD
3301-002223	L7000,L7001	CORE-FERRITE BEAD
3301-002236	L7004,L7011,L7012	CORE-FERRITE BEAD
3301-002236	L7014	CORE-FERRITE BEAD
3301-002237	L1000,L1001	CORE-FERRITE BEAD

5. MAIN Electrical Parts List

3301-002238	L3000,L3031	CORE-FERRITE BEAD
3301-002286	L3043,L3044	CORE-FERRITE BEAD
3301-002312	L7005,L7008,L7010	CORE-FERRITE BEAD
3301-002331	L7002	CORE-FERRITE BEAD
3301-002336	L6000	CORE-FERRITE BEAD
3705-001937	RFS1000,RFS1001	CONNECTOR-COAXIAL
3705-001937	RFS2000	CONNECTOR-COAXIAL
3710-004008	SOC5000	CONNECTOR-SOCKET
3710-004109	HEA8000	CONNECTOR-SOCKET
3710-004285	SOC6000	CONNECTOR-SOCKET
3710-004367	SOC7000,SOC7001	CONNECTOR-SOCKET
3712-001694	ANT2001,ANT2002	CONNECTOR
3712-001694	ANT2003,ANT2004	CONNECTOR
3712-001694	ANT3002,ANT6000	CONNECTOR
3712-001694	ANT6001,ANT6002	CONNECTOR
3712-001694	ANT6003,ANT6007	CONNECTOR
3712-001694	ANT8000,ANT8001	CONNECTOR
3712-001731	ANT2000	CONNECTOR
3712-001749	ANT2005,ANT3000	CONNECTOR
3712-001749	ANT3001,ANT3003	CONNECTOR
3712-001749	ANT3006	CONNECTOR
4709-002226	F1000,F2002	RF-MODULE
4709-002285	F3002,F3008	RF-MODULE
4709-002351	F3005	RF-MODULE
4709-002589	F1004	RF-MODULE
GH63-17218A	SC6001	SC- AP
GH63-17219A	SC6003	SC -RF
GH63-17220A	SC6002	SC- PMIC
GH63-17221A	SC6000	SC -WIFI
rf-A90_AP_TAPE	SC6001SP	AP_TAPE

5. MAIN Electrical Parts List

[SM-A8050]

Part Code	Design LOC	Description
0404-001250	D6000	DIODE-SCHOTTKY
0406-001592	ZD4002	DIODE-TVS
0406-001728	ZD1000,ZD5000	DIODE-TVS
0406-001809	ZD6003,ZD6004	DIODE-TVS
0406-001829	ZD5001	DIODE-TVS
0505-003234	Q5002,TR5001	FET-SILICON
0505-003618	TR4001	FET-SILICON
0801-003639	U4001	IC
1001-001755	U5000	IC
1001-001844	U1005	IC
1001-002046	U2005	IC
1001-002063	U1002	IC
1001-002065	U2000,U3001,U3003	IC
1003-002805	U3013	IC
1003-003042	U8000	IC
1009-001074	U3015	IC
1009-001079	U3004,U3014	IC
1108-000662	UME6000	MEMORY
1201-003869	U3008	IC
1201-004029	U1001,U1003	IC
1201-004109	PAM1001	IC
1201-004200	U8431	IC
1201-004209	PAM1000	IC
1201-004229	U8002	IC
1203-007365	U8001	IC
1203-008249	U3000	IC
1203-008322	U7000	IC
1203-008859	U8004	IC
1203-008865	U7004	IC
1203-008867	U3012,U7010	IC
1203-008872	U6004,U7009	IC
1203-008989	U3002	IC
1203-009054	U6006	IC
1203-009220	U7007	IC
1203-009221	U7016	IC
1203-009227	U7002	IC
1203-009240	U2006	IC

5. MAIN Electrical Parts List

1203-009248	U5002	IC
1203-009253	U5007	IC
1203-009254	U5009	IC
1204-003781	U8426	IC
1205-005731	U3017	IC
1205-005833	U2003	IC
1205-006037	U4000	IC
1205-006115	U3010	IC
1205-006119	UCP400	IC
1209-002450	U3007	IC
1209-002513	U3006	IC
1209-002629	U3005	IC
1209-002649	U3011	IC
1404-001724	TH2000,TH3000,TH4000	THERMISTOR
1405-001403	V6002,V6004	VARISTOR
1405-001415	V2000,V2003,VR2002	VARISTOR
1405-001415	VR3000,VR3001	VARISTOR
1405-001416	V6000	VARISTOR
2007-003015	R6002,R6003	R-CHIP
2007-007099	R5011	R-CHIP
2007-007741	R2001,R3001,R4012	R-CHIP
2007-007741	R4032,R4035,R4036	R-CHIP
2007-007741	R4039,R5002,R6009	R-CHIP
2007-007741	R6012,R6015	R-CHIP
2007-008050	R3003,R3008	R-CHIP
2007-008054	R4043	R-CHIP
2007-008056	R1000,R1001	R-CHIP
2007-008263	R4041	R-CHIP
2007-008420	R4005,R5013	R-CHIP
2007-008516	R6004,R6005,R6006	R-CHIP
2007-008531	R4002,R7000,R7001	R-CHIP
2007-008588	R3005,R3006,R4003	R-CHIP
2007-008588	R4004,R4006,R4007	R-CHIP
2007-008588	R4008,R4009,R4010	R-CHIP
2007-008588	R4011,R4014,R4015	R-CHIP
2007-008588	R4016,R4017,R4018	R-CHIP
2007-008588	R4019,R4020,R4021	R-CHIP
2007-008588	R4022,R4023	R-CHIP
2007-008766	R4024,R4025	R-CHIP

5. MAIN Electrical Parts List

2007-008785	R1004	R-CHIP
2007-008798	R8000,R8001	R-CHIP
2007-008808	R7002	R-CHIP
2007-009111	R3000,R3004,R5000	R-CHIP
2007-009157	R4045,R5021	R-CHIP
2007-009171	R3007,R6014	R-CHIP
2007-009212	R4033,R4040,R5019	R-CHIP
2007-009212	R5020,R6020,R8014	R-CHIP
2007-009352	R4026,R6007,R8006	R-CHIP
2007-009352	R8007	R-CHIP
2007-009408	R4027,R4028,R6010	R-CHIP
2007-009408	R8004,R8005	R-CHIP
2007-009410	R8012	R-CHIP
2007-009801	R4037,R4038	R-CHIP
2007-009805	R1002,R1003,R2000	R-CHIP
2007-009805	R3002	R-CHIP
2007-009920	R4000,R6000,R6001	R-CHIP
2007-009954	R6008	R-CHIP
2007-009969	R3009,R3010	R-CHIP
2007-010202	R5010,R8015	R-CHIP
2007-010685	R4034	R-CHIP
2007-011043	R4044	R-CHIP
2007-011648	R8002,R8003,R8023	R-CHIP
2007-011648	R8024	R-CHIP
2203-000311	C3097,C3105	C-CERAMIC,CHIP
2203-000330	C3102	C-CERAMIC,CHIP
2203-001153	C3101	C-CERAMIC,CHIP
2203-005682	C2074,C2076,C2078	C-CERAMIC,CHIP
2203-005682	C4069,C4070,C6037	C-CERAMIC,CHIP
2203-005682	C6038,C6039	C-CERAMIC,CHIP
2203-005719	C1108	C-CERAMIC,CHIP
2203-005725	C1020	C-CERAMIC,CHIP
2203-005729	C7003	C-CERAMIC,CHIP
2203-005734	C1017,C1117,C1118	C-CERAMIC,CHIP
2203-005736	C1004,C1005,C1010	C-CERAMIC,CHIP
2203-005736	C1014,C1018,C1025	C-CERAMIC,CHIP
2203-005736	C1027,C1028,C1031	C-CERAMIC,CHIP
2203-005736	C1035,C1054,C1069	C-CERAMIC,CHIP
2203-005736	C1073,C1078,C2003	C-CERAMIC,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2203-005736	C2027,C2028,C2030	C-CERAMIC,CHIP
2203-005736	C2031,C2032,C2035	C-CERAMIC,CHIP
2203-005736	C2047,C2053,C2070	C-CERAMIC,CHIP
2203-005736	C2080,C2081,C2082	C-CERAMIC,CHIP
2203-005736	C3003,C3005,C3009	C-CERAMIC,CHIP
2203-005736	C3025,C3061,C3062	C-CERAMIC,CHIP
2203-005736	C3068,C3069,C3071	C-CERAMIC,CHIP
2203-005736	C3077,C3111	C-CERAMIC,CHIP
2203-005740	C8030	C-CERAMIC,CHIP
2203-005777	C1012,C1032,C1033	C-CERAMIC,CHIP
2203-005777	C1074,C1106,C1112	C-CERAMIC,CHIP
2203-005777	C2004,C3006	C-CERAMIC,CHIP
2203-005789	C1001,C1015,C1022	C-CERAMIC,CHIP
2203-005789	C1034,C1036,C1044	C-CERAMIC,CHIP
2203-005789	C1047,C1050,C1071	C-CERAMIC,CHIP
2203-005789	C1075,C1082,C1084	C-CERAMIC,CHIP
2203-005789	C1115,C1116,C1119	C-CERAMIC,CHIP
2203-005789	C1120,C2001,L3026	C-CERAMIC,CHIP
2203-005792	C1046,C3002	C-CERAMIC,CHIP
2203-005806	C1097	C-CERAMIC,CHIP
2203-006047	C5021,C5063	C-CERAMIC,CHIP
2203-006120	C5120,C5121	C-CERAMIC,CHIP
2203-006305	C1093,C3010,C3012	C-CERAMIC,CHIP
2203-006305	C3076	C-CERAMIC,CHIP
2203-006318	C1045,C1068,C2040	C-CERAMIC,CHIP
2203-006318	C3000	C-CERAMIC,CHIP
2203-006400	C3067,C3098,C3100	C-CERAMIC,CHIP
2203-006400	C5087	C-CERAMIC,CHIP
2203-006410	C1067	C-CERAMIC,CHIP
2203-006426	C8010,C8012	C-CERAMIC,CHIP
2203-006556	C1061,C1062,C1096	C-CERAMIC,CHIP
2203-006611	C1081	C-CERAMIC,CHIP
2203-006648	C8121	C-CERAMIC,CHIP
2203-006665	C3079	C-CERAMIC,CHIP
2203-006674	C1016	C-CERAMIC,CHIP
2203-006839	C3087,C3094,C3108	C-CERAMIC,CHIP
2203-006839	C4067,C4080,C5027	C-CERAMIC,CHIP
2203-006839	C5091,C8001,C8006	C-CERAMIC,CHIP
2203-006839	C8129	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-006846	C1066	C-CERAMIC,CHIP
2203-007143	C5001	C-CERAMIC,CHIP
2203-007194	C3016,C3019	C-CERAMIC,CHIP
2203-007210	C3056,C3084,C4025	C-CERAMIC,CHIP
2203-007210	C4026,C4033,C4034	C-CERAMIC,CHIP
2203-007271	C1098,C1123,C7009	C-CERAMIC,CHIP
2203-007271	C7020	C-CERAMIC,CHIP
2203-007317	C3036,C3038,C3044	C-CERAMIC,CHIP
2203-007317	C5070,C5072,C5073	C-CERAMIC,CHIP
2203-007317	C5074,C5095,C5096	C-CERAMIC,CHIP
2203-007317	C5105,C5109,C5110	C-CERAMIC,CHIP
2203-007317	C5115,C5118,C6003	C-CERAMIC,CHIP
2203-007317	C6008,C7006,C7010	C-CERAMIC,CHIP
2203-007317	C7038,C7039,C7043	C-CERAMIC,CHIP
2203-007317	C8022,C8128	C-CERAMIC,CHIP
2203-007391	C3049,C3051,C3052	C-CERAMIC,CHIP
2203-007391	C3090,C8016	C-CERAMIC,CHIP
2203-007392	C8048,C8130	C-CERAMIC,CHIP
2203-007393	C2005,C2008,C2017	C-CERAMIC,CHIP
2203-007393	C2021,C2026,C2075	C-CERAMIC,CHIP
2203-007393	C3092,C3093,C6012	C-CERAMIC,CHIP
2203-007393	C6014,C6047,C6048	C-CERAMIC,CHIP
2203-007393	C7042,C8013	C-CERAMIC,CHIP
2203-007403	C2029	C-CERAMIC,CHIP
2203-007456	C5039	C-CERAMIC,CHIP
2203-007474	C4046,C5088,C5093	C-CERAMIC,CHIP
2203-007474	C7019	C-CERAMIC,CHIP
2203-007503	C8000	C-CERAMIC,CHIP
2203-007544	C3004,C3011,C3064	C-CERAMIC,CHIP
2203-007621	C1000,C1002,C1038	C-CERAMIC,CHIP
2203-007621	C2006,C2007,C2009	C-CERAMIC,CHIP
2203-007621	C2010,C2011,C2012	C-CERAMIC,CHIP
2203-007621	C2013,C2014,C2015	C-CERAMIC,CHIP
2203-007621	C2016,C2018,C2019	C-CERAMIC,CHIP
2203-007621	C2020,C2022,C2023	C-CERAMIC,CHIP
2203-007621	C2024,C2025,C2054	C-CERAMIC,CHIP
2203-007621	C2058,C3014,C3015	C-CERAMIC,CHIP
2203-007621	C3020,C3065,C3066	C-CERAMIC,CHIP
2203-007621	C3075,C3096,C3103	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-007621	C4016,C4017,C5119	C-CERAMIC,CHIP
2203-007621	C7054	C-CERAMIC,CHIP
2203-007687	C6043	C-CERAMIC,CHIP
2203-007796	C3007,C3008,C3023	C-CERAMIC,CHIP
2203-007796	C3037,C3081,C3082	C-CERAMIC,CHIP
2203-007796	C3083,C4002,C4003	C-CERAMIC,CHIP
2203-007796	C4004,C4005,C4006	C-CERAMIC,CHIP
2203-007796	C4007,C4008,C4009	C-CERAMIC,CHIP
2203-007796	C4010,C4011,C4013	C-CERAMIC,CHIP
2203-007796	C4014,C4015,C4019	C-CERAMIC,CHIP
2203-007796	C4020,C4021,C4023	C-CERAMIC,CHIP
2203-007796	C4024,C4027,C4028	C-CERAMIC,CHIP
2203-007796	C4030,C4031,C4032	C-CERAMIC,CHIP
2203-007796	C4037,C4038,C4039	C-CERAMIC,CHIP
2203-007796	C4040,C4041,C4042	C-CERAMIC,CHIP
2203-007796	C4044,C4045,C4047	C-CERAMIC,CHIP
2203-007796	C4048,C4050,C4052	C-CERAMIC,CHIP
2203-007796	C4053,C4054,C4055	C-CERAMIC,CHIP
2203-007796	C4056,C4061,C4063	C-CERAMIC,CHIP
2203-007796	C4064,C4065,C4066	C-CERAMIC,CHIP
2203-007796	C4068,C4073,C4074	C-CERAMIC,CHIP
2203-007796	C4076,C4077,C4078	C-CERAMIC,CHIP
2203-007796	C4081,C4085,C4086	C-CERAMIC,CHIP
2203-007796	C4087,C4093,C4094	C-CERAMIC,CHIP
2203-007796	C4095,C5049,C5064	C-CERAMIC,CHIP
2203-007796	C5065,C5066,C5067	C-CERAMIC,CHIP
2203-007796	C5068,C5069,C5071	C-CERAMIC,CHIP
2203-007796	C5075,C5084,C5089	C-CERAMIC,CHIP
2203-007796	C5094,C5097,C5098	C-CERAMIC,CHIP
2203-007796	C5099,C5102,C5103	C-CERAMIC,CHIP
2203-007796	C5104,C5106,C5108	C-CERAMIC,CHIP
2203-007796	C5111,C5113,C5117	C-CERAMIC,CHIP
2203-007796	C6000,C6002,C6005	C-CERAMIC,CHIP
2203-007796	C6006,C6007,C6009	C-CERAMIC,CHIP
2203-007796	C6013,C6015,C6016	C-CERAMIC,CHIP
2203-007796	C6020,C6022,C6024	C-CERAMIC,CHIP
2203-007796	C6025,C6028,C6029	C-CERAMIC,CHIP
2203-007796	C6030,C6032,C6035	C-CERAMIC,CHIP
2203-007796	C6036,C7004,C7011	C-CERAMIC,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2203-007796	C7015,C7021,C7022	C-CERAMIC,CHIP
2203-007796	C7041,C7059,C8015	C-CERAMIC,CHIP
2203-007796	C8033,C8034,C8040	C-CERAMIC,CHIP
2203-007796	C8049,C8050,C8052	C-CERAMIC,CHIP
2203-007796	C8053,C8122,C8123	C-CERAMIC,CHIP
2203-007796	C8124	C-CERAMIC,CHIP
2203-008095	C4000	C-CERAMIC,CHIP
2203-008097	C1056,C1060,C1063	C-CERAMIC,CHIP
2203-008097	C5032,C5050,C8018	C-CERAMIC,CHIP
2203-008242	C3053,C3086,C3088	C-CERAMIC,CHIP
2203-008242	C6017,C6018,C7007	C-CERAMIC,CHIP
2203-008242	C7023,C7053	C-CERAMIC,CHIP
2203-008243	C8023	C-CERAMIC,CHIP
2203-008386	C3080	C-CERAMIC,CHIP
2203-008394	C1053	C-CERAMIC,CHIP
2203-008400	C1049,C1104,C2063	C-CERAMIC,CHIP
2203-008400	C3039,C3040,C3041	C-CERAMIC,CHIP
2203-008400	C3043,C3045,C3046	C-CERAMIC,CHIP
2203-008400	C3047,C3054,C3055	C-CERAMIC,CHIP
2203-008400	C3057,C3058,C3059	C-CERAMIC,CHIP
2203-008400	C3060	C-CERAMIC,CHIP
2203-008403	C3001,C3030,C3032	C-CERAMIC,CHIP
2203-008403	C8025,C8029	C-CERAMIC,CHIP
2203-008463	C1003,C1013,C7001	C-CERAMIC,CHIP
2203-008466	C1023,C2046,C2057	C-CERAMIC,CHIP
2203-008529	C3073	C-CERAMIC,CHIP
2203-008572	C5024,C5045	C-CERAMIC,CHIP
2203-008654	C6042	C-CERAMIC,CHIP
2203-008749	C5056	C-CERAMIC,CHIP
2203-008844	C7033	C-CERAMIC,CHIP
2203-008860	C1101,C2059,C3022	C-CERAMIC,CHIP
2203-008860	C3085,C5000,C5017	C-CERAMIC,CHIP
2203-008860	C5022,C5026,C5028	C-CERAMIC,CHIP
2203-008860	C5029,C5030,C5031	C-CERAMIC,CHIP
2203-008860	C5037,C5042,C5046	C-CERAMIC,CHIP
2203-008860	C5047,C5048,C5051	C-CERAMIC,CHIP
2203-008860	C5053,C5076,C5077	C-CERAMIC,CHIP
2203-008860	C5079,C5081,C5090	C-CERAMIC,CHIP
2203-008860	C5092,C6010,C6019	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-008860	C6023,C6027,C6051	C-CERAMIC,CHIP
2203-008860	C7014,C7028,C7035	C-CERAMIC,CHIP
2203-008860	C7058,C8017,C8027	C-CERAMIC,CHIP
2203-008860	C8035	C-CERAMIC,CHIP
2203-008876	C3089,C3091,C6026	C-CERAMIC,CHIP
2203-008876	C6033,C6034,C7018	C-CERAMIC,CHIP
2203-008876	C7026,C7036,C7044	C-CERAMIC,CHIP
2203-008876	C7050,C7051,C7055	C-CERAMIC,CHIP
2203-008876	C7056,C7136,C8042	C-CERAMIC,CHIP
2203-009064	C4018,C4029,C4035	C-CERAMIC,CHIP
2203-009064	C4036,C4079,C4083	C-CERAMIC,CHIP
2203-009064	C4084	C-CERAMIC,CHIP
2203-009167	C3099,C3104	C-CERAMIC,CHIP
2203-009444	C8038	C-CERAMIC,CHIP
2203-009618	C5016,C5018,C5019	C-CERAMIC,CHIP
2203-009618	C5020,C7061,C8004	C-CERAMIC,CHIP
2203-009618	C8011,C8019,C8037	C-CERAMIC,CHIP
2203-009733	C5004,C5008,C5010	C-CERAMIC,CHIP
2203-009733	C5011,C5034,C5035	C-CERAMIC,CHIP
2203-009733	C5038,C5040,C5041	C-CERAMIC,CHIP
2203-009733	C5043,C5044,C5052	C-CERAMIC,CHIP
2203-009733	C5054,C5057,C5060	C-CERAMIC,CHIP
2203-009733	C5061,C5062,C5078	C-CERAMIC,CHIP
2203-009733	C5082,C5086,C7008	C-CERAMIC,CHIP
2203-009733	C7012,C7013,C7016	C-CERAMIC,CHIP
2203-009733	C7017,C7071,C7072	C-CERAMIC,CHIP
2203-009733	C7073,C7074,C7075	C-CERAMIC,CHIP
2203-009733	C7076,C7078,C7079	C-CERAMIC,CHIP
2203-009733	C7080,C7081,C7082	C-CERAMIC,CHIP
2203-009734	C6021	C-CERAMIC,CHIP
2203-009735	C4057,C4058	C-CERAMIC,CHIP
2203-009858	C1064,C2060,C5036	C-CERAMIC,CHIP
2203-009858	C7027,C7062,C7063	C-CERAMIC,CHIP
2203-009858	C7064,C7065,C7066	C-CERAMIC,CHIP
2203-009858	C7067,C7068,C8007	C-CERAMIC,CHIP
2203-009858	C8055	C-CERAMIC,CHIP
2203-009859	C7005,C8020	C-CERAMIC,CHIP
2203-010066	C5025,C6046	C-CERAMIC,CHIP
2203-010085	C4001,C4012,C5080	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2409-001400	TA3000	CAPACITOR
2703-002649	L1032,L1045,L1070	INDUCTOR-SMD
2703-002901	L2008,L3019	INDUCTOR-SMD
2703-002903	L1004,L3018,L3025	INDUCTOR-SMD
2703-002907	L1027,L3027	INDUCTOR-SMD
2703-002951	L1021,L2014,L3032	INDUCTOR-SMD
2703-002953	L1025	INDUCTOR-SMD
2703-002955	L3007	INDUCTOR-SMD
2703-002958	L1020,L1026	INDUCTOR-SMD
2703-002959	L2013,L3036,L8009	INDUCTOR-SMD
2703-002961	L6003	INDUCTOR-SMD
2703-002999	L1029,L2009	INDUCTOR-SMD
2703-004001	L1017,L2000	INDUCTOR-SMD
2703-004012	L1033,L1051,L2016	INDUCTOR-SMD
2703-004013	L1006,L2041,L3010	INDUCTOR-SMD
2703-004013	L3011	INDUCTOR-SMD
2703-004014	L1010,L1016,L1041	INDUCTOR-SMD
2703-004014	L2036,L3006,L3014	INDUCTOR-SMD
2703-004014	L3015,L3017	INDUCTOR-SMD
2703-004018	L1037	INDUCTOR-SMD
2703-004034	L2012,L2033	INDUCTOR-SMD
2703-004037	L2005,L2010,L2021	INDUCTOR-SMD
2703-004038	L1013,L1042,L1077	INDUCTOR-SMD
2703-004038	L2024,L2031,L2032	INDUCTOR-SMD
2703-004038	L2040	INDUCTOR-SMD
2703-004193	L6004,L6005	INDUCTOR-SMD
2703-004286	L1002,L1031,L1036	INDUCTOR-SMD
2703-004286	L1038,L1063,L1065	INDUCTOR-SMD
2703-004286	L1079,L2004,L2020	INDUCTOR-SMD
2703-004286	L2025,L2027,L2028	INDUCTOR-SMD
2703-004287	L1007,L1024,L1039	INDUCTOR-SMD
2703-004287	L2003,L2023,L2026	INDUCTOR-SMD
2703-004288	L1005,L1011,L1028	INDUCTOR-SMD
2703-004288	L1034,L1056,L1078	INDUCTOR-SMD
2703-004288	L2002,L2018,L2037	INDUCTOR-SMD
2703-004288	L3034	INDUCTOR-SMD
2703-004289	L3016	INDUCTOR-SMD
2703-004299	L3012	INDUCTOR-SMD
2703-004302	L1003,L1019,L1055	INDUCTOR-SMD

5. MAIN Electrical Parts List

2703-004302	L3001,L3003,L3013	INDUCTOR-SMD
2703-004302	L6001,L6002	INDUCTOR-SMD
2703-004317	L2034	INDUCTOR-SMD
2703-004328	L1043,L3022,L3033	INDUCTOR-SMD
2703-004362	L2029	INDUCTOR-SMD
2703-004368	L1014,L1018,L1022	INDUCTOR-SMD
2703-004703	L2011	INDUCTOR-SMD
2703-004763	L1080	INDUCTOR-SMD
2703-004853	L2006,L3037	INDUCTOR-SMD
2703-004862	L1030,L1035	INDUCTOR-SMD
2703-005098	L2030	INDUCTOR-SMD
2703-005224	L7009	INDUCTOR-SMD
2703-005295	L2022	INDUCTOR-SMD
2703-005418	L7006	INDUCTOR-SMD
2703-005419	L7007	INDUCTOR-SMD
2703-005445	L2019	INDUCTOR-SMD
2703-005505	L7003,L8002,L8003	INDUCTOR-SMD
2703-005505	L8008	INDUCTOR-SMD
2703-005555	L3042,L3045	INDUCTOR-SMD
2703-005581	L5001,L5002,L5005	INDUCTOR-SMD
2703-005581	L5006,L5007,L5009	INDUCTOR-SMD
2703-005581	L5012,L5013,L5014	INDUCTOR-SMD
2703-005660	L5000,L5003,L5004	INDUCTOR-SMD
2703-005660	L5008,L5010	INDUCTOR-SMD
2703-005738	L5011	INDUCTOR-SMD
2801-005481	OSC5000	CRYSTAL-UNIT
2901-001690	C4059	FILTER-EMI SMD
2903-001576	F3000,F3001	FILTER-CERAMIC
2904-002143	F1012	FILTER-SAW
2904-002257	F2005	FILTER-SAW
2904-002285	F1006	FILTER-SAW
2904-002326	F2006	FILTER-SAW
2904-002339	F2003	FILTER-SAW
2904-002356	F3006,F3007	FILTER-SAW
2904-002381	F3003,F3004	FILTER-SAW
2904-002397	F1005,F2004	FILTER-SAW
2910-000401	F1011	FILTER
2911-000435	U2007	FILTER
2911-000458	U1004	FILTER

5. MAIN Electrical Parts List

3301-002122	L7013,L8000,L8001	CORE-FERRITE BEAD
3301-002223	L7000,L7001	CORE-FERRITE BEAD
3301-002236	L7004,L7011,L7012	CORE-FERRITE BEAD
3301-002236	L7014	CORE-FERRITE BEAD
3301-002237	L1000,L1001	CORE-FERRITE BEAD
3301-002238	L3000,L3031	CORE-FERRITE BEAD
3301-002286	L3043,L3044	CORE-FERRITE BEAD
3301-002312	L7005,L7008,L7010	CORE-FERRITE BEAD
3301-002331	L7002	CORE-FERRITE BEAD
3301-002336	L6000	CORE-FERRITE BEAD
3705-001937	RFS1000,RFS1001	CONNECTOR-COAXIAL
3705-001937	RFS2000	CONNECTOR-COAXIAL
3710-004008	SOC5000	CONNECTOR-SOCKET
3710-004109	HEA8000	CONNECTOR-SOCKET
3710-004285	SOC6000	CONNECTOR-SOCKET
3710-004367	SOC7000,SOC7001	CONNECTOR-SOCKET
3712-001694	ANT2001,ANT2002	CONNECTOR
3712-001694	ANT2003,ANT2004	CONNECTOR
3712-001694	ANT3002,ANT6000	CONNECTOR
3712-001694	ANT6001,ANT6002	CONNECTOR
3712-001694	ANT6003,ANT6007	CONNECTOR
3712-001694	ANT8000,ANT8001	CONNECTOR
3712-001731	ANT2000	CONNECTOR
3712-001749	ANT2005,ANT3000	CONNECTOR
3712-001749	ANT3001,ANT3003	CONNECTOR
3712-001749	ANT3004,ANT3005	CONNECTOR
3712-001749	ANT3006	CONNECTOR
4709-002226	F1000,F2002	RF-MODULE
4709-002285	F3002,F3008	RF-MODULE
4709-002351	F3005	RF-MODULE
4709-002589	F1004	RF-MODULE
GH63-17218A	SC6001	SC-AP
GH63-17219A	SC6003	SC-RF
GH63-17220A	SC6002	SC-PMIC
GH63-17221A	SC6000	SC-WIFI
GH02-18822A	SC6001SP	AP_TAPE

Please consult the GSPN website (Samsung Portal) for the most recent version of the product's part list.