

5. MAIN Electrical Parts List

Parts Code	Design LOC	Description
0404-001250	D5000	DIODE-SCHOTTKY
0406-001459	ZD6010,ZD6011	DIODE-TVS
0406-001561	ZD5012,ZD5013,ZD6000	DIODE-TVS
0406-001561	ZD6001,ZD6017	DIODE-TVS
0406-001592	ZD3002,ZD3003,ZD3004	DIODE-TVS
0406-001592	ZD3005,ZD3006,ZD3007	DIODE-TVS
0406-001592	ZD3008,ZD3009,ZD5001	DIODE-TVS
0406-001592	ZD5010,ZD7004,ZD7009	DIODE-TVS
0406-001592	ZD7010	DIODE-TVS
0406-001659	ZD3000,ZD3001,ZD3010	DIODE-TVS
0406-001659	ZD3011	DIODE-TVS
0406-001675	ZD1001,ZD5011	DIODE-TVS
0406-001709	ZD6013	DIODE-TVS
0406-001713	ZD5008,ZD5009	DIODE-TVS
0406-001729	ZD6005,ZD6007	DIODE-TVS
0406-001743	D6000,D6001,D6002	DIODE-TVS
0406-001743	D6003,D6004,ZD6003	DIODE-TVS
0406-001743	ZD6009,ZD6012	DIODE-TVS
0406-001780	ZD5003,ZD5004,ZD5005	DIODE-TVS
0406-001780	ZD5006,ZD7011	DIODE-TVS
0406-001781	ZD6014,ZD6015,ZD6016	DIODE-TVS
0406-001789	ZD6002,ZD6008	DIODE-TVS
0406-001807	ZD5000	DIODE-TVS
0406-001808	D5001	DIODE-TVS
0505-002088	TR7000	FET-SILICON
0505-003234	Q3000	FET-SILICON
0505-003618	Q5000	FET-SILICON
0601-003667	LED7000	LED
0903-002171	U3002	IC
1001-001844	U1016	IC
1001-001911	U2001	IC
1001-001974	U1003	IC
1001-001975	U3003	IC
1001-001999	U1008	IC
1001-002022	U1005,U1009,U1012	IC
1003-002769	U3013	IC
1003-002802	U2002	IC
1009-001066	U3007,U3011	IC

5. MAIN Electrical Parts List

1105-002915	UCP400UP	IC
1107-002552	UME5000	IC
1201-003786	U3005	IC
1201-003974	U1000	IC
1201-003979	U1010	IC
1201-004029	U1002,U1006	IC
1201-004036	U7014	IC
1201-004109	PAM1000	IC
1201-004129	PAM1001	IC
1201-004156	U6002	IC
1203-007884	U7006	IC
1203-008249	U3001,U7012	IC
1203-008250	U7011	IC
1203-008431	U7009	IC
1203-008475	U5000	IC
1203-008693	U1017	IC
1203-008719	U3016	IC
1203-008751	U7016	IC
1203-008865	U1011	IC
1203-008867	U3000,U3014,U3015	IC
1203-008867	U6003,U7013	IC
1203-008870	U7003,U7005,U7008	IC
1203-008872	U3012,U7010	IC
1203-008904	U5001	IC
1203-008913	U7007	IC
1203-008948	U6000	IC
1203-008955	U7001,U7004	IC
1203-008989	U7002	IC
1203-009029	U5006	IC
1204-003685	U6001	IC
1205-005845	U1007	IC
1205-005859	U2003	IC
1205-005860	U3004	IC
1205-005862	U3017	IC
1205-005870	UCP400	IC
1209-002428	U3010	IC
1209-002450	U3008	IC
1209-002513	U3009	IC
1404-001664	TH5000	THERMISTOR_NTC

5. MAIN Electrical Parts List

1404-001724	TH4000,TH4001,TH5001	THERMISTOR_NTC
1404-001734	TH2000	THERMISTOR_NTC
1405-001395	VR1004,VR1007,VR1008	VARISTOR
1405-001395	VR1009,VR1010,VR1013	VARISTOR
1405-001395	VR1014,VR2001,VR3000	VARISTOR
1405-001395	VR3001,VR3003,VR6004	VARISTOR
1405-001395	VR6005,VR6007,VR6008	VARISTOR
1405-001395	VR6009,VR6010,VR6011	VARISTOR
1405-001395	VR6012,VR6013,VR6015	VARISTOR
1405-001395	VR6016,VR6017	VARISTOR
1405-001404	VR1015,VR6006,VR6014	VARISTOR
1405-001404	VR6018	VARISTOR
1405-001410	VR1012	VARISTOR
1405-001412	VR1000	VARISTOR
1405-001425	VR1001	VARISTOR
1405-001439	VR1011	VARISTOR
1405-001445	VR3002,VR6000,VR6001	VARISTOR
1405-001445	VR6002,VR6003	VARISTOR
1405-001450	VR1003,VR1005,VR2000	VARISTOR
1405-001450	VR2002	VARISTOR
2007-007100	R1008	R-CHIP
2007-007142	R7002	R-CHIP
2007-007190	R6032,R6034	R-CHIP
2007-007405	R1001	R-CHIP
2007-007741	R2001,R2002,R2007	R-CHIP
2007-007741	R3016,R3022,R5004	R-CHIP
2007-007741	R5005,R5013,R5022	R-CHIP
2007-007741	R5023,R5026,R5027	R-CHIP
2007-007741	R5034,R5035,R5051	R-CHIP
2007-007741	R6033,R6036,R7001	R-CHIP
2007-007741	R7007	R-CHIP
2007-007798	R5039,R5040	R-CHIP
2007-007942	R5028	R-CHIP
2007-007946	R5033	R-CHIP
2007-008044	R3010,R3011,R3012	R-CHIP
2007-008044	R3013,R3014,R3015	R-CHIP
2007-008050	R3025	R-CHIP
2007-008531	R3018,R3019,R3020	R-CHIP
2007-008531	R5018,R7000	R-CHIP

5. MAIN Electrical Parts List

2007-008800	R6020	R-CHIP
2007-009111	R3017,R5050	R-CHIP
2007-009157	R3000,R4004,R4015	R-CHIP
2007-009157	R4040,R5008,R5019	R-CHIP
2007-009158	R5010	R-CHIP
2007-009171	R5006,R5014	R-CHIP
2007-009201	R5048,R6010,R6011	R-CHIP
2007-009201	R6018,R6019	R-CHIP
2007-009212	R4044,R4049,R5007	R-CHIP
2007-009212	R5012,R5017,R5049	R-CHIP
2007-009212	R6006,R6015	R-CHIP
2007-009314	R6004,R6014	R-CHIP
2007-009352	R3004,R3005,R4016	R-CHIP
2007-009352	R4017,R4018,R5016	R-CHIP
2007-009352	R7009	R-CHIP
2007-009408	R1007,R3001,R3002	R-CHIP
2007-009408	R3006,R3007,R4023	R-CHIP
2007-009408	R4024,R4025,R4027	R-CHIP
2007-009408	R4028,R4029,R4030	R-CHIP
2007-009408	R4031,R4032,R4034	R-CHIP
2007-009408	R4035,R4037,R4038	R-CHIP
2007-009408	R4039,R4041,R4042	R-CHIP
2007-009408	R6016	R-CHIP
2007-009410	R6024	R-CHIP
2007-009766	R3003,R6002,R6012	R-CHIP
2007-009793	R6022	R-CHIP
2007-009801	R5002,R7003	R-CHIP
2007-009805	R1000,R1010,R1011	R-CHIP
2007-009805	R1012,R1016,R2000	R-CHIP
2007-009920	R4006,R4007,R4008	R-CHIP
2007-009920	R4009	R-CHIP
2007-009969	R6017	R-CHIP
2007-010202	R1013,R3023	R-CHIP
2007-011043	R4010,R4011,R4012	R-CHIP
2007-011043	R4013,R4014	R-CHIP
2007-011532	R6031	R-CHIP
2007-011648	R7008	R-CHIP
2007-012033	R6001	R-CHIP
2007-012038	R5011	R-CHIP

5. MAIN Electrical Parts List

2007-012068	R5025	R-CHIP
2203-000489	C5143,C5144	C-CERAMIC, CHIP
2203-000812	C3082,C3097	C-CERAMIC, CHIP
2203-000995	C3084,C3096,C5116	C-CERAMIC, CHIP
2203-001153	C3093,C5117	C-CERAMIC, CHIP
2203-001239	C5034,C5126	C-CERAMIC, CHIP
2203-002443	C3081	C-CERAMIC, CHIP
2203-005053	C3094	C-CERAMIC, CHIP
2203-005682	C1033,C1048,C1058	C-CERAMIC, CHIP
2203-005682	C2053,C3042,C3044	C-CERAMIC, CHIP
2203-005682	C3054,C3055,C5111	C-CERAMIC, CHIP
2203-005682	C5112,C5113,C5146	C-CERAMIC, CHIP
2203-005682	C5147,C6016,C6033	C-CERAMIC, CHIP
2203-005682	C6038,C6040,C7232	C-CERAMIC, CHIP
2203-005682	L1065	C-CERAMIC, CHIP
2203-005719	C1000,C3091	C-CERAMIC, CHIP
2203-005725	C2002,C3028	C-CERAMIC, CHIP
2203-005726	C6042,C6045,C7047	C-CERAMIC, CHIP
2203-005727	C2027,L1093	C-CERAMIC, CHIP
2203-005729	C5142,C6000,C6007	C-CERAMIC, CHIP
2203-005729	C7007,L3001,L3002	C-CERAMIC, CHIP
2203-005731	C2001,C6051,C6052	C-CERAMIC, CHIP
2203-005731	L1035	C-CERAMIC, CHIP
2203-005732	C5118	C-CERAMIC, CHIP
2203-005734	C6049,C6050	C-CERAMIC, CHIP
2203-005736	C1001,C1003,C1004	C-CERAMIC, CHIP
2203-005736	C1005,C1009,C1012	C-CERAMIC, CHIP
2203-005736	C1013,C1018,C1021	C-CERAMIC, CHIP
2203-005736	C1025,C1029,C1034	C-CERAMIC, CHIP
2203-005736	C1035,C1053,C1055	C-CERAMIC, CHIP
2203-005736	C1069,C1072,C1074	C-CERAMIC, CHIP
2203-005736	C1078,C1079,C1080	C-CERAMIC, CHIP
2203-005736	C1082,C1084,C1100	C-CERAMIC, CHIP
2203-005736	C1101,C1103,C1121	C-CERAMIC, CHIP
2203-005736	C1132,C1168,C1173	C-CERAMIC, CHIP
2203-005736	C1174,C2000,C2004	C-CERAMIC, CHIP
2203-005736	C2005,C2011,C2012	C-CERAMIC, CHIP
2203-005736	C2031,C2032,C2034	C-CERAMIC, CHIP
2203-005736	C2040,C2050,C2051	C-CERAMIC, CHIP

5. MAIN Electrical Parts List

2203-005736	C2054,C2056,C2060	C-CERAMIC, CHIP
2203-005736	C2061,C2062,C2067	C-CERAMIC, CHIP
2203-005736	C2069,C2071,C2073	C-CERAMIC, CHIP
2203-005736	C3001,C3002,C3005	C-CERAMIC, CHIP
2203-005736	C3006,C3014,C3017	C-CERAMIC, CHIP
2203-005736	C3019,C3043,C3045	C-CERAMIC, CHIP
2203-005736	C3092,L1002,L1051	C-CERAMIC, CHIP
2203-005736	L1062,L1090,L1107	C-CERAMIC, CHIP
2203-005736	L1121,L1122,L2004	C-CERAMIC, CHIP
2203-005736	L2014,L2036,L3017	C-CERAMIC, CHIP
2203-005736	R1002	C-CERAMIC, CHIP
2203-005777	C1099,C1128,C2041	C-CERAMIC, CHIP
2203-005777	C2052,C3099,L1025	C-CERAMIC, CHIP
2203-005779	C7009,C7015	C-CERAMIC, CHIP
2203-005789	C1047,C1054,C1126	C-CERAMIC, CHIP
2203-005789	C1144,C1153,C1154	C-CERAMIC, CHIP
2203-005789	C1157,C3036,L1020	C-CERAMIC, CHIP
2203-005789	L1046,L1052,L1057	C-CERAMIC, CHIP
2203-005789	L1060,L1067	C-CERAMIC, CHIP
2203-005792	C6009	C-CERAMIC, CHIP
2203-005806	C1041,C1042,C1045	C-CERAMIC, CHIP
2203-005806	C2023,C2024	C-CERAMIC, CHIP
2203-006048	C3059	C-CERAMIC, CHIP
2203-006121	C6048	C-CERAMIC, CHIP
2203-006123	L1040,L2017	C-CERAMIC, CHIP
2203-006187	C1022,C1024,C1062	C-CERAMIC, CHIP
2203-006187	C1097,C2017,C2020	C-CERAMIC, CHIP
2203-006187	C6012,L1100	C-CERAMIC, CHIP
2203-006194	C2066,C6017,C6032	C-CERAMIC, CHIP
2203-006194	C6054	C-CERAMIC, CHIP
2203-006305	L1069,L1111	C-CERAMIC, CHIP
2203-006318	C1006,C1146,C1160	C-CERAMIC, CHIP
2203-006318	L1053	C-CERAMIC, CHIP
2203-006399	C3020,C7003,C7004	C-CERAMIC, CHIP
2203-006400	C1031,C1057,C1068	C-CERAMIC, CHIP
2203-006400	C1071,C2065,C3016	C-CERAMIC, CHIP
2203-006400	C3032,C3053,C4011	C-CERAMIC, CHIP
2203-006400	C6023,C6047,C7048	C-CERAMIC, CHIP
2203-006400	C7049,R5021	C-CERAMIC, CHIP

5. MAIN Electrical Parts List

2203-006410	C1127	C-CERAMIC, CHIP
2203-006556	C1075,C1122,C1135	C-CERAMIC, CHIP
2203-006556	C1138,C1141,C6039	C-CERAMIC, CHIP
2203-006556	C6046,L1015	C-CERAMIC, CHIP
2203-006562	C5099,C5100,C7072	C-CERAMIC, CHIP
2203-006562	C7074,C7231	C-CERAMIC, CHIP
2203-006604	C6010	C-CERAMIC, CHIP
2203-006611	C1162,L1041	C-CERAMIC, CHIP
2203-006620	C7045	C-CERAMIC, CHIP
2203-006642	C6022,C6028	C-CERAMIC, CHIP
2203-006648	C6043	C-CERAMIC, CHIP
2203-006665	C3027,C3052	C-CERAMIC, CHIP
2203-006668	C2064,C4043	C-CERAMIC, CHIP
2203-006674	L1027	C-CERAMIC, CHIP
2203-006707	C3024	C-CERAMIC, CHIP
2203-006839	C1065,C1136,C1137	C-CERAMIC, CHIP
2203-006839	C1139,C1142,C2014	C-CERAMIC, CHIP
2203-006839	C2037,C2049,C3008	C-CERAMIC, CHIP
2203-006839	C3009,C3010,C3011	C-CERAMIC, CHIP
2203-006839	C3023,C3056,C3058	C-CERAMIC, CHIP
2203-006839	C3060,C3061,C3062	C-CERAMIC, CHIP
2203-006839	C3067,C4005,C4012	C-CERAMIC, CHIP
2203-006839	C4016,C4032,C5004	C-CERAMIC, CHIP
2203-006839	C5017,C5093,C5124	C-CERAMIC, CHIP
2203-006839	C5125,C6001,C6003	C-CERAMIC, CHIP
2203-006839	C6005,C6013,C6015	C-CERAMIC, CHIP
2203-006839	C6034,C6041,C6044	C-CERAMIC, CHIP
2203-006846	C4026,C4027,C4028	C-CERAMIC, CHIP
2203-006846	C4029	C-CERAMIC, CHIP
2203-006872	C5049,C5050,C5052	C-CERAMIC, CHIP
2203-006872	C5053,C5055,C5062	C-CERAMIC, CHIP
2203-006872	C5069,C5070,C5073	C-CERAMIC, CHIP
2203-006872	C5076,C5086,C5091	C-CERAMIC, CHIP
2203-006872	C5128,C5130,C7005	C-CERAMIC, CHIP
2203-006979	C2022,C2026,C2029	C-CERAMIC, CHIP
2203-006979	C2035,C2039,C2043	C-CERAMIC, CHIP
2203-006979	C2045,C2048	C-CERAMIC, CHIP
2203-007194	L1127,L3010	C-CERAMIC, CHIP
2203-007210	C4057,C4101,C4102	C-CERAMIC, CHIP

5. MAIN Electrical Parts List

2203-007210	C4103,C4105,C5060	C-CERAMIC, CHIP
2203-007210	C5087	C-CERAMIC, CHIP
2203-007271	C1140,C5011,C5012	C-CERAMIC, CHIP
2203-007271	C5097	C-CERAMIC, CHIP
2203-007392	C5037,C5098,C5158	C-CERAMIC, CHIP
2203-007393	C5005,C5020,C5024	C-CERAMIC, CHIP
2203-007393	C5025,C5043,C5045	C-CERAMIC, CHIP
2203-007393	C5048,C5057,C5059	C-CERAMIC, CHIP
2203-007393	C5141	C-CERAMIC, CHIP
2203-007403	C1014	C-CERAMIC, CHIP
2203-007456	C1043,C1044,C5023	C-CERAMIC, CHIP
2203-007456	C5115	C-CERAMIC, CHIP
2203-007474	C4052,C4055,C4071	C-CERAMIC, CHIP
2203-007775	C1170,C5014,C5077	C-CERAMIC, CHIP
2203-007775	C5139	C-CERAMIC, CHIP
2203-007781	C7053,C7067,C7230	C-CERAMIC, CHIP
2203-007796	C1076,C1171,C2003	C-CERAMIC, CHIP
2203-007796	C2028,C2038,C2042	C-CERAMIC, CHIP
2203-007796	C2047,C3013,C3015	C-CERAMIC, CHIP
2203-007796	C3038,C3040,C3066	C-CERAMIC, CHIP
2203-007796	C3068,C3069,C3071	C-CERAMIC, CHIP
2203-007796	C3072,C3079,C3080	C-CERAMIC, CHIP
2203-007796	C3087,C3088,C3089	C-CERAMIC, CHIP
2203-007796	C4001,C4003,C4004	C-CERAMIC, CHIP
2203-007796	C4006,C4007,C4008	C-CERAMIC, CHIP
2203-007796	C4013,C4014,C4018	C-CERAMIC, CHIP
2203-007796	C4019,C4020,C4021	C-CERAMIC, CHIP
2203-007796	C4023,C4024,C4025	C-CERAMIC, CHIP
2203-007796	C4030,C4031,C4033	C-CERAMIC, CHIP
2203-007796	C4035,C4036,C4037	C-CERAMIC, CHIP
2203-007796	C4038,C4039,C4041	C-CERAMIC, CHIP
2203-007796	C4042,C4044,C4045	C-CERAMIC, CHIP
2203-007796	C4046,C4047,C4048	C-CERAMIC, CHIP
2203-007796	C4061,C4062,C4064	C-CERAMIC, CHIP
2203-007796	C4065,C4066,C4067	C-CERAMIC, CHIP
2203-007796	C4074,C4075,C4076	C-CERAMIC, CHIP
2203-007796	C4078,C4079,C4080	C-CERAMIC, CHIP
2203-007796	C4082,C4083,C4084	C-CERAMIC, CHIP
2203-007796	C4087,C4088,C4089	C-CERAMIC, CHIP

5. MAIN Electrical Parts List

2203-007796	C4090,C4091,C4092	C-CERAMIC, CHIP
2203-007796	C4093,C4094,C4095	C-CERAMIC, CHIP
2203-007796	C4096,C4097,C4098	C-CERAMIC, CHIP
2203-007796	C4099,C5003,C5038	C-CERAMIC, CHIP
2203-007796	C5040,C5056,C5061	C-CERAMIC, CHIP
2203-007796	C5063,C5065,C5066	C-CERAMIC, CHIP
2203-007796	C5067,C5068,C5071	C-CERAMIC, CHIP
2203-007796	C5072,C5074,C5075	C-CERAMIC, CHIP
2203-007796	C5078,C5079,C5080	C-CERAMIC, CHIP
2203-007796	C5081,C5082,C5083	C-CERAMIC, CHIP
2203-007796	C5084,C5085,C5088	C-CERAMIC, CHIP
2203-007796	C5090,C5129,C5157	C-CERAMIC, CHIP
2203-007796	C6004,C6006,C6018	C-CERAMIC, CHIP
2203-007796	C6019,C6020,C6026	C-CERAMIC, CHIP
2203-007796	C6035,C6036,C7014	C-CERAMIC, CHIP
2203-007796	C7016,C7018,C7020	C-CERAMIC, CHIP
2203-007796	C7022,C7024,C7026	C-CERAMIC, CHIP
2203-007796	C7027,C7031,C7033	C-CERAMIC, CHIP
2203-007796	C7034,C7035,C7037	C-CERAMIC, CHIP
2203-007796	C7038,C7039,C7040	C-CERAMIC, CHIP
2203-007796	C7042,C7044,C7046	C-CERAMIC, CHIP
2203-007796	C7069,C7070,C7075	C-CERAMIC, CHIP
2203-007796	C7076	C-CERAMIC, CHIP
2203-008094	C1070	C-CERAMIC, CHIP
2203-008097	C1007,C1020,C1056	C-CERAMIC, CHIP
2203-008097	C6029	C-CERAMIC, CHIP
2203-008158	C5028,C5033	C-CERAMIC, CHIP
2203-008242	C3000,C3003,C3004	C-CERAMIC, CHIP
2203-008242	C3018,C4000,C4002	C-CERAMIC, CHIP
2203-008242	C4015,C4040,C5001	C-CERAMIC, CHIP
2203-008242	C5136,C5137,C5138	C-CERAMIC, CHIP
2203-008242	C7011,C7012	C-CERAMIC, CHIP
2203-008312	C4049,C4059,C4069	C-CERAMIC, CHIP
2203-008312	C5008,C5015,C5019	C-CERAMIC, CHIP
2203-008312	C5027,C5030,C5032	C-CERAMIC, CHIP
2203-008312	C5039,C5044,C5047	C-CERAMIC, CHIP
2203-008386	C3064	C-CERAMIC, CHIP
2203-008394	L1110	C-CERAMIC, CHIP
2203-008529	C3057	C-CERAMIC, CHIP

5. MAIN Electrical Parts List

2203-008572	C5016,C5064,C5149	C-CERAMIC, CHIP
2203-008654	C5119	C-CERAMIC, CHIP
2203-008749	C5101	C-CERAMIC, CHIP
2203-008860	C1077,C2013,C3012	C-CERAMIC, CHIP
2203-008860	C3037,C3065,C3073	C-CERAMIC, CHIP
2203-008860	C3074,C3077,C3083	C-CERAMIC, CHIP
2203-008860	C5105,C5154,C6027	C-CERAMIC, CHIP
2203-008860	C7017,C7019,C7021	C-CERAMIC, CHIP
2203-008860	C7023,C7025,C7030	C-CERAMIC, CHIP
2203-008860	C7032,C7041,C7043	C-CERAMIC, CHIP
2203-008876	C3078,C5133,C5134	C-CERAMIC, CHIP
2203-008876	C5135,C7028,C7029	C-CERAMIC, CHIP
2203-008876	C7036,C7051,C7054	C-CERAMIC, CHIP
2203-008876	C7071	C-CERAMIC, CHIP
2203-009210	C3086,C3095	C-CERAMIC, CHIP
2203-009537	C5051	C-CERAMIC, CHIP
2203-009618	C5150,C6031	C-CERAMIC, CHIP
2203-009733	C1143,C1169,C2021	C-CERAMIC, CHIP
2203-009733	C2025,C2036,C2044	C-CERAMIC, CHIP
2203-009733	C3047,C3075,C5007	C-CERAMIC, CHIP
2203-009733	C5010,C5013,C5018	C-CERAMIC, CHIP
2203-009733	C5022,C5029,C5031	C-CERAMIC, CHIP
2203-009733	C5035,C5041,C5046	C-CERAMIC, CHIP
2203-009733	C7000,C7001,C7008	C-CERAMIC, CHIP
2203-009733	C7010,C7013,C7056	C-CERAMIC, CHIP
2203-009736	C3007,C3021,C3049	C-CERAMIC, CHIP
2203-009736	C4010,C4017,C4022	C-CERAMIC, CHIP
2203-009736	C4034,C4077,C4081	C-CERAMIC, CHIP
2203-009736	C5006,C5058,C5089	C-CERAMIC, CHIP
2203-009736	C5131,C5132,C5164	C-CERAMIC, CHIP
2203-009736	C6002,C6014	C-CERAMIC, CHIP
2203-009858	C5009,C6024,C6025	C-CERAMIC, CHIP
2203-009859	C7057,C7058	C-CERAMIC, CHIP
2203-009969	C6030	C-CERAMIC, CHIP
2409-001399	TA3000	C-POLYMER, CHIP
2703-002858	L1011,L1074,L1077	INDUCTOR
2703-002858	L1079,L1120,L2013	INDUCTOR
2703-002900	C1158,L6002	INDUCTOR
2703-002901	C1067,L1031,L1034	INDUCTOR

5. MAIN Electrical Parts List

2703-002901	L2012	INDUCTOR
2703-002903	L6003,L6020	INDUCTOR
2703-002907	L1058,L2018,L3009	INDUCTOR
2703-002951	C1134	INDUCTOR
2703-002953	C3029,L2035	INDUCTOR
2703-002955	C1150	INDUCTOR
2703-002958	C3022,L1004,L1012	INDUCTOR
2703-002958	L1019,L2002	INDUCTOR
2703-002959	C1095,L1028,L1039	INDUCTOR
2703-002959	L1048,L1130,L2005	INDUCTOR
2703-002959	L7000,L7001	INDUCTOR
2703-002999	L1072	INDUCTOR
2703-003121	L1021	INDUCTOR
2703-003476	L3000	INDUCTOR
2703-003479	L6000,L6001	INDUCTOR
2703-003878	L6017	INDUCTOR
2703-003970	C1124,C3048,L1126	INDUCTOR
2703-004000	C3098	INDUCTOR
2703-004001	L2009	INDUCTOR
2703-004012	C1002,C1017,L1010	INDUCTOR
2703-004012	L1044,L1059,L1106	INDUCTOR
2703-004012	L2033	INDUCTOR
2703-004013	C1010,C1073,C2016	INDUCTOR
2703-004013	L1050,L1112,L2034	INDUCTOR
2703-004014	C1015,C3035,C3046	INDUCTOR
2703-004018	C1148,L1061,L1075	INDUCTOR
2703-004018	L1109,L3004,L3018	INDUCTOR
2703-004032	C3034,L1038	INDUCTOR
2703-004033	L1073	INDUCTOR
2703-004034	C1019,C1050,C1133	INDUCTOR
2703-004034	L1014,L1108,L1129	INDUCTOR
2703-004034	L2003,L2006	INDUCTOR
2703-004035	C1049,L1081,L2026	INDUCTOR
2703-004035	L2037	INDUCTOR
2703-004036	C1151,C2010,L1029	INDUCTOR
2703-004036	L1055	INDUCTOR
2703-004037	C1059,L1007,L1118	INDUCTOR
2703-004037	L2008,L2022,L2029	INDUCTOR
2703-004038	C2059,L2040	INDUCTOR

5. MAIN Electrical Parts List

2703-004212	L6011	INDUCTOR
2703-004259	L2015	INDUCTOR
2703-004286	L2032	INDUCTOR
2703-004287	C2068,C2070,C2072	INDUCTOR
2703-004287	L2027	INDUCTOR
2703-004288	L2038	INDUCTOR
2703-004300	C1036,L1016,L1043	INDUCTOR
2703-004300	L1116,L3005	INDUCTOR
2703-004317	C3025	INDUCTOR
2703-004328	L1083	INDUCTOR
2703-004365	C1032,L1013	INDUCTOR
2703-004366	C1038,L1001,L1018	INDUCTOR
2703-004366	L1026,L1066,L1068	INDUCTOR
2703-004366	L1102,L1103,L1104	INDUCTOR
2703-004366	L1105,L1114,L1119	INDUCTOR
2703-004366	L2039,L3003	INDUCTOR
2703-004367	L1030	INDUCTOR
2703-004763	C1064,C2033,L1101	INDUCTOR
2703-004764	L2016,L2042	INDUCTOR
2703-004862	C1030,L1063,L1064	INDUCTOR
2703-004911	C1102,L1009	INDUCTOR
2703-004976	L2041	INDUCTOR
2703-005066	L1125	INDUCTOR
2703-005067	L5000,L5005,L5006	INDUCTOR
2703-005067	L5007,L5008	INDUCTOR
2703-005085	L1017,L1113	INDUCTOR
2703-005087	C1066,C1172,L1076	INDUCTOR
2703-005089	C1016	INDUCTOR
2703-005117	L7011,L7014	INDUCTOR
2703-005118	L7010	INDUCTOR
2703-005136	L5009	INDUCTOR
2703-005201	L5002,L5004,L5014	INDUCTOR
2703-005372	L3015,L3016	INDUCTOR
2703-005505	L6005,L7005	INDUCTOR
2703-005581	L5003	INDUCTOR
2801-005393	OSC5000	CRYSTAL-SMD
2805-001118	TCX2000	OSCILLATOR-TCXO
2901-001690	C4050,C4054,C4056	FILTER-EMI SMD
2901-001690	C4058,C4060,C4072	FILTER-EMI SMD

5. MAIN Electrical Parts List

2901-001690	C4085	FILTER-EMI SMD
2901-001798	F7010,F7011,F7012	FILTER-EMI SMD
2901-001798	F7013,F7014	FILTER-EMI SMD
2904-002143	F1005	FILTER-SAW
2904-002211	F2001	FILTER-SAW
2904-002256	F1011	FILTER-SAW
2904-002257	F2004	FILTER-SAW
2904-002326	F2005	FILTER-SAW
2904-002339	F2002	FILTER-SAW
2904-002345	F1010	FILTER-SAW
2904-002349	F2003	FILTER-SAW
2904-002350	F1003	FILTER-SAW
2904-002355	U3006	FILTER-SAW
2904-002365	F1002	FILTER-SAW
2904-002381	F3000	FILTER-SAW
2910-000364	F1007	DUPLEXER-SAW
2910-000390	F1004	DUPLEXER-SAW
2910-000402	F1006	DUPLEXER-SAW
2910-000404	F1008	DUPLEXER-SAW
2911-000430	U2004	DUPLEXER-FEM
2911-000452	U1001	DUPLEXER-FEM
3003-001232	MIC6000,MIC6001	MIC MEMS
3301-001885	L6012	BEAD-SMD
3301-001895	L3007	BEAD-SMD
3301-002078	L6007,L6009,L6013	BEAD-SMD
3301-002078	L6014,L6015,L6016	BEAD-SMD
3301-002078	L6018,L6019	BEAD-SMD
3301-002122	L1123,L1124,L6004	BEAD-SMD
3301-002122	L6006	BEAD-SMD
3301-002223	L7002,L7003,L7004	BEAD-SMD
3301-002236	L3011,L3012,L6008	BEAD-SMD
3301-002236	L6010	BEAD-SMD
3301-002237	L1000,L1087,L1088	BEAD-SMD
3301-002237	L2043,L2046,L3008	BEAD-SMD
3301-002238	L2000,L2025,L2044	BEAD-SMD
3301-002243	L2021,L2023	BEAD-SMD
3301-002286	L3013,L3014	BEAD-SMD
3301-002312	L2019,L2020,L2028	BEAD-SMD
3301-002312	L2031,L7009,L7012	BEAD-SMD

5. MAIN Electrical Parts List

3301-002312	L7013	BEAD-SMD
3301-002331	L5016,L5017	BEAD-SMD
3705-001708	RFS1000,RFS1001	CONNECTOR-COAXIAL
3709-001883	SIM6001	CONNECTOR-CARD EDGE
3709-001892	SIM6000	CONNECTOR-CARD EDGE
3711-008508	HEA7000	HEADER-BOARD TO BOARD
3711-008593	HEA7001	HEADER-BOARD TO BOARD
3711-008716	HEA7002	HEADER-BOARD TO BOARD
3711-008824	HEA3000,HEA3001	HEADER-BOARD TO BOARD
3711-008847	HDC5000	CONNECTOR-BATTERY
3711-008997	HEA6000	HEADER-BOARD TO BOARD
3712-001604	ANT1004,ANT1006	CONNECTOR-TERMINAL
3712-001604	ANT1007,ANT1008	CONNECTOR-TERMINAL
3712-001604	ANT1009,ANT1010	CONNECTOR-TERMINAL
3712-001604	ANT1012,ANT1013	CONNECTOR-TERMINAL
3712-001604	ANT1014,ANT1015	CONNECTOR-TERMINAL
3712-001604	ANT2003,ANT3002	CONNECTOR-TERMINAL
3712-001604	ANT3003,ANT3004	CONNECTOR-TERMINAL
3712-001604	ANT3005,ANT5000	CONNECTOR-TERMINAL
3712-001604	ANT5004,ANT6000	CONNECTOR-TERMINAL
3712-001604	ANT6001,ANT6002	CONNECTOR-TERMINAL
3712-001604	ANT6003	CONNECTOR-TERMINAL
3712-001626	ANT5002,ANT5003	CONNECTOR-TERMINAL
3712-001634	ANT5001,ANT5005	CONNECTOR-TERMINAL
3712-001634	ANT5006	CONNECTOR-TERMINAL
3712-001666	ANT1005,ANT2002	CONNECTOR-TERMINAL
3712-001666	ANT2004,ANT2005	CONNECTOR-TERMINAL
3712-001666	ANT3000	CONNECTOR-TERMINAL
3712-001731	ANT1001,ANT1003	CONNECTOR-TERMINAL
3712-001731	ANT3006	CONNECTOR-TERMINAL
3722-004107	IFC5000	JACK-USB
4709-002187	CPL1000	COUPLER-DIRECTION
4709-002284	F3001	FREQ-DISTRIBUTER
4709-002387	F1001	FREQ-DISTRIBUTER
4709-002464	F2000	FREQ-DISTRIBUTER
4709-002589	CPL1001	COUPLER-DIRECTION
GH02-15843A	SC6006SP	TAPE ABSORBER-SHILED AP
GH61-08265A	SUS6000	PLATE-SMD
GH61-12423A	CN6000	PLATE-SUS-SCREW-1-SUBPCB

5. MAIN Electrical Parts List

GH61-13152A	SUS6001	PLATE-SMD
GH62-00043A	CN6001,CON6000	SMD GASKET
GH63-10971A	SC6009	SHIELD CAN
GH63-12069A	SC6008	SHIELD CAN
GH63-13700A	SC6006	SHIELD CAN
GH63-13704A	SC6004	SHIELD CAN
GH63-14237A	SC6011	SHIELD CAN
GH63-14916A	SC6000	SHIELD CAN
GH63-15221A	SC6003	SHIELD CAN
GH63-15222A	SC6005	SHIELD CAN
GH63-15223A	SC6001	SHIELD CAN

Please consult the GSPN website (Samsung Portal) for the most recent version of the product's part list.